

Multi-Functional Mobiles Remote

Work for iPhone or for iPad

(iOS 6.0+)


Please Read Me. . .

Tiktok users, please must read me!



Manual

Bluetooth Pairing



1. Turn on this Bluetooth Remote.
2. Turn on Bluetooth on your cellphone.
3. Scan to find "DY-Remoter", then pairing with it.

eBook Remote/PPT Remote

- eBook apps

(Applicable apps: Kindle, Aldko Book Reader, AlReader etc.)

1. Open an "eBook" app on cellphone.
2. Press "Left" or "Right" button to turn the page.
(**Note:** for some eBook apps, you need to press "Up" or "Down" button to turn the page.)

- PPT apps

(Applicable apps: MS PowerPoint, Google Slides, Acrobat, Keynote, ACDSee Pro.)

1. Open a "PPT" app on cellphone.
2. Press "Left" or "Right" button to slide the page.
(**Note:** for some PPT apps, you need to press "Up" or "Down" button to slide the page.)

Note:It is important!!!


If the remote cannot work, please set your phone as below:

(Settings>Accessibility>Touch>AssistiveTouch>TRACKING SENSITIVITY)

- 1.please make sure turn "on" the AssistiveTouch in Iphone.
- 2.Ajust the TRACKING SENSITIVITY TO 50%.



Camera Remote



1. Open "Camera" on your cellphone.
2. Hold on "Left" or "Right" Button for 3 seconds to take photo/take video.
3. When taking video, if you want to stop recording video, press "Left" or "Right" button for 3 seconds again.

Note:

If "Left" or "Right" button NOT work, try as below:

1. Hold on the "Shutter Button", then press the Up/Down/Left/Right to adjust the dot pointer to Camera button.
2. Then you can just press "Shutter Button" to take photo or take video.



Tiktok Remote

Note:It is important!!!

(Settings>Accessibility>Touch>AssistiveTouch>TRACKING SENSITIVITY)

- 1.please make sure turn "on" the AssistiveTouch in Iphone.
- 2.Ajust the TRACKING SENSITIVITY TO 50%.


Without the above two settings, it can NOT work on Tiktok!

1. Open "Tiktok" app .
2. Press "Left" or "Right" button to select the tab.
3. Press "Up" or "Down" to scroll up/down videos.
4. Press "Function Button" to Play/Pause video.
5. Double-click "Function Button" to thumb-up video.
6. Hold on "Right" / "Left" to do the Volume Control.
7. When getting to take photo or video on Tiktok, press "Shutter Button" to do it.

(Note: If "Shutter Button" NOT work, try this way:

1. Hold on the "Shutter Button", then press the Up/Down/Left/Right to adjust the dot pointer to Camera button.
2. Then you can just press "Shutter Button" to take photo or take video.)

Function Button



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and**
- (2) this device must accept any interference received, including interference that may cause undesired operation.**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.