

Manual Instruction

Please read the instructions carefully before using the controller.

1. Features

The controller is adopted by the most advanced PWM control technology, and has memory function (The light status will keep same as the status before you turn off the light) ; Wireless and 4G controlled by Tuya Smart Life APP.

- 16 Millions of colors to choose

WiFi wireless control

Color temperature 2700K-6500K

Smartphone APP control

Dim brightness / saturation

Support third party voice control

Support music rhythm

Device sharing

Support scene customization

Group control

Timing setting / countdown turn on / off LED light

Auto-transmitting & Synchronization

Bluetooth wireless control


Tap-to-Run & automation


Free screw when connecting to LED strip

Link/Unlink/Reset Button on the controller

WiFi Smart LED Products
Model No.: WB5

2. Parameters

Model No.: WB5
Input Voltage: DC12V-24V (5.5*2. 1mm) 
Output: 6A/Channel (Total Output Max. 15A)
Working Temperature: -20-60°C
Communication Mode: WiFi-IEEE 802. 11b/g/n 2. 4GHz
RF: 2. 4GHz Weight: 65g







Smart Link&Unlink: We have 3 methods to Link and Unlink to APP.
1. Long press "SET" 3 seconds,the purple will blink 3 times,the device go into Smart Link/Unlink mode.
2. Switch ON and OFF 3 times(ON-OFF-ON-OFF-ON) within 10 seconds,the purple light will blink 3 time, the device go into Smart Link and Unlink Mode.

Note:Pilot lamp red light always ON means device not link to APP, need to do above steps to link. green light always ON means device linked to APP;device is controllable.

Switching Output Mode: Short press "SET" button to switch the output mode; The indicating lamp flickering means switching successfully; Different colors flickering correspond to different output mode; Details see below sheet.

White Light Flickering	Yellow Light Flickering	Red Light Flickering	Green Light Flickering	Blue Light Flickering
Single Color Mode	Dual White Mode	RGB Mode	RGBW Mode	RGB+CCT Mode (Default Mode)




Suggestion: Complete the network distribution of the equipment first, then adjust the output mode Pilot lamp.

Indicating light instruction:

Red light always-on	Green light always-on	Red light blinking	Blue light always-on
Disconnected from network	Networking successfully	Waiting for smart link	WiFi router disconnected but still controllable

3. Connect to LED strip

 Controller input voltage must be in accordance with the required voltage of LED Strips.
Input voltage=Output Voltage



Switching Bluetooth control steps:

- Complete the network distribution of the equipment.
- Power off the router used for network configuration, turn off WiFi on the mobile phone, turn on Bluetooth, and wait for about 3-5 minutes to control.

Tuya Smart Life APP WiFi Control Instruction:

1,Download and install [Tuya Smart] APP or [Smart Life] APP


Search for [Smart Life] in Apple or Google store or scan following QR code to download and install the app.

Please click "Register" button to create account while using it in the first time, Log in directly if you already had account.



2, Connect to Smartphone

- Connect controller with power supply.
- Confirm Pilot lamp is flashing quickly (2 flashes per second)
If Pilot lamp isn't in fast flashing state, there are two ways to enter:
 - Long press "SET" key until Pilot lamp flashing quickly.
 - Power OFF and ON once, long press Zone ON button of linked remote until the LED strip blinking 3 times. (available remote model: LM091)
- Connect phone with home WiFi network in the 2.4GHz frequency.
- Open homepage of APP and click "+" button at the upper right corner of page.If the pilot lamp is flashing red, it will find the new device automatically.




- Added devices will be displayed on home page after network configuration is successful.
- Click device you want to control to enter the control interface.




4,Device name editing, third-party control, device sharing,Group control.

- Click "+" on the upper right corner of control page to enter edit page, where you can modify device name, icon, etc.
- Click icon under third-party control to view detailed description of third-party control.
- Click "Share Device" to share device with family and friends.
- Click "Create Group" and follow APP prompt after setting is completed, the device can be controlled by group.



5 Intelligent control


- Click "Smart" at the bottom.
- Click "+" in the upper right corner to create intelligent control.




3,APP Control

- Click "device" or "group" you want to control on homepage to enter control page, where you can control color, saturation, brightness, color temperature, and scene.
- Click music sync to enter music rhythm mode, light will change with rhythm of music.

Note: Music rhythm mode requires phone keep on this page




- In the page of creating smart, you can set command to be executed under the specified conditions (such as: turn on or turn off light, color, brightness, mode, etc.)



- Click More on the right bottom, you can choose more settings, including Plan, Schedule, Biorhythm and Power-on behavior.

Detailed setting, please read the below links:

<https://developer.tuya.com/en/docs/iot/product-panel-configuration?id=K9s9rhj4i7z8b#title-11-生物节律>



 Attention

- Please check whether the input voltage of the constant voltage power supply is in accordance with the controller, and please check the connection of both the cathode and anode.
- The working Voltage is DC12-24V,the controller will be broken if the voltage is higher than 24V.
- Non-professional user cannot dismantle the controller directly, otherwise, it may cause fire and electric shock.
- The working temperature is -20-60°C ; Do not use the device to direct sunlight, moist and other high temperature area.
- Please do not use controller around the mental area and high magnetic field, otherwise,it will badly affect the control distance.
- When the device load to 15A,wire diameter must be over 1.5mm²



Made in China

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.