



INSTRUCTIONS AND PRECAUTIONS:

(Note: this model of mouse charging must be turned to the on position for normal charging)

1. The mouse can be fully charged in two to three hours. The charging supports a USB interface, mobile phone charging head, and power bank.
2. The switch at the bottom of the mouse indicates that off is to turn off the mouse. on is to turn off the colorful backlight. to turn on the mouse and 0 is to turn on the colorful backlight Turn on the mouse.
3. When the mouse cursor moves slowly, or when the mouse light is dim or stuck. please check whether the battery is in time There is a shortage of electricity, it is recommended to charge in time.
4. when the mouse fails to connect, please check whether the power switch at the bottom of the mouse turned on or move the nano receiver to other devices' USB interface.
5. If you do not use the mouse for along time, it is recommended to turn off the mouse power switch to save the mouse battery power Loss of battery.

INSTRUCTIONS
RECHARGEABLE WIRELESS MOUSE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment



Receiver card slot

5 LIGHT MODES



Matte mode



Colorful



RGB



Colorful loop



Colorful breath

PRODUCT FEATURES:

- 1.Ergonomic shape, optimized with honeycomb shell
- 2.RGB colorful wireless charging mouse
- 3.One key switching adjustment of three gear DPI
- 4.2.4GHz wireless solution, energy-saving, and power-saving
- 5.Mouse built-in 800 Ma large capacity battery, can be recycled charging use. more economic and environmental protection!

INSTALLATION INSTRUCTIONS:

Step 1: The nano receiver at the bottom of the mouse (rectangular slot beside the switch at the bottom of the mouse) is pulled out and installed with the USB interface of the computer.

Step 2: then turn on the switch at the bottom of the mouse to pair with the computer (the normal pairing time takes 10 to 30 seconds). the first time is to install.

If it needs to be matched, it can be used after a successful pairing.
Step 3: move the mouse or press the left and right keys to activate normal use.