


woice

LED BLUETOOTH HEADPHONES W-01



User Manual

WEEE registration number: 79267165



- a. Pause/Start: Press to Play/Pause Music
- b. V+/Prev: Short press for Previous Song
Long press for VOL+
- c. -/Next: Short press for Next Song
Long press for VOL-
- d. MODE: Mode Switch
- e. Micro SD(TF): Up to 16GB
- f. USB Charging: for Recharging
- g. LED: Indicate the Status of the Headphone
- h. ON/OFF: Turn on/off the Headphone
- i. Mic: Hands Free Call Microphone
- j. AUX: Audio Input Port
- k. Ears LED Light: Short press to turn on/off the LED Light

Getting Started

When using the headphone for the first time, please fully charge the headphone using the cable included.

Bluetooth Mode

1. Turn on the headphone by switching [ON/OFF] button
2. Open the Bluetooth function on your smartphone or other Bluetooth supported devices, search for the device named "WOICE W01" and connect it.

Hands Free Calling

- Press the [Pause/Start] button to answer/hang up phone call under Bluetooth mode.
- Long press the [Pause/Start] for 2 seconds to reject the phone call.
- Double Press the [Pause/Start] to dial back the last call.

Micro SD/TF Mode

1. Turn on the headphone by switching [ON/OFF] button
2. Insert Micro-SD/TF card, the headphone will switch to Micro SD/TF mode automatically.

LINE IN Mode

1. Turn on the headphone by switching [ON/OFF] button
2. Insert one end of the Mic-audio line into the AUX interface, the other end into the output interface of the player.

Sharing Function

You could use the audio cable for sharing to connect the headphones and other player devices, then listen to music on two different devices at the same time. The max sharing quantity is 2 or 3 headphones, if connect too many headphones in the same time, it would affect the voice quality.

Indicator Lights

	Indicator	Status
While Charging	RED	Charging
	NO Light	Fully Charged
Bluetooth Mode	Quick Flash Blue and Red	Bluetooth Not Matched
	Slow Flash Red	Bluetooth Matched
AUX Mode	Blue	AUX Mode Playing

PRECAUTIONS

Like Warm and Prompt (1)

1. When the headset is not in use for more than three months, please use it after full charged.

Like Warm and Prompt (2)

2. When not in use for a long time, it is recommended to charge to headset every three months to protect the battery life more effectively.

Precautions

- Please Don't place the headphone in high temperature, including strong sun exposure.
- Please Don't place the headphone near a fire or other hot environment.
- Please Don't place the headphone in wet or submerged in liquid environment, keep it dry.
- Please use the specified charge cable offered by our company.
- Please Don't disassemble, repair or reform it.
- Please note that excessive drop, impact, abrasion or other acts of affecting headphone function, if there is any damage, such as depression, puncture, tearing, deformation or corrosion etc., please stop using the device immediately, and contact the seller or contact us by the service information on the warranty card.
- Please stop using the headphone immediately if the headphone produces abnormal smell, higher than normal temperature, and abnormal changes in color or shape, and contact the seller or contact us by the service information on the user manual.

Features

1. Volume is Limited to Kid Safe Level of 85db. This Volume Level is Recommended by the World Health Organization as the Max Volume for Children.
2. Support TF/Micro-SD card, plug and play.
3. Rechargeable high capacity BL-5B battery, long enough to use.
4. Foldable and adjustable head bow, make sure anymore with different headform can wear it comfortably, also very convenient to bring it.
5. Compatible with almost all Bluetooth supported devices, such as Smartphone, iPads, Tablets, PC, TV etc.
6. Line In function is compatible with smartphone, computer, MP3, MP4, mp5 and other audio input supported devices.
7. Sharing function support you enjoy the music with your friends.

Features

1. Bluetooth version: 5.0
2. Bluetooth range: 10 meters
3. Duration: more than 6 hours
4. Battery capacity: 500mAh
5. Input: DC 5V
6. Working voltage: 3.7V
7. Standby time: more than 6 hours
8. Impedance: 32Ω±15%
9. Sensitivity: 85±3db at 1KHZ
10. Frequency band: 20 HZ - 20K HZ

What's in the box

- 1 * Bluetooth Headphone
- 1 * USB to Micro-USB Charging Cable
- 1 * Audio Cable
- 1 * User Manual

After-sale Service

1. All of our Woice headphones has 6-month warranty
2. If you have any question or need, please feel free to contact us.

How to contact us

Email: sales@woice.com 163.com

Enjoy shopping and have a nice day!

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.