


210 mm

65 mm

User Manual

Bluetooth remote control




MODEL: D18

Power on/Pairing

Turn on the remote controller:

Press and hold the power button for 1 second until the red and blue lights flash alternately.



Pairing the Bluetooth:

Enable Bluetooth and connect to the D18.

Note:


- If D18 not found or connection fails, turn Bluetooth off then on to reconnect.
- Android devices work once Bluetooth-connected; iPhone/iPad need 4 extra steps on Page 2.
- Power on again to auto-reconnect to the last used device.




- 1 -

For iPhones and iPads, in addition to Bluetooth connection, you must also enable the "Zoom" feature in Settings. Please follow the 4 steps below to complete the setup and start using the device.


Step 1




Step 2



Step 3



Step 4



- After enabling the zoom function, the screen will zoom in.
- Double-tap the screen with three fingers to restore.

- 2 -

Function of the Short Video Button


Long press for 1 second: Power on

Long press for 5 second: Power off

Long press for 1 second: Screen off (when connected)

Click: Pause/Play

Double click: To give a like



Click: Previous video

Click: Next video

Click: Swipe the screen left

Press and hold: Volume -

Click: Swipe the screen right

Press and hold: Volume +


Function of Video/Photo Button

Click:

Select the photo menu on the left

Click:

Select the photo menu on the right



Click: Focus

Click: Switch front/rear cameras of phone's built-in original camera

Click or long press:

Decrease camera focus

Double click:

Infinite zoom automatically decreases; click again to stop decreasing

Click: Photo/Video

Long press: Continuous shooting

Click or long press:

Increase camera focus

Double click:


Infinite zoom automatically increases; single click again to stop the increase

Click: Switch front/rear lenses of third-party cameras (TikTok Camera)

Charging

Low Power Warning:

The red light flashes once every 5 seconds to indicate low battery.



Charging:

Steady red light

Fully charged:

red light off

Power off

Manual power off:

- Press and hold the power button for 5 seconds; the red light will stay on for 2 seconds and then turn off.
- The device cannot be power off if it is being charged while the remote control is in use.

Auto power off or Sleep Mode:

- Auto-power off if no device connection within 5 mins.
- Auto-power off if no operation for 1 hour after device connection.
- Enters standby sleep if no operation after phone connection; wake via brief press of any button.

Specifications

Bluetooth Version:

Ver.5.3

Transmission Power:

ClassII(-6dBm~+4dBm)

Frequency (Hz):

2.40GHz~2.48GHz

Bluetooth Name:

D18

Wireless Range:

10 meters

Battery Capacity:

180mAh

Charging Time:

About 1.5 hours

Charging Interface:

Type-C

- 4 -

本说明书尺寸适合：72×113mm盒子

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.