


Instructions

- ①. Pause button (long press the button switch mode)
- ②. Hand-free Call
- ③. In the state of music playing, a short press is to play previous one. Continuous press is to volume down.
- ④. In the state of music playing, a short press is to play next one. Continuous press is to volume up.
- ⑤. Light selection key
- ⑥. Power switch (third gear rotation)
- ⑦. TF card slot
- ⑧. USB port
- ⑨. Indicator



User Instructions

1、Start

Slide the power switch to the right, the blue indicator next to the switch will light up (the indicator light is inside the shield, when it is on, the blue light can be seen out of the shield.)

2、Bluetooth connection

Turn on the power switch, the voice prompts "Enter the Bluetooth". Turn on the mobile phone bluetooth search (my music box) and paired. (If prompted to input a password, please enter "123456" or "000000") and then start to play the music.

[Tips: If the Android phones bluetooth connected, the music is still playback on the phone, please open the bluetooth setting and find a sign behind the device name, then choose media. If Apple mobile phones bluetooth connected, the music is still playback on the phone, please slide the menu on the desktop, click the bluetooth device)]

3、Charging

Use the USB / DC5V interface power supply to charge. (The charger indicator light will be red while charging, then the battery is fully charged it will turn off.)

Charge the speaker with the provided USB cable which is compatible with any computer or cell phone 5V output charger. It can be powered by laptop/computer, power bank, phone charger, etc.

Tips: Please make sure the speaker as fully charged when use it first time. When the light becomes dim, please charge it instead of using so as to protect the battery, please charge it at least once every month to prolong the battery life. The light source of this lamp is irreplaceable.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment