

figIV Phone Overview	Table of Contents Fig Phone Key Functions Overview.....1 Recent Activity Hub.....2 Recent Calls.....3 Accessing Contacts from the Home Screen.....4 Call Waiting.....5 Conference Calling.....5 Caller ID.....6 Speed Dials.....6 Long Press Quick Key Shortcuts.....7 Gallery.....7 Fig Messenger (Talk and Text version only).....8 Starting a New Conversation.....9 Quick Key Shortcuts in Messenger.....10 Schedule Message.....10 Whitelist Settings.....11 Self Signing.....12 Translate Settings.....12 Advanced Settings.....13 Texting Tips & Commands.....13 Conversation Options.....14	Typing on Your Fig Phone.....14 Using the Contacts App.....15 Other Built-in Apps.....16 Notes.....17 Sound Recorder.....17 Calculator.....17 Clock.....17 Fig & Waze.....18 Visit Us: Figphone.com.....20	Fig Phone Key Functions Overview 1. Home Screen – Displays your messages, status icons, and alerts you to any missed calls or unread text messages. 2. Center OK Key – Opens the Recent Activity Hub, where you can view your latest calls, messages, and more. 3. Down Navigation Key – Press once to open the Tool Bar for quick access to key apps and functions. 4. Down Navigation Key (from Home) – Also opens the Notifications panel to view alerts and updates. 5. Speakerphone Key – Toggles speakerphone mode on or off during a call. (Available only while on a call.) 6. Send Key – Use to make or answer calls. From standby mode, press to open your Call History (All, Missed, Dialed, Received). 7. Back Key – In text entry, press to delete a character; press and hold to delete entire words. Also used to go back one menu level at a time. 8. OK / Navigation Keys – Use the Navigation Keys to scroll through menus or highlight items, and press OK to select. 9. End/Power Key – Press to turn the phone on/off or to end a call. Also exits menus and returns to the Home Screen. 10. Vibrate Mode Key – From the Home Screen, press and hold for 3 seconds to quickly enable Vibrate Mode. 11. Outside Subscreen Controls – To switch between Vibrate, Ring, Silent, or to adjust the ring volume: - Wake the subscreen - Press and hold the Sleep Button for 2 seconds - Use the Volume Up/Down keys to make your selection	Recent Activity Hub (Access by pressing the OK key from the Home Screen) The Recent Activity Hub displays all your personal notifications—including text messages and phone calls—in one convenient place. > While Navigating the Activity Hub: Text Message Notifications: 1. Press the OK key to open the full conversation in the Text Message app. 2. Press the Text Message key to open a Quick Reply window to that contact. 3. While composing a message, press the Text Message key again to send. Recent Call Notifications: 1. Press the Call key to call that contact directly. 2. Press the Menu key (left soft key) to open more options: - Add to Contacts – Save the number to your contact list - Show Preview – Toggle preview of message or call - Quick Reply – Reply directly from the hub	4. Call – Call the selected contact 5. Multi-Select – Select multiple notifications to delete	Recent Calls The Recent Calls App keeps a running list of all the calls you have made, received, or missed. > How to Access: From the Home Screen, press the Send key to open your Call Log. > Navigation: Use the Left/Right Navigation keys to switch between call types: All Calls – Includes all outgoing, incoming, and missed calls Missed Calls – Calls you did not answer Dialed Calls – Outgoing calls you placed Received Calls – Calls you answered or rejected	Accessing Contacts from the Home Screen Your Fig Phone makes it easy to quickly find and interact with contacts using T9 predictive typing (Text on 9 Keys). T9 Search for Contacts From the Home Screen, start typing the contact's name using the numeric keypad. For example, to search for "John": Press 5 (for JKL) Press 6 (for MNO) Press 4 (for GHI) Press 6 (for MNO) As you type, matching contacts will appear automatically using T9 real-time prediction. > Once a contact appears: Use the Navigation (D-pad) keys to highlight the contact Press the OK key to dial Press the Text Message key to send a message Press the Left Soft Key to open the contact menu with options such as: - View Contact - Send Text Message	Call Waiting When you're already on a call and another call comes in: You'll hear a single beep indicating the incoming call. Press the Send key to answer the new call. The first call will be placed on hold. Press the Send key again to switch between calls or merge them (if supported).	Conference Calling To start a conference call: While on a call, press the Left Soft Key to access Options. Choose Add Call. You'll be taken to the dialer where you can: - Manually enter a number - Use T9 typing to search your contacts (just like from the Home Screen) Press the Send key to dial. The original caller is placed on hold automatically.	Speed Dials Speed Dials let you quickly access contacts by assigning them to 1- or 2-digit shortcuts. When you dial that number from the Home Screen, the assigned contact will appear as the first result. > Example: If John is assigned to Speed Dial 1, simply press 1 from the Home Screen, and John will appear at the top of the contact results.	Caller ID When receiving a call, your phone displays: The caller's name and number If saved, their contact photo This helps you instantly recognize who's calling.	Long Press Quick Key Shortcuts Long pressing a key from the Home Screen can quickly launch an app or call a contact. You can assign these shortcuts to: The Navigation Keys (Up, Down, Left, Right) Keys 2-9 > How to Assign a Quick Key Shortcut: 1. From the Home Screen, press the Left Menu Key 2. Go to Settings > Quick Key Settings 3. Choose a key to assign (e.g., Up, Down, or 2-9) 4. Select an App or a Contact by choosing "Speed Dial" and selecting from your contact list	Fig Messenger (Talk & text version only) Accessing Fig Messenger: You can open Fig Messenger by: Pressing the Text Message Key on the keypad Navigating to Menu > Fig Messenger Main Menu Options Press the Left Soft Key while in Fig Messenger to access the options menu. From here, you can: 1. Start a New Conversation 2. Search your messages 3. Show Pinned Conversations 4. Show Archived Messages			
	5. Show Blocked Messages 6. Go to Settings 7. Pin a Conversation 8. Archive a Message 9. Delete a Conversation 10. Mark as Unread 11. Mark All as Read 12. Mute a Conversation 13. Block a Contact from messaging you 14. Schedule a Message to send later	Quick Key Shortcuts in Messenger From the main Fig Messenger screen: Double tap the Right Navigation Key to mark a message as read If you've scrolled down the message list, double tap the Left Navigation Key to quickly jump back to the top	Editing or Cancelling a Scheduled Message: Open the Scheduled Messages screen. Tap on the message you want to change. Choose: - Update Message – to modify the time or message content - Delete Message – to cancel it entirely	Whitelist Settings (Recommended for Kids and Controlled Messaging) What it does: The Whitelist setting gives you full control over who can send you text messages. When activated, it blocks all messages except from specific contacts you approve. This is ideal for: Children's phones – to limit communication to family and trusted individuals Focus and productivity – to avoid distractions Privacy and security – to block unknown or spam messages You can also choose advanced options, like allowing only text messages (and blocking picture messages, for example). How to Set It Up:	Advanced Settings In Advanced Settings, you can fine-tune your messaging preferences, including: Group messaging options Auto-retrieve for MMS Auto-retrieve while roaming SMS delivery reports And other technical preferences for messaging behavior	Conversation Options Selecting Conversation Options from the menu gives access to more advanced tools: People & Options – View all shared photos and media, adjust conversation-specific settings like notifications, vibration, and blocking Call the Contact – Initiates a voice call Pin the Conversation – Keep it at the top of your message list Archive Conversation – Move the chat out of your main view Delete Conversation – Permanently remove the chat Translate Setting – Adjust the translation language for this specific conversation	2. Touchscreen Typing (Touchscreen Models Only) Simply tap on the text input box with your finger. This will bring up the on-screen keyboard. Type as you would on a regular smartphone.	Quick Actions from a Contact Navigate to any contact using the arrow keys. Once highlighted, you can: Press the Send (Call) button to quickly place a call Press the Text Message key to start a message to that contact Press the OK or Edit key to view or edit contact details	Sound Recorder The Sound Recorder App allows you to record audio directly from your phone. Ideal for saving voice memos, meetings, lectures, or personal reminders You can play back, rename, or delete recordings Recordings are saved in your phone's internal storage and can be shared via Bluetooth or text	Setting Up Waze Navigation Prerequisites: An active data plan (SIM card installed) or Wi-Fi connection. GPS Location Services enabled. 1. Enable Location Services (GPS) Before opening Waze, you must ensure the phone allows apps to see your location. Go to Settings. Scroll down and select Location (sometimes found under Security & Location or Privacy). Toggle the switch to On. Note: If prompted to "Improve Location Accuracy," select Yes for the best navigation experience. 2. Locate or Install Waze If Waze is pre-installed: Look for the Navigation folder or the Tools menu on your home screen. Select the Waze icon. If Waze is missing: - Open the App Store (or Store / Applications menu). - Navigate to the Travel & Navigation category. - Select Waze and press Install or Update. - Once finished, the app will appear in your main menu. 3. Launching Waze for the First Time Open the Waze app. Permissions: You will see a prompt asking to allow Waze to access your location. You must select "While using the app" or "Always." If you select "Deny," the GPS will not work. Terms of Service: Scroll down and accept the license agreement. 4. Basic Configuration Once inside the app, we recommend adjusting these settings to save data and battery: Press the Search icon. Select the Gear icon (Settings). Voice & Sound: Ensure sound is set to "On" if you want turn-by-turn directions. Battery Saver: Enable this if you are on a long trip without a car charger.	Troubleshooting "No GPS" Error: Go back to phone Settings > Location and toggle it Off and On again. Ensure you are outside or in a vehicle, as GPS signals are weak indoors. App Freezes on Launch: If the app gets stuck on the loading screen, restart your phone to clear the memory and try again.	How to Use Android Auto with Waze Connect your phone to your vehicle using a USB cable. Your car's display will launch Android Auto. Tap the Waze icon on the car screen to start navigation. Use voice or car screen input to search destinations, check traffic, or follow live directions.				
	5/20	6/20	7/20	8/20	9/20	10/20	11/20	12/20	13/20	14/20	15/20	16/20	17/20	18/20	19/20	20/20

70.00 mm

120.00 mm

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information

This device meets the government's requirements for FCC exposure limits set forth for an uncontrolled environment. This device was tested for typical body-worn operations with the back of the mobile phone kept 10 mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 10 mm separation distance between the user's body and the back of the mobile phone. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.