




Thank you for purchasing our S4. Please read [these instructions](#) carefully before use.

Specifications

- Pairing name:S4
- Bluetooth version:4.2
- Built-in Flash: 16G
- Audio formats: MP3、WMA、WAV、APE、FLAC
- Size:59(L)×32(W)×54(H)mm （Fuselage Size）
- Weight:24.5g
- Battery capacity: 3.7V 230mAh
- Input: DC 5V 500mAh
- Charging time: About 2.5 hour
- Support Profile : HSP、HFP、A2DP、AVRCP
- Receiving sensitivity:~38dBm
- Transmission distance:2.40GHz~2.48GHz
- Distance: Up to 10m (without obstacle)

Product Appearance



Part Name

- 1、ON/OFF Button ; Playing/Pause ; Call answering, ending and callback ()
- 2、Mode switching / Voice assistant

Charging Red LED light on
Fully charged Blue LED light on

Button Introduction

Turn ON/OFF

Power on: Long press 3 seconds, blue LED flash with prompt “Power on”.
Power off: Long press 3 seconds, blue LED light with prompt “ Power off ”.

Reset

If the headset crashes, press the power on button for 10 seconds to reset the system

Bluetooth mode and MP3 mode switch

- Short press the **M** button to switch the mode.

- 3、Indicator light /microphone
- 4、Data and charging interface
- 5、Volume +（Increase Volume）
Next Track（ Long press 2 seconds）
- 6、Volume –（Decrease Volume）
Previous Track（ Long press 2 seconds）

How to connect to Bluetooth?

Press and hold the power button for two seconds to power on. After power on, you will hear the following sentence: "Power on, Bluetooth, waiting for a connection." Turn on the Bluetooth function of the mobile phone to search and connect the device with the name: S4 and the mobile phone will connect to the device. (After you have connected the phone, turn on the headset (built-in mp3 player) next time. If you turn on Bluetooth, the phone will automatically connect

to the headset with the built-in player)

How to switch between memory mode and Bluetooth mode?

There is an "M" button next to the power button of the headset (built-in MP3 player.)

1. Press the "M" button, the headset will enter the "Memory mode", The device has a built-in 16GB memory card. When in-memory mode, you can listen to the songs in the memory TF card

2. When in "Memory mode", Press the "M" button again, and the headset will return to "Bluetooth mode". In this mode, you can play songs on your phone or online songs in real-time.

How to switch songs?

Next to the charging port is the volume button. Long press the volume buttons "+" and "-" to switch to the next or previous song.

- Previous song: Long press "-" 2 seconds.

Next song: Long press "+" 2 seconds

Activate the voice assistant

(Operate require the user's phone support this function) After the headset and the phone is connected, Short press the **M** button twice in a row to activate the voice assistant function of the mobile phone

Notes

No phone is connected to the device, will automatically power off after 5 minutes. The iPhone will display the earphone's battery in real-time.

You can choose to wear a large, medium, and small ear caps according to the size of your ear canal.

If you have any [problems](#) with this product, please feel free to contact us.

How to copy songs to the device?

1. If you want to copy music to the device, before connecting the device to your computer, please make sure that the device is turned off, This is very important!!

To prevent errors when transferring music to your device, please follow the steps below:

- a). Before copying music to the headset, turn off the device first.
- b). After turning off the device, first connect the charging port of the headset with a data cable.
- c). Finally, connect the USB port of the computer.

2. Use our included power cord/charging cable to connect to the USB port of the

1 YEAR WARRANTY

Your S4 Sport Bluetooth Earphone with MP3 instructions is warrantied by idoooz against defects in materials, under normal use, for one year beginning from the original date of purchase.



Email: support@idoooz.com
Web: www.idoooz.com



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.