

Remote Control Instructions

Versions: V1.0

一、product presentation

1、Power Supply: Two 1.5V DC batteries

2、support BLE

二、 Remote Control Instructions

(1) Pairing Method

Long-press the WL button on the remote control for 2–3 seconds to pair it. The indicator light will flash rapidly to confirm pairing; after successful pairing, it will first flash slowly and then stop blinking. Following pairing, all buttons except TRE and BASS will flash slowly three times; pressing TRE or BASS will trigger one slow flash; pressing volume up/down buttons will each cause one slow flash. After exiting adjustment mode, the light will flash slowly three times.

(2) functional description



Startup & Shutdown	Short press to turn the device on or off
Wireless Mode	Short press to enter wireless playback mode; long press to enter pairing mode
Volume Down	Short press to reduce the music volume by one level. If the current setting is high or low, adjust this function to reduce it by one level.
Increase Volume	Short press the volume up button to increase the volume by one level. If the current setting is high or low, adjust this function to increase the volume by one level or decrease it by one level.
Play \Pause	In wireless mode, short press to play or pause; ARC mode is disabled
Previous Song	Short press Music to play the previous track. ARC, AUX, and SPDIF fiber modes are disabled
Next Song	Short press Music to play the next track. ARC, AUX, and SPDIF fiber modes are disabled
high pitch	Shortly press the indicator light to flash slowly once to enter high-frequency adjustment mode. Press the volume up/down button to adjust the high frequency. Shortly press any other key except the high/low buttons or hold for 3 seconds to automatically exit high-frequency adjustment mode.
Bass	Shortly press the indicator light to flash slowly once to enter bass adjustment mode. Use volume up/down buttons to adjust bass intensity. Shortly press any other button except high/low or hold for 3 seconds to automatically exit bass adjustment mode.
Mode Switch	Short press to switch playback modes in the order: USB → AUX → ARC → SPDIF
Music Sound Effects	Short press to access music effects
Movie Sound Effects	Short press to access movie sound effects

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment

generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.