


CH9965

Ride on car

Installation and operation manual

- Executive standard: F963



Please follow real product, Photo for reference only
This toy contains batteries that are non-replaceable.



WARNING:
Assembly By Adult Only

The picture in this manual is to show the product operation and structure, please follow the real product only if any difference between picture and product happens. There must be chance not to inform you on time to improve the product result from appearance or structure, please be understood.



Please read this manual carefully before play the product, it tells you the right way for operation and install to avoid any possible hurt to your kids. Please keep this manual and put it in a place where is easy to get.

Specification _____


Item	Specification
Batteries	12V
Motor	12V
Age	3-8years old
Max Weight	20KG
Dimension	685×315×380 mm
Speed	7KM/H
Play Time	1-2 hours / recharger time 8-12hours
Charger	Out Put DC12V

WAARNING:

The following safety hazards may cause serious injury or death

- 1.Never leave your children unattended
- 2.Be sure to sit on the seat when using this car
- 3.Keep your hands, hair and clothes away from moving parts
- 4.Be sure to wear shoes when operating this car
- 5.Up to one child is allowed to ride in the vehicle
- 6.Only on flat roads
- 7.Do not approach the swimming pool or other water bodies, falling places or steep slopes
- 8.Do not drive into loose soil.Mud, sand, gravel or wet pavement
- 9.Do not drive on the road or near the car
- 10.PISK OF FIRE.Do not bypass.Replace only with.




PARTS



Serial No.	Component Name	Quantity	Serial No.	Component Name	Quantity	Serial No.	Component Name	Quantity
1	Body	1	2	seat	1	3	Steering wheel	1
4	Front wheel assembly	1	5	Front wheel square tube	1			

1


Insert the front wheel fixing iron into the front wheel assembly and secure it with screws



Insert the front wheel assembly into the body (Small boat facing forward)



2

Insert the steering wheel into the body and secure it with screws
(Steering wheel arrow pointing forward)





3

Connect the power cord and lock the seat



4 Feature Introduction



When in use, the arrow on the steering wheel faces forward

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.



The charging hole is located in the front of the seat. Insert the Q head of the charger into the charging hole. Insert the other end into the socket

- Charge the battery **15 to 18 hours** before initial use.
- On average, you will need to charge the battery between 8 and 12 hours. Do not charge the battery for more than 20 hours. Failure to charge the battery as directed could cause permanent damage to the battery and void the warranty.
- Damage to the battery may occur if it is allowed to drain completely. Do not allow the battery to drain completely.
- Check the battery and charger (supply cord, connector) for wear and damage before charging. Do not charge the battery if damage has occurred.
- Only an adult who has read and understood the safety warnings should handle, charge and recharge the battery.



WARNING: _____

For your baby to drive safely, you must pay attention to the following warnings :

- The assembly and adjustment of the product must be carried out by adults. Please keep children away from moving parts
- Small parts inside
- Children must use the product under the guidance of adults, and the carer must not leave during use! Do not get close to the fire
- Do not allow children to stand or play on the footboard (or electric vehicle)
- The battery must be charged by adults before using this product
- In order to avoid harm to children, please keep plastic bags and other packaging materials away from children! Room breathing danger!
- Do not use any accessories not provided by the manufacturer
- All batteries shall be inserted with correct polarity
- Do not use the charger as a toy
- The maximum load-carrying capacity of the vehicle is 20kg, and overload is not allowed
- Applicable age range: 3-8years old
- Power terminals shall not be short circuited
- Toys cannot be connected to more than the recommended number of power supplies
- When the vehicle is charging, the toy (vehicle) cannot be operated

PRECAUTIONS FOR USE

- When using the electric vehicle for the first time, the battery must be charged for 18 hours, otherwise the battery will be permanently damaged and cannot be repaired
- Before use, please check whether all parts are installed in place and connected firmly
- Do not use in dangerous areas such as streets, roads, slopes, ditches, etc
- Do not use on smooth ground such as marble tile
- Do not switch the forward / reverse switch while the electric vehicle is running.
Be careful not to let the child stand on the seat
- It is not allowed to change the circuit and additional live devices of this vehicle
- Electric vehicles shall not be allowed to rain or be used in water. Do not pour water or other liquid on the vehicle or immerse it in water in other ways. Keep away from the fire source to avoid damage to the circuit
- When encountering obstacles, the electric vehicle stops running. Please leave the obstacles before riding.
- Do not use it indoors to avoid damaging furniture or even wrestling children
- This product is limited to one person. It cannot be overloaded. The maximum load is 20kg
- When not in use, please turn off the power switch. When not in use for a long time, please unplug the battery connector.
- Non rechargeable battery is not rechargeable, take out the exhausted battery from the toy
- Do not mix old and new batteries or different types of batteries
- The rechargeable battery should be removed from the toy before charging.

MAINTENANCE

- To protect your baby from accidental injury, please check and maintain the car regularly
- Before loading, please check whether the packing components are complete. If there is any shortage, please contact our company immediately
- Check regularly for damage to loose parts of screws
- When installing or using all parts, please check whether they are in good condition
- Please clean the product regularly, and be careful not to damage the original electric appliance
- When disassembling and assembling, please carefully follow the operation manual to avoid unnecessary damage.
- Please check the product and charger regularly to see if the wire, plug and other parts are damaged. If there is any damage, stop using until it is repaired.