

# Home Lights

# User Manual

## Customer Service

Warranty: 24-Month Limited Warranty

Support Lifetime Technical Support



Email: [yllighting1@outlook.com](mailto:yllighting1@outlook.com)

If you have any questions when using the product, please contact us by email, we will provide you with any support within 24 hours

(Due to policy restrictions we cannot contact you directly from comments)



# Introduction

Thank you for purchasing our product. Please read the following instructions carefully before assembly. If you have any questions, please contact us via email at: [yyllighting1@outlook.com](mailto:yyllighting1@outlook.com)

If you are a customer who placed an order on Amazon, you can also contact us by checking your order page

## Cautions

1. When opening the package, use a sharp tool like a utility knife carefully to avoid damaging the components inside.
2. Carefully remove all packaging materials and keep them for future use.
3. Keep all hardware parts and packaging out of the reach of small children.
4. Check the packing list to ensure it's complete. If there are missing or damaged accessories, contact us via email: [yyllighting1@outlook.com](mailto:yyllighting1@outlook.com)
5. Choose a clean, level, spacious assembly area to avoid hard surfaces that may damage the product.
6. Take care when lifting the components. Assemble the product close to where you intend to place it.
7. Do not overtighten screws, as it may damage the threads.
8. After finishing assembly, place the product on a flat surface and ensure it is stable before use.
9. Do not allow children to play with the product
10. If you have any questions, feel free to contact us via email: [yyllighting1@outlook.com](mailto:yyllighting1@outlook.com).


# Assembly Instructions

Refer to the diagrams included in the packaging for detailed step-by-step assembly instructions.

**The textbook switch only has ON/OFF function**



The light pole is screwed onto the bottom disc mount through the screw hole at the bottom



Connect the power plug of the light pole to the plug of the power adapter and then plug the adapter into the socket

## Remote Control Instructions



### ● Remote Control Pairing



#### Pair Button

Press and hold the pairing button until the light starts flashing. After the light flashes three times, pairing is completed.

## Cleaning & Maintenance

1. Avoid prolonged exposure to heat sources to prevent glazing, melting, scorching, or color fading.
2. Vacuum or lightly brush to remove dirt regularly.
3. Check screws periodically (every 90 days) to ensure they remain fully tightened.

## Warranty

We offer a 24-month warranty, excluding damage caused by incorrect installation or user error. For any issues, please contact us at us : [yyllighting1@outlook.com](mailto:yyllighting1@outlook.com)

## Specifications

|             |                                   |
|-------------|-----------------------------------|
| Model       | Corner Floor Lamp                 |
| Power Input | 100`240V, 50/60Hz 1AMAX           |
| Brightness  | adjustable from 10%-100%          |
| Material    | All aluminum alloy + PC Lampshade |
| Color       | 3000K~6000K Adjustable            |
| Limit       | Indoor Use Only                   |

### FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.