

FRONT

155mm

Motif Wireless Speaker
Instruction manual

LZH-05B

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP THIS
MANUAL


In the Box

- LZH-05B Motif Wireless Speaker (x1)
- Power Cable (x1)
- User Manual (x1)

Safety Precautions

- This product is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual.
- Never use the device for anything other than its intended purpose.
- ONLY use the supplied power cable.
- Do not open this product or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a dry, cool location, away from sources of water or heat.
- Do not expose device or power cable to extreme temperatures (heat or cold), open flames, humid or wet conditions.
- Do not submerge in water. Do not use in a location where the device or power cable could fall into liquid.
- Unplug the charging cable when not in use. Do not pull the charging cable to disconnect, or use the cable as a handle.
- Do not use if device or power cable is damaged. If device or power cable is damaged, it MUST be serviced or replaced by the manufacturer or its service agent before using again.
- Low battery may cause dysfunction.
- Do not over charge battery.
- This device contains a built-in battery and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

Product



- ① Power Button
- ② Multi-function Button
- ③ Phone Button
- ④ Vol+/Previous Track
- ⑤ Vol-/Next Track
- ⑥ LED indicator
- ⑦ Micro USB Charging Port

Instructions

Be sure to fully charge the speaker before using for the first time.

Charge the Speaker

- Plug the small connector of the included charging cable into the micro-USB charging port on the speaker.
- Plug the large connector into an USB power source, such as the USB port on a computer or into a compatible 5V USB adapter (not included) and plug into a wall socket.
- The LED indicator will glow RED when charging and turn off when fully charged.

Pair & Connect with a New Device

- Press and hold the Power button to turn speaker ON. LED indicator will flash BLUE indicating that it's in pairing mode.
- Open the Bluetooth menu on your smartphone and search for new devices.
- When you see "Motif Speaker" listed, tap it to connect. LED indicator will stop flashing when paired successfully.
- Previously connected speaker will connect automatically after they are powered on.

Play & Calls

- Press the Multi-function button to play/pause your audio.
- Press the ◀◀ button to skip to previous track; Press and hold the ◀◀ button to increase volume.
- Press the ▶▶ button to skip to next track; Press and hold the ▶▶ button to decrease volume.
- Press the Phone button once to answer an incoming call, and again to end the call.
- Double press the Phone button to redial the last dialed number.
- Press and hold the Phone button to reject an incoming call.

Tech Specifications

Speaker Output	3W
Frequency Response	150Hz~18KHz
S/N Ratio	>80dB
Connection Range	33 feet
Continuous Play Time	2 hours (max volume)
Battery Capacity	400mAh
Charging Time	1.5 hours (from 0-100%)

FCC Information

This device complies with Part 15 of the FCC Rules.

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

BACK

155mm

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure com

Packaging from responsible sources

FSC® C1160125

Made in China