

READ ALL INSTRUCTIONS CAREFULLY BEFORE USE AND KEEP THIS MANUAL.

- WLT-NV22 Nova Adjustable Desk Lamp w/ Wireless Charger (x1)
- USB Type-C Power Cable (x1)
- USB to USB Type-C Adapter (x1)
- Instruction Manual (x1)

- This product is NOT a toy, keep away from children and pets.
- Only use the device according to the instructions in this manual
- Never use the device for anything other than its intended purpose.
- Do not open this device or attempt to repair the unit yourself if it is not working properly. Doing so risks fire, shock or injury.
- When not in use, the device should be stored in a cool, dry location, away from sources of heat or moisture.
- Do not expose device or power cable to extreme temperatures (hot or cold), open flames, humid or wet conditions
- Do not submerge in water. Do not use in a location where the device or power cable could fall into liquid.
- Unplug the power cable when not in use. Do not pull the power cable to disconnect, or use the cable as a handle
- Do not use if power cable or device is damaged, if power or power cable is damaged, it must be replaced by the manufacturer or its service agent before using again.
- Attachments on the back of your device can impede effectiveness of the wireless charger, and lead to overheating. Remove attachments from your device before charging on this wireless charger.
- and warm white light.
- Touch the Touch Bar to turn off the light.

Diagram illustrating the USB Type-C Input and Wireless Charging Surface. The diagram shows a device with a circular base and a handle. The base features a circular area labeled "Wireless Charging Surface" and a circular port labeled "USB Type-C Input". A cable connects the handle to the base, and a small indicator light labeled "LED Indicator" is located near the base. A "Power Button" is located on the handle.

- Plug the provided power cable into the USB Type-C input port on the back of the lamp.
- Plug the other end of the cable into a USB Type-C power source, such as the USB Type-C port on a computer or into a certified USB Type-C adapter (not included), and plug into a wall socket.

(With the included USB to USB Type-C adapter, the product can be connected to a USB power source.)

- The LED Indicator will flash **BLUE** and **RED** alternately for 3 times, then glow **RED** to indicate the device is in standby mode

Using the Lamp

- Touch the Power button on top of the lamp turn on the light
- Touch the Power button to adjust the light color: white light, warm light,

- Place a wireless charging enabled mobile device on the wireless charging surface, the mobile device will begin to charge automatically.
- The LED indicator will turn **BLUE** to indicate that your device is charging properly.
- If your device does not begin to charge, try repositioning your device on the wireless charging surface. You may need to remove the case of your device to charge properly.
- Remove your device from the wireless charging surface when it is fully charged.

Note:

- If the LED indicator is flashing when the wireless charger is in use, either the device is not wireless charging enabled, or there is an object between the device and charging pad interfering with the charging process.
- To achieve a better wireless charging experience, please use 18W, 20W or higher power adapter (not included).

The wireless charging will automatically power OFF when the wireless charging surface is overheated or when a metal object, such as a coin, is placed on the wireless charging surface. The LED indicator will flash **RED** and **BLUE** alternatively to warn of automatic shutoff.

Power of Lamp: 2 Watt
Luminous Flux: 240 Lumen
Power Input: DC 5V/3A 9V/2A 12V/1.5A
Wireless Charging Output: 15W (Max.)
Working Temperature: 32°F - 122°F (0°C - 50°C)

Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

digital device, pursuant to Part 15 of the FCC Rules. Resilientems are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure

