


TELESIN


Zoom Remote Controller for phone

手机变焦遥控器



User Guide / 使用指南

产品图示



① 变焦波轮

② 拍照按键

③ 指示灯

④ 开关机键

⑤ 模式按键

⑥ 电池后盖

操作说明

1. 长按遥控器开关机键2秒，指示灯自动闪烁
2. 打开手机“设置”界面，开启“蓝牙”功能，搜索“TELESIN_RC1”并点击设备名称进行蓝牙配对，显示“设备已连接”后，指示灯常亮3秒，此时手机成功连接遥控器

3. 苹果手机连接蓝牙后仅可使用拍摄键。首次使用其他按键功能，请进行如下操作：

进入设置-->辅助功能-->缩放-->缩放区域(全屏缩放)-->打开缩放。



* 打开“缩放”时，画面会放大，三指轻点两下恢复。其它设置不变。

序号	按键	操作和功能	指示灯状态
④	开关机键	1.长按2秒开关机, 进入配对状态 2.配对成功后, 短按一次进行前后摄像头翻转	配对状态: 绿灯持续闪烁 配对成功: 绿灯亮3秒后熄灭
⑤	模式键	1.长按2秒切换相机模式和短视频模式 2.相机模式下, 短按一次进行对焦	相机模式: 绿色灯亮3秒 短视频模式: 橙色灯亮3秒
②	拍照键	1.相机模式下, 短按一次进行拍照或者录像 2.短视频模式下, 短按1次暂停, 短按2次进行点赞	相机模式: 绿色灯亮1次 短视频模式: 橙色灯亮1次

①	变焦 波轮	1.相机模式下, 右旋 无极变焦放大, 左 旋无极变焦缩小 2.短视频模式下, 右 旋下翻页面, 左旋 上翻页面	/
⑥	电池 后盖	用十字螺丝刀拧开 后盖螺丝, 可取出 CR2025电池进行 更换	低电量时: 红灯 闪烁

规格参数

产品名称	Telesin 手机变焦遥控器
折叠尺寸	44mm*28mm*10mm
整机重量	10g
连接方式	低功耗蓝牙

遥控器
功能

拍照/录像/变焦/短视频浏览

遥控器电
池容量

CR2025 (3.0V)

遥控器控
制距离

10米

包装清单

名称	图示	数量	规格说明
遥控器		1	支持变 焦功能
说明书		1	/
彩盒		1	/

安全提示

- 本产品属于精密仪器，请避免使用时掉落，碰撞或者承受重击
- 请勿将板产品放置在有腐蚀性化学物品的地方，避免产品受到腐蚀，被腐蚀可能引起产品故障
- 请使用软布，干布清洁本产品
- 请勿将本产品放置在温度过高的地方，高温可能导致产品内部电池受损或爆炸
- 请勿自行拆解和维修机器
- 此说明书依据本公司严格测试后制定，设计和规格如有变更，恕不另行通知

警告

1. 本产品内含纽扣电池，为保障安全，使用后请将废旧电池妥善处理，切勿随意丢弃或焚烧。同时，要确保电池远离儿童和宠物，避免意外发生。
2. 本产品内含纽扣电池，危险勿触！纽扣电池若被吞食，可能造成食管灼伤等严重伤害。请妥善保管，防止儿童接触。如不慎吞食，请立即就医。
3. 纽扣电池易被儿童误吞食，为避免潜在危险，请将其

存放在儿童接触不到的位置，防止因误食、塞入鼻腔或耳朵等引发严重后果。


4. 本产品兼容的电池类型为CR2025，标称电压为3.0V。
5. 本产品内含的纽扣电池不可再充电。
6. 请勿强制排放、重新充电、拆卸、加热至60°C以上或焚烧。以防电池过热、起火或爆炸，从而导致人员受伤或化学灼伤。
7. 请严格按照产品说明书的要求正确安装和更换纽扣电池。正负极安装错误可能导致电池短路、发热甚至引发火灾。若在使用过程中发现电池有异常，应立即停止使用。
8. 如长期未使用的设备，请从中取出并立即回收或处理电池。
9. 如果电池盒关闭不牢固，请停止使用产品，应立即取出电池，并使其远离儿童。

免责声明

请仔细阅读本声明，一旦使用本产品，即视为对本声明的全部认可和接受。每次使用前，请仔细检查产品，若出现破损、变形，请勿使用。使用本产品，就意味着您认可并同意，您将对使用本产品的行为和可能产生的后果负全部责任。您承诺仅会出于正当合法的目的使用本产品。您理解并同意，对于直接或间接因使用本产品而造成的滥用、不利影响、损害、伤害、惩罚或者其他法律后果，泰迅数码有限公司（以下简称“Telesin”）将不承担任何责任。用户应遵循包括但不限于本文提及的使用注意事项。在国家法律法规范围内，本承诺解释权、修改权归 Telesin 所有。

泰迅保修期从您收到货物后的当日起计算，享有 6 个月保修服务。

Product Diagram




- | | |
|-------------------|-----------------|
| ① Zoom Wheel | ④ Power Button |
| ② Shutter Button | ⑤ Mode Button |
| ③ Indicator Light | ⑥ Battery Cover |

Instructions

1. Press and hold the remote control's power button for 2 seconds until the indicator light starts blinking automatically
2. Open the "Settings" interface on your phone, enable "Bluetooth", search for "TELESIN_RC1", and click the device name to initiate Bluetooth pairing
3. When "Device Connected" is displayed, the indicator light will stay lit for 3 seconds, indicating successful pairing between the phone and remote control

4. iPhone: Bluetooth enables shutter only. First use of other functions requires enabling Zoom in Settings > Accessibility

Go to Settings-Accessibility-Zoom-ZoomRegion (FullScreen Zoom)-Turn on Zoom



* (Double-tap with 3 fingers to restore).

No.	Button	Function	Indicator Status
④	Power	1.2s long-press: Power on/pairing 2.Single press: Switch front/rear camera	Pairing: Green flashing Connected: Green steady (3s)
⑤	Mode	1.2s long-press: Switch photo/video mode 2.Single press: Focus (photo mode)	Photo: Green (3s) Video: Orange (3s)
②	Shutter	1.Photo mode: Capture/record 2.Video mode: Like content	Photo: Green blink Video: Orange blink

①	Zoom Wheel	1.Photo mode: Rotate R/L for zoom 2.Video mode: Scroll pages	/
⑥	Battery Cover	Replace CR2025 battery (cross screwdriver required)	Low power: Red blinking

Specifications

Product Name	Zoom Remote Controller for phone
Folded Size	44mm*28mm*10mm
Weight	10g
Connection Method	Bluetooth Low Energy (BLE)

Remote Functions	Photo Capture, Video Recording & Zoom Control
Remote Battery	CR2025 (3.0V)
Control Range	10m

Package Contents

Product Name	Diagram	Quantity	Specification
Remote Controller		1	zoom enabled
User Manual		1	/
Color Box		1	/

Safety Tips

- This product is a precision instrument. Please avoid dropping, colliding or heavy impact during use.
- Do not place the product in areas with corrosive chemicals to prevent corrosion, which may cause the product to malfunction.
- Please clean the product with a soft, dry cloth.
- Do not place the product in excessively high temperatures, as this may damage or cause the internal battery to explode.
- Do not disassemble or repair the machine by yourself
- This manual has been prepared based on rigorous testing by our company. Design and specifications are subject to change without prior notice.

Warnings

WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as 2 hours.
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN.**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



1. This product contains a button battery. For safety reasons, please dispose of used batteries properly and do not discard or burn them carelessly. Also, ensure that the batteries are kept away from children and pets to avoid accidents.
2. Button batteries can be easily swallowed by children. To avoid potential dangers, please store them in a location out of reach of children to prevent serious consequences such as accidental ingestion, insertion into the nose or ears.
3. This product contains a button battery. Danger, do not touch! If swallowed, the button cell may cause serious injuries such as esophageal burns. Please store it properly to prevent children from accessing it. In case of accidental ingestion, seek medical attention immediately.
4. This product is compatible with CR1632 battery type.
5. The nominal voltage of the battery used in this product is 3.0V.
6. The button battery included in this product is not rechargeable.
7. Do not force discharge, recharge, disassemble, heat above 60°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
8. Ensure the batteries are installed correctly according to polarity (+ and -).

9. Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
10. If the device has not been used for a long time, please remove the battery and recycle or dispose of it immediately.
11. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

FCC Caution

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection

against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure conditions without restriction.

IC Statement

-English:

This device contains licence-exempt transmitter (s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF exposure statement:

The device was evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

- French:

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

- (1) Cet appareil ne doit pas causer d'interférences.

(2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Tout changement ou modification non expressément approuvé par la partie responsable de la conformité pourrait annuler l'autorité de l'utilisateur à utiliser l'équipement.

Déclaration d'exposition RF:

L'appareil a été évalué pour répondre aux exigences générales en matière d'exposition aux RF. L'appareil peut être utilisé en condition d'exposition portable sans restriction.



Declaration of
Conformity

Disclaimer

Please read this statement carefully. Once you use this product, it is deemed that you fully recognize and accept this statement. Before each use, please carefully check the product. If it is damaged or deformed, do not use it. By using this product, you acknowledge and agree that you will be fully responsible for the actions and possible consequences of using this product. You promise to use this product only for legitimate and legal purposes. You understand and agree that Telesin Digital Co., Ltd. (hereinafter referred to as "Telesin") will not be liable for any abuse, adverse effects, damages, injuries, penalties or other legal consequences directly or indirectly caused by the use of this product. Users should follow the usage precautions mentioned herein and others. Within the scope of national laws and regulations, the right to interpret and modify this commitment belongs to Telesin. The Telesin warranty period starts from the day you receive the goods and enjoys a 6-month warranty service.

www.telesin.com