




SAFETY INSTRUCTIONS

Before use, please read the product instructions carefully and keep them properly for use in case of urgent need. During product projection, it is forbidden to block the air inlet or outlet of the product to avoid damage caused by excessive machine temperature. Products are not allowed to fall or strike from the high to avoid damage to the machine. To avoid eye injury, do not look directly into the machine lens.

If there is any problem with the product, do not disassemble it without permission. Please contact professional after-sale personnel for assistance.



THE ANNOUNCEMENT

Our company has always been in the spirit of excellence, always committed to improve perfect product performance, to provide users with high quality, competitive prices of products. All pictures and function descriptions in this manual are subject to the material object and factory default. Our company reserves the right to improve the product functions and man-machine interface described in this manual without prior notice. Please take the material object as first.

Please be sure to take good care of your machine. We will not be responsible for any loss caused by software, hardware misoperation or maintenance, or any loss caused by disclosure of personal information to a third party. The company will not be responsible for any unexpected losses that may occur during the use of the manual or any third party claims arising from the use of the product.

ITEM LISTING



Host



Remote Control



Product Specification



Power Adapter

Note: Thank you very much for buying our products. Please check whether the product received is consistent with the list. If the products and accessories you receive do not match the list, please contact customer service immediately.

01 HOME PAGE

- 1) The home page contains seven functions: file management, signal source, settings, customer service, Miracast, Airplay, and DUNA. When selected, press "OK" to enter.



Figure 1: Home Page



Figure 2: Signal Source Inlet

- 1) Computers, set-top boxes, game consoles and other equipment are viewed as signal output end, home projector as signal input end. The output end needs to have HDMI interface.
- 2) Connect the output terminal and the input terminal through the HDMI cable, and select the signal source card of the projector, as shown in Figure 2.

02 SETTING

- 1) Select "Settings" on the home page and press the "OK" to enter. You can set bluetooth, network, image mode, sound and other system functions, as shown in FIG. 3 and FIG. 4 below.



Figure 3: Setting Entry



Figure 4: Related Functions of Setting

03 BLUETOOTH

- 1) The first item in the menu bar at the top of "Settings" is "Bluetooth", as shown in Figure 7. This Bluetooth is different from the Bluetooth in Bluetooth audio (receiver). This Bluetooth uses the projector as the "host" (sender) to connect to external Bluetooth audio, Bluetooth headset, and Bluetooth keyboard and mouse. Operation method is similar to android phone connect to Bluetooth headset.



Figure 7: Bluetooth Related Settings

- 2) Click "Bluetooth Switch" to enable/disable bluetooth function.
- 3) Click "Search" to search for available bluetooth devices nearby.
- 4) After the search is complete, click the "Device Name" (default is Home Projector).
- 5) In the list below, you can view nearby bluetooth devices, select the desired Bluetooth device and press "OK" to connect/unpair the Bluetooth device.

04 NETWORK

- 1) The second item in the top menu bar of "Settings" is "Network". See Figure 5.
- 2) Click Network Information to query the current connected network information.




Figure 5: Network Connection Entry



Figure 6: Searching for Available Networks

- 3) Press "OK" to "scan" to search for available networks. See Figure 6.
- 4) After "scanning" is completed, select the required hotspot in the network list and click "Confirm", then input the correct password to connect the projector to the hotspot (WIFI). See Figure 7 and Figure 8 below.



Figure 7: Connecting the Network




Figure 8: Entering a Password

05 IMAGE MODE

- 1) The third item in the top menu bar of "Settings" is "Image Mode". See Figure 9.



FIG. 9: Image mode-related functions

LOGO DESIGN

06 SOUND SETTINGS

- 1) The 4th item in the top menu bar of 'Settings' is 'Sound Settings'. See Figure 11.



Figure 11 Related Functions of Sound Setting



Figure 10 Parameter Adjustment

- 2) Select 'Image Filter' in the image mode list and press 'left/right' to switch the image mode. Under 'User Mode', parameters can be customized and the grey state list can be activated. Press 'OK' to enter parameter adjustment and press 'left/right' to 'increase/decrease' parameter. See Figure 10.



Figure 12 Related Functions of Sound Settings

- 3) Automatic volume: Press the 'left/right' to 'turn on/turn off', as shown in Figure 12.
- 4) Select 'Sound Mode' in the list of Sound Settings, and press 'left/right' to switch the sound mode. In 'User Mode', you can customize parameters and activate the grey state list. Press 'OK' to enter parameter adjustment, and press 'left/right' to 'increase/decrease' parameters. See Figure 13.



Figure 13 Custom Parameters

07 OTHER SETTINGS

- 1) The fifth item in the menu bar at the top of 'Settings' is 'Other Settings', which can be used for language switching, factory setting restoration, screen flipping, system upgrade and other functions, as shown in Figure 14.



FIG. 14 Related Function Entry



Figure 15 Language Switch

- 2) Select 'Language' in the 'Other Settings' list. (FIG. 14). Press 'OK' to enter the language list (FIG. 15), and press 'OK' to switch.



Figure 16 Screen Flip

- 3) In the 'Other Settings' list, select 'Screen Flip' and press the 'left/right' to switch the projection mode. See Figure 16.
- 4) 'Restore Factory Settings' - Restore system data to factory settings.

08 FILE MANAGEMENT

- 1) Select the 'File Management' on the home page and press 'OK' to enter. You can open data in local files or mobile storage devices.



Figure 17 File Management Entrance



Figure 18 File Management Disk Entry



Figure 19 File Classification

- 2) In the file manager, click the categorized entry of video, music, and picture to enter the corresponding detailed directory. See Figure 19.
- 3) Press the 'Return key' to go back step by step when you go to other folders in the USB flash disk.



Figure 20 video file



Figure 21 music file



Figure 22 Picture file

Warning:
Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.