

MQ-M4 Wireless Speaker User Manual

Dear customer:

Thank you very much for purchasing our Glaze-4 wireless speaker. Please read this manual before use to understand that this product will make it easier to use,

NO1. Product Parameters

Model: MQ-M4

Type: Wireless Stereo

Connection methods: wireless connection, TF, USB, FM, AUX

Signal to noise ratio: 95 dB or higher

Power supply: built-in lithium battery

Frequency: 2402-2480MHz

Battery capacity: 500mAh

Broadcast time: 2-3 hours

Speaker specification: 52CM 5W

Distortion rate: less than 0.5%

Package Includes: 1 speaker, 1 USB power cord, and 1 Instruction manual

NO2. Function Introduction

After pressing the power button, you will hear a *dong dong dong° prompt sound and the colorful lights flashing simultaneously. After turning on, Bluetooth automatically searches and the colorful Indicator light flashes. Now pair the device with your phone and the name should be displayed as 'MQ-M4', but it may vary depending on the device. After successfully pairing with the speaker, a sound of *dong° will be emitted. This device has a memory function. After establishing a Bluetooth connection, the Bluetooth will automatically connect when the speaker is powered on. If the Bluetooth connection falls, please shut down and restart, or it may be due to low battery power. Please recharge.

“  ” Key: Long press to turn on/off. Double click to make (reject) a call. Short press to pause/play while music is playing. When in AUX mode, short press to mute. When in radio mode, short press 'search' (stop searching).

“  ” Key: When playing music, short press to switch to the previous track, long press to decrease volume. “  ” Key: When music is playing, short press to switch to the next track, long press to increase volume.

“M” key: Short press to switch modes. Long press the couplet function. Double click to switch lights. Call function in Bluetooth connection state:

Answer the phone: When a call comes, press the “  ” button briefly to answer the call. Hang up the call: When the call is complete, short press the “  ” button to end the call.

Cancel dialing: Double click the “  ” button to make a call, and before the other person answers the call, press the “  ” button briefly to cancel the dialing. This product will automatically shut down after 10 minutes without playing music or inserting an audio cable. If needed, please restart the device.

NO3. Precautions:

..To extend the service life of the machine and protect your physical and mental health, please do not listen to music loudly for a long time to avoid damaging your hearing.

2. If you find that the machine is malfunctioning, please immediately turn off the power switch, unplug the power plug, USB plug to prevent damage to the speaker and components.

3. Power shortage affects wireless distance or wireless disconnection. Please charge in a timely manner, Warning.

1. Please store and use this product at room temperature.

2. Do not expose this product to rain and humid environments.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.