


sanag T45 Pro MP3 TWS Bluetooth Headset
FCC ID:2A6MS-T45PRO



User Guide

- Product Overview



1. Headset function key 2. Earphone charging contact 3. Charging bin charging contact
4. TF card jack 5. Type-C charging port 6. Headset light 7. Power display
8. MP3 next key 9. MP3 on a key 10. MP3 volume reduction key 11. MP3 volume button
12. MP3 pause/play button

● Headset Function Operation Instructions

- **Power-on pairing:** Long press the function key for 3 seconds/take out the charging bin, the prompt light will flash white quickly and there will be an electronic sound prompt to start pairing.


- Power off: Long press the function key for 5 seconds/put into the charging bin, the prompt light will flash white for 3 times and there will be an electronic tone indicating successful shutdown.
- Earphone charging: The earphone is displayed with a white breathing light during charging.
- Fully charged headset: fully charged for about 1 hour, the white light of the cue light and the charging cabinet are all turned off.
- When pairing is complete: the main headphone indicator blinks white quickly, while the secondary headphone indicator blinks off.
- Connect to a mobile phone: there will be an electronic voice prompt when connecting to a mobile device.
- Disconnect: the main headphone prompt light flashes white quickly, the secondary headphone prompt light does not turn on, and there is an electronic sound prompt.
- Answer a call: Press the function key to answer a call.
- Hang up: Press the function key to hang up the call.
- Reject calls: Double click the function button to reject calls.
- Voice control function: Long press the function key to open, the phone needs to support this function.
- Music playback: Press the function key to play the music.
- Music pause: Short press the function key to pause playing.
- Previous: Double click L function key to switch the previous song.
- Next: Double click the R function key to switch to the next song.
- Volume plus: Triple L function key to increase volume.
- Volume reduction: three clicks R function key to reduce volume, and electronic sound prompt.
- Low power prompt: low power prompt light white light 3S shining and electronic sound prompt.
- Restore factory Settings: Four clicks of the L/R function key in pairing state, the white light flashes three times, and the machine prompts.
- If the headset is not successfully connected to the phone within 5 minutes or the launch bay will automatically shut down.

- Charging Bin Function Operation Instructions

- Charging bin Charging: The display of the charging bin shines according to the percentage of power, and the Type-C input of the data cable is 5V/0.5A.
- Charging compartment full charge: the charging compartment is full for about 2 hours, and the display continues to light up according to the percentage of electricity.
- Discharge in charging compartment: The display of charging compartment is long and bright according to the power ratio.
- Power-on pairing: Press and hold the function key for 2 seconds, and the prompt light will flash white.
- Shutdown: Long press the function key for 4 seconds/put into the charging bin, the charging bin prompt light is white for 2 seconds, and the device is shut down.
- Successfully connected to the headset: No display in the charging bay.
- Device playback: Press the function key to play music. After pressing the key, light up for 15s and then turn off.
- Device pause: Press the function key to pause the music. After pressing the key, the screen lights up for 15s and then turns off.
- Previous: Press the function key to switch to the previous one. After pressing the key, the screen will light up for 15s and then turn off.
- Next: Press the function key to switch to the next one. After pressing the key, the screen will light up for 15s and then turn off.
- Volume increase: Short press the function key to increase the volume, and there is a prompt tone "beep", the screen after the key is on for 15s and then off.
- Volume reduction: Press the function key to reduce the volume. After pressing the key, the screen will light up for 15s and then turn off.
- Low battery warning: the display of the charging bay flashes according to the percentage of battery, and the warning light is white and 3S flashing reminder.
- Data download: Insert the data cable in the startup state, and the display of the charging bay flashes according to the percentage of power.
- Restore factory Settings: pairing state four click function key charging compartment shutdown, prompt light white light steady 2s off, start to recover
- If the charging bin is not successfully connected within 3 minutes, the earphone will automatically shut down.

- Bluetooth Pairing

1. Open the charging compartment, and the headset will turn on automatically. Please put the distance between the Bluetooth headset and the mobile phone (or other connected devices) within 20CM, the closer the better.
2. Open the Bluetooth interface of the mobile phone, search for "sanag T45 Pro", and click Pair to connect the device.



- Specification Parameter

- Product name :MP3 TWS Bluetooth Headset
- Product model: sanag T45 Pro
- Bluetooth version: V 5.3
- Connection range: ≥10m
- Headphone battery capacity: 30mAh
- Charging compartment battery capacity: ≥400mAh

- Matters Need Attention

- Do not use abrasive cleaning agents to clean this product.
- Do not allow this product to heat or be near a source of fire, such as a cooking stove.
- Do not expose this product to direct sunlight for a long time.
- Do not dispose of this product in fire to avoid explosion.
- Do not attempt to disassemble this product for any modification, as it does not contain any repair components.
- Do not use this product in the rain.
- If you do not intend to use this product for a long time, please store it in a dry environment and charge the headset at least once a month to extend its life and avoid extreme temperatures and dust.

- FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.