

OPERATING INSTRUCTIONS



Thank you so much for your purchase

INSTRUCTIONS FOR USE

①Attachment Connector

②Motor In sae

③Suction Cup

④power pack


⑤Base Plate

⑥Rotary Knob


⑦Handle

⑧remote controls

1. Press all of ⑤ to mount machine to smooth surfaces.
2. Install one of included attachments onto ①.
3. Rotate ⑥ to adjust the angel of the thrusting position.
4. Plug ④ in Power, turn on the remote controls.



INSTRUCTIONS FOR USE



 Tap to turn on while in standby mode; this controls changes in frequency.

 While in standby mode, tap to turn it on and adjust the speed.

 The device is in standby mode by default. Tap to activate it. After it starts up, tap to pause it, and press and hold to turn it off.

SPECIFICATIONS

Material	ABS plastic and metals + TPE
Input	100V~240V
Output	DC 3~24V
Power	0~24W
Motor	24V (60W)
Mode	6speed+6modes
Product function	Thrust
Noise	50-55dB
Extension Distance	2.36 inches (6 cm)
Adjusting Angle	About 135 degrees
Size	37.8×15.3×16.8 cm
Remote control voltage	DC 3V

MAINTAIN

Remove and clean the accessories after each use. Use a mild detergent and a damp cloth, or follow the separate instructions in the attachment. Do not use irritating chemicals or abrasive cleaning pads unless otherwise specified.

Remove any dust or other substances that may accumulate on the machine with a soft cloth dipped in a mild detergent solution. Do not use harsh chemicals or abrasive cleaning pads.

Check the moving and fixed parts regularly for signs of wear. Before continuing to use, repair, adjust or replace any parts that may be loose.

Danger!

This product is not waterproof, please do not wade.

Attention!

- a. Use only on a flat and stable surface to prevent damage to your machine. Cause injury or damage. Check the normal operation of the machine before each use. If your machine can't run as expected, please stop using parallel connection immediately. Department of store customer service help.
- b. in order to achieve the best effect, according to the need to use lubricant with accessories.
- c. in order to achieve the best results, please clean after each use. Don't rinse.
- d. Unplug the machine after each use to ensure a long service life.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

service@blissmakersnovelties.com

