

All in one AD player

8" LCD Screen

User Manual

Contents

Notes of Importance.....	2
Features.	3
Package Contents.	4
Android OS Home Screen.	5
Factory Reset.	6
Specifications.....	7

Notes of Importance


- 1) The equipment is for indoor use only.
- 2) To reduce the risk of fires or electric shock, do not expose the equipment to rain or moisture.
- 3) Do not block the ventilation holes on the back of equipment at any time.
- 4) Do not subject the equipment to severe shocking
- 5) Prevent any foreign matter falling into the external slot.
- 6) Do not open the case of the equipment. There is a risk of electric shock, and there are no user serviceable parts inside. Opening the case will void your warranty.

Features


- ◆ 8" LCD Screen,1280x800
- ◆ Quad-core Cortex-A55 up to 1.8GHz
- ◆ Android 11
- ◆ 8 Ω *1W Speaker

Package Contents

Please make sure all of the following are present when you unpack your AD players.



8" all in one AD
player



Power adapter



User manual


All in one AD player

Android OS Home Screen

- 1) Insert the power lead into the DC socket, and then insert the other end into the power socket.
- 2) The Equipment will automatically power on
- 3) Screen will show starting logo.
- 4) Waiting for about 25 seconds and enter into main interface.



Android OS Home Screen



Specifications

No.	Item	SPEC
1	CPU	Quad-core Cortex-A55 up to 1.8GHz
2	O/S	Android 11
3	DRAM	2GB
4	Memory	EMMC,16GB
5	LCD	8"
6	LCD Resolution	8",1280x800
7	Touch screen	touch panel
8	Ethernet	100M Ethernet
9	Camera	NO
10	Video format	MPEG1;MPEG2;MPEG4;4K UHD,H.265,H.264,RV,VC-1,VP8
11	Audio format	MP2,MP3,AAC etc.
12	DC input	NO
13	Poe	48V1A
14	VESA	100x100mm
16	Power consumption	13W(max)
17	The dimensions	8", 198.1x133.33x15.5mm
18	WiFi	802.11b/g/n
19		

Common Problems And Countermeasures

1. Can't open the machine
Solutions: connect the charger after 10 minutes to boot.
2. In the touch screen have no reaction when charging or automatically jump to the other interface.
Solution: The connection is not the factory configuration chargers may cause bad touch, please use the factory configuration when charging.
3. After open the WiFi, not be able to connect to the router
Solution: May the WiFi password input error, please enter the password correctly.
4. Computer USB connection reaction
Solution: Check whether the connecting line between the machine with a computer is connected, then click the machine upper /left screen
5. In the abnormal operation after crash, lag
Solution: Press the restart button,then restart will be back to normal.
6. WIFI and Bluetooth function description
Open Settings, turn on WIFI or Bluetooth function, wait to scan nearby devices, click Connect pairing

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC Warning

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with ISSED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet appareil est conforme aux CNR exemptes de licence d'Industrie Canada . Son fonctionnement est soumis aux deux conditions suivantes :

- (1) Ce dispositif ne peut causer d'interférences ; et
- (2) Ce dispositif doit accepter toute interférence , y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

Ce matériel est complété par une exposition de rayonnements ISSED pour un environnement naturel. Ce matériel doit être installé et se faire avec une distance minimale de 20cm entre les radiateurs et les autresYour body shop.

Note: The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.