

Overview introduction

The device works with both Google's Find Hub and Apple Find My, providing a secure and user-friendly solution for finding belongings. Collaborative positioning is carried out by leveraging a vast secure network composed of Android™ and Apple devices. It can easily locate keys, wallets, and more, with security as its top priority. Designed for user convenience, it helps you say goodbye to lost items and simplifies daily life.

How To Pair (iOS device)

Note: iOS or macOS with the latest version.

- 1.1 Place the device next to your Apple device like iPhone.
- 1.2 Turn on Bluetooth on iPhone and connect to the Internet.
- 1.3 Press and hold the button for 2 seconds, and you will hear a beep indicating successful power-on.
- 1.4 Open the 'Find My' app.
- 1.5 In the Find My app, tap Add Item, then select Other Supported Items.
- 1.6 Once the device is located, tap 'connect'.
- 1.7 Enter a name and choose an emoji for the device. Tap 'Continue'.
- 1.8 Find My will ask for confirmation to add the device to your Apple ID. Tap 'Agree'.
- 1.9 Tap 'Finish' and the device will be set up and ready to be used.

How To Pair (Android device)

Note: It requires an Android smartphone that supports Google Play Services and runs on Android 9 or later.

Android Pairing Name: Smart Tag

- 2.1 Search and download the Find Hub app on Google Play.
- 2.2 Ensure that your phone has location services enabled, Bluetooth turned on, is connected to the internet, logged into a Google Account, and has the "Find Hub" feature activated.
- 2.3 Open 'Find Hub' app.
- 2.4 Place your device near your Android device.
- 2.5 Press and hold the button for 2 seconds, and you will hear a beep indicating successful power-on.
- 2.6 Wait for a half-screen notification to appear, then follow the on-screen instructions on your Android device to add the the device to Find Hub.

Battery

The device contains a coin shaped battery. During the product's lifespan, it may be necessary to replace the battery. By observing the correct negative and positive connections, only replace batteries of the same type (CR2032) and rating.

Battery replacement

- 3.1 Use the small tool to open the rear cover.
- 3.2 Replace the new battery.
- 3.3 Close the rear cover.

Additional Tips

- 4.1 To switch from working mode to disabled mode (Flight Mode), simply power off the device: press and hold the button for approximately 7 seconds, then release it once the device emits a beep pattern of "beep, beep-beep, beep-beep-beep".
- 4.2 To switch from disabled mode (Flight Mode) to working mode, please power on the device again: press and hold the button for approximately 2 seconds, then release it once the device emits a single "beep"; the device will enter pairing mode, and note that if no connection is established within 2 minutes, it will time out and require a restart.

4.3 Factory Reset: Press and hold the button – do not release it after hearing the continuous beep pattern of "beep, beep-beep, beep-beep-beep"; keep holding until a long beep is heard, then release. Note that a timeout will occur after 2 minutes.

4.4 To remove this device from your Apple device: Open the "Find My" app, select "Items", tap on the device, then scroll down and tap "Remove This Device".

4.5 To remove this device from your Android device: Open the "Find Hub" app, tap on the device you want to remove, then tap the "Settings" button in the top-right corner. Tap "Remove from Find Hub" at the bottom of the interface, and then tap the "Remove" button. Once the device is removed successfully, it will emit a "beep-beep" prompt, and a "Device Removed" pop-up will appear on your phone.

4.6 If this device fails to connect to the App, follow the instructions in Section 4.3 to perform a factory reset, then restart the pairing process.

Important matters

The device contains delicate electronic parts, including a battery to avoid damage, loss of function, or potential harm, please refrain from dropping, hitting, puncturing, crushing, disassembling, exposing it to extreme heat or liquids, or placing it in areas with a high concentration of industrial chemicals.

WARNING: Do not swallow the battery; There is a chemical burn hazard.

Choking Hazard Warning

The device, its battery compartment door, the battery itself, and the case may pose a choking hazard or cause injury to small children. Please keep these items out of reach of young children.

The device, the battery hatch, the battery itself, and the enclosure may pose a choking hazard or cause injury to young children. Keep these out of the reach of small children.

Medical Device Interference

The device contains components and radios that emit electromagnetic fields, as well as magnets. These elements may potentially interfere with pacemakers, defibrillators, or other medical devices. To ensure safety, maintain a safe distance between your medical device and the device. We strongly advise consulting your physician and the manufacturer of your medical device for information that is specific to your situation. If you suspect that the device is interfering with your pacemaker defibrillator or any other medical device, discontinue its use immediately.

Important Handling Guidelines

It's normal for the device to show discoloration with regular use. To clean it, use a soft, dry, lint-free cloth. Avoid applying pressure with sharp objects on the rubber seal or the battery terminal contacts inside the device. Do not allow moisture to enter any openings or use aerosol sprays, solvents or abrasive materials to clean the device.

Legal notice

Find Hub helps you find and connect to what matters in a single secure place. Google, Android, Google Play and Find Hub are trademarks of Google LLC.

This product has been certified by Google to meet Find Hub network accessory specifications. Google is not responsible for the operation of this product. Google is also not responsible for ensuring that the product complies with any applicable safety standards or other requirements. Find Hub network requires location services and Bluetooth to be turned on. Requires cell service or internet connection. Works on Android 9+ and in certain countries for age-eligible users.

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.