180g铜版纸彩色双面印刷，风琴折页

DOUBLE SIDE PRINTED - 180G

3.6”　3.6”　3.6”　3.6”

3.6”

FCC

These devices comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) these devices may not cause harmful interference, and (2) these devices must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
•Reorient or relocate the receiving antenna.
•Increase the separation between the equipment and receiver.
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
•Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.

Warranty 180 days from purchase date
For support please email **icelabs.co@gmail.com**

©2026 Best Brands Consumer Products LLC
2147 Lincoln Highway
Suite 402
Edison, NJ 08817-3365
RN# 22195 • Made in China

FCCID:2A6QJOS3000B

*Photos are for illustration purposes only
Ice Labs LLC
All trademarks and copyrights are property of their respective owners.

TWS STEREO PAIRING

Note: TWS mode requires two identical Pulse speakers.
1. Turn on both speakers.
2. Make sure neither speaker is connected to a Bluetooth device.
3. Double-press the + button on one speaker.
4. Wait for both speakers to pair automatically.
5. Only one BU55266 device will remain visible in your Bluetooth device list.
6. Connect your mobile device to that Bluetooth device.

The speakers are now paired in True Wireless Stereo (TWS) mode.
To disconnect TWS mode, double-press the + button again.


CHARGING

Connect the supplied USB Type-C cable to the speaker. **Connect the other end to:** a USB wall charger (not included), or a powered USB port on a computer.

Charging Status:
Red LED On: Charging
Red LED Off: Fully Charged

When the battery level becomes low, the speaker announces: **"Low Battery."**
When the battery reaches a critically low level, the speaker announces: **"Please Charge."**
Recharge the speaker as soon as possible to avoid automatic shutdown.


FUNCTIONAL BUTTONS



① Volume up/Next track
② Volume down/Previous track
③ ON/OFF button
④ Play/pause/phone
⑤ Light mode button
⑥ Mode button
⑦ TF card slot
⑧ AUX slot
⑨ USB slot
⑩ Charging port

PULSE

PREMIUM WIRELESS SPEAKER



10W
BOLD SOUND.
DEEP BASS.

USER MANUAL

Notice: Please read user manual carefully and keep it for your records

3.6”

BEFORE FIRST USE

- Fully charge the speaker before using it for the first time.
- Use only a certified 5 V USB power source.
- Avoid playing music while the battery is charging for optimal battery performance.
- Recharge the speaker after hearing the "Low Battery" voice prompt.
- If the speaker announces "Please Charge," recharge it immediately.
- Keep the speaker within approximately 10 m (33 ft) of your Bluetooth device for the best connection.

SPECIFICATIONS

- Material: ABS, fabric, and silicone
- Bluetooth Version: 5.3
- Rechargeable Battery: 1200 mAh
- Speaker Power: 1 × 10 W
- Functions: Bluetooth / FM / TF Card /USB Playback /AUX Input / RGB Light / TWS
- Water Resistance: IPX4
- Charging Port: USB Type-C
- Product Size: 127 × 127 × 175 mm

PACKAGE INCLUDES

- 1 × Wireless Speaker
- 1 × USB Type-C Charging Cable
- 1 × User Manual

BLUETOOTH PAIRING

1. Press and hold the Power button to turn on the speaker.
2. The speaker will automatically enter Bluetooth mode and announce: **"Bluetooth Mode."**
3. Enable Bluetooth on your phone, tablet, or computer.
4. Search for available Bluetooth devices.
5. Select **BU55266** from the device list.
6. Once connected successfully, the speaker will announce: **"Paired."**

If the Bluetooth connection is interrupted, the speaker will announce: **"Disconnected."**

POWER BUTTON

Press and hold the Power button for approximately 2 seconds to turn the speaker on or off. When powered on, the speaker plays a startup sound before entering Bluetooth mode. When powered off, the speaker plays a shutdown sound.

MODE BUTTON

Press briefly to switch between:
- Bluetooth
- FM Radio
- TF Card
- USB Playback
- AUX Input

A voice prompt will announce each selected mode.

LIGHT MODE BUTTON

Press briefly to cycle through the available RGB lighting effects.
Press and hold to turn the lighting on or off.

PLAY / PAUSE / PHONE

Music Playback
- Press once to play or pause music.

Phone Calls
- Press once to answer an incoming call.
- Press again to end the call.
- Press and hold for 2 seconds to reject an incoming call.
- Double-press to redial the last dialed number.

When receiving a call, the speaker will play a ringing tone.

VOLUME UP / NEXT TRACK

- Press briefly to skip to the next track.
- Press and hold to increase the volume.

VOLUME DOWN / PREVIOUS TRACK

- Press briefly to return to the previous track.
- Press and hold to decrease the volume.

FM RADIO MODE

Press the Mode button until the speaker announces:
"FM Radio Mode."
Press the Play/Pause button to automatically search for available FM stations.
The speaker will automatically save all detected stations.
- Press the + or – button briefly to switch between saved stations.
- Press and hold the + or – button to adjust the volume.

AUX MODE

Connect a 3.5 mm AUX cable to the speaker and your audio device.
The speaker will automatically switch to AUX mode and announce:
" Line In."
If necessary, press the Mode button until AUX mode is selected.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

3.6”