


# Motor controller

Model: CMD850E



According to the company's business development, the product may be adjusted from time to time, and the specific functions and contents may be adjusted dynamically. The company cannot guarantee that the relevant packaging and instructions updated in time. Customers please use in practical. The functions and contents shall prevail.

## Structural description



### Reset key

**Add device:** press 3 time, then hold on the press reset key till the light on

**Remove device:** press 3 time, then hold on the press reset key till the light on

### Indicator light

Colour: green;

Light on: Remove device


## Basic parameters

|                 |                    |                 |             |                     |          |
|-----------------|--------------------|-----------------|-------------|---------------------|----------|
| Product model   | YS-MT750           | Radio frequency | 2.4G/433MHz | Maximum width       | 12m      |
| Rated power     | 45W                | Maximum payload | 50Kg        | Protection grade    | 20IP     |
| Rated current   | 0.14A              | Fuselage weight | 1.05Kg      | Running time        | >4min    |
| Rated torque    | 1.2Nm              | Operation noise | 33dB        | Working temperature | -10℃~50℃ |
| Running speed   | 14cm/s             | Minimum width   | 0.9m        | Power line type     | 2 core   |
| Working voltage | 100~240Vac 50/60Hz |                 |             |                     |          |


## Functional characteristics

- Touch start function
- Power failure pull function
- Resistance And Stop Function
- Run gracefully
- Fabric rebound correction function
- Stroke fine tuning function
- Electronic memory limit
- Remote control
- Timing control
- Speech control
- Positive inversion settings
- Calibration function

## Motor installation



Check whether the pull-out lock rod is in the schematic position. If on the right side of the diagram, pull the pull-out lock rod while pulling it to the left.



The motor is inserted into the main transmission box.



Pull out the locking rod to the right until the rod head falls into the right limit hole.


## Motor disassembly




Pull down the locking rod downward to make the top slide out of the limit hole.



Pull and pull the lock bar to the left side.



Remove the motor.




Pullout lock rod


### Be careful

- Install according to the size requirements in the illustration.
- Ensure the position of the pullout lock rod in the illustration.
- The ceiling of the motor must be strong enough to withstand all the weight including the guide rail, motor and curtain cloth.


## Remote control pair code



## Motor and remote control counter code




The motor is energized.



Press the motor reset key for 3 seconds until the indicator light is long.




The remote control opens the back cover and press the P2 key twice (press the first button, the indicator light flashes slowly, press the second button, the indicator light flashes twice, and goes out).




The front of the remote control is pressed or opened, and the code is successful.

## Motor and remote control decoding




After energizing, press the reset key of the motor to flicker the indicator.




Then press the reset button for 5 seconds, the indicator lights flicker 5 times, and the decoding is successful.

## Commutation of motor operation



After power on, press the motor reset key for 3 seconds until the indicator light is on.



The front side of the remote control is pressed by the pause button, and the reverse setting is successful.



The product uses graffiti intelligent system control, please download graffiti smart APP.

## Electric motor networking



Scanning two-dimensional code, downloading and installing graffiti smart APP or searching and downloading in the mobile application market, and registering account login.



Press the three reset button continuously, then press the green indicator to flash.



in Tuya smart app intelligent gateway press [Add Subdevice] to add device.



Select "curtains", confirm the device status according to the page instructions, click confirmation to enter the network.



Enter the password, click confirm, make the distribution network.



Waiting for the connection to be successful, you can control it on APP and customize the setting name.

## The way to solve the net problem is

There are two ways to solve the intelligent switch network :

Method 1: on mobile APP, remove the device to be removed, click the upper right corner. , Select "remove equipment";

Method 2: Release the curtain motor, press the reset key of the motor three times in a row, and then press it for a long time until flash, then the equipment will be relieved.

## Device sharing:

---

Enter the device on graffiti APP and click on the top right side.  Select "share device", then "add share", add the account you want to add to it.

## Speech control method

---

Graffiti intelligent curtain motor supports a variety of voice box control: Tmall elves | Little love classmate | takki | Amazon | Google Home

1. intelligent curtain motor through "graffiti intelligence" APP networking.
2. bind the account of graffiti intelligence to the APP of each voice box, that is, the corresponding voice control.

## Example 1: Tmall elf control

---

1. intelligent curtain motor through "graffiti intelligence" APP networking.
2. open the Tmall elf APP. Click on my "add device" to bind the platform account. Find "graffiti intelligence" to bind. After binding, you can control Tmall elf.

## For example, 2: little love classmates control.

---


1. intelligent curtain motor through "graffiti intelligence" APP networking.
2. open "Mi Jia" APP. Click on "mine" — "Set up" — "Laboratory function" — "Third party platform" — Add "find" graffiti intelligence "to bind. After binding, you can control your classmates.

## Inventory

---

1. intelligent curtain motor;
2. power cord.
3. a user manual.

## Interface description



## After sale policy

### Three package provisions

1. Within 7 days from the date of your signature and receipt, if there is a performance failure of this product, the service center will confirm that it can enjoy free return or exchange services.
2. Within 8-15 days from the date of your signature, if there is a performance failure of this product, the service center will determine that it can enjoy free exchange or maintenance services.
3. Within 36 months from the date of your signing and receiving, the product has performance failures, which can be repaired free of charge by the service center.

### Quality assurance performance failure

1. the product is not energized, or the power fails to start properly.
2. the key of the device can not be used normally.
3. the function of other products caused by other hardware failures can not be used normally.

### Non warranty range

1. Unauthorized maintenance, misuse, collision, abuse, infusion, accident, alteration, incorrect use of non-product accessories, or tear, alter labels, anti-counterfeiting marks;
2. more than three packages are valid.
3. the damage caused by force majeure, such as fire, flood and lightning strikes, is not in line with the situation of failure.
4. failure of the product and accessories due to human causes.

### Commitment and statement

The company guarantees that the products conform to the national standards. The company will not undertake any obligations for any declarations related to products that are not directly issued by the company.

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### RF Exposure Information

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition, compliance with exposure requirements.