

SLEEP SOOTHER SPEAKER

OWNER'S MANUAL (V1.0)



WARNING MESSAGE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Buttons and Interfaces Guide



Button	Long Press 10s	Long Press	Single Click	Double Click
	Reset	POWER ON / OFF	TF/White Noise/BT Switching	Disconnect BT (Only BT Mode)
	/	Previous song	Volume -	/
	/	Next song	Volume +	/
	/	Cancel The Countdown	Countdown Shutdown 30/60/90 minutes	/
	/	Connect/Disconnect TWS(Only BT Mode)	Play/Pause	Sleep Mode Vol
		Play in a loop (Only TF Mode)	Answer/Hang up (Only BT Mode)	

⑥ Microphone ⑦ TF Card ⑧ Type-C Charging port: DC 5V

⑨ Detailed Explanation of Indicator Light Status:

LED Indicator	Mode	Flashing	Be Constantly On	Be Off	Breathing
Red Light		/	Charging	Fully Charged	
Blue Light	TF Mode	/	Pause	/	Playing
	WN Mode	/	Pause	/	Playing
	BT Mode	Waiting For Connection	Pause	/	Playing

Detailed Explanation of Functions

Power ON / OFF

Long Press "①" button: Power ON / OFF.

Function (Mode) Switching

Single click "①" button: Switch between TF card / White Noise / BT.

TF Card (Micro SD) Play Mode

Insert the TF card, the speaker sounds, you can play music.

In TF card mode, long - press the "⑤" button to enable/disable single - song loop.

White Noise Mode

Single - click the "①" button to switch to the white noise mode, and the built - in audio files will play automatically. You can switch audio by long - pressing the "-" and "+" button. Single - click the "-" and "+" button to adjust the volume.

BT Wireless Mode

Single - click the "①" button to switch to BT mode, Open the phone BT function, select the product's pairing code, the speaker is connected after the success of sound.

Phone Call / Handsfree

When the speaker is in the BT connection status, if the mobile phone has an incoming call, the speaker will make a ringtone. Single - click the "⑤" button to answer the call and press it again to hang up.

TWS Wireless Couplet Mode

Use two speakers. In BT Mode, Long Press any one of the "⑤" button to enter the couplet / disconnect couplet. After the couplet, use the phone to search and connect, you can play.

(When TWS couplet mode, the two speakers automatically change to be left and right stereo).

Countdown Function

Single - click the "④" button to activate the countdown shutdown function. There are three countdown options: 30 minutes, 60 minutes, and 90 minutes. Long - press the "④" button to cancel the countdown.

Reset Function

If the speaker freezes or crashes, you can perform a reset by long - pressing the "①" button for 10 seconds.

About Charging

Plug the USB-C cable into the speakers and connect the DC 5V charger to charge the speakers.

ZH

快速操作指南

按钮	长按10秒	长按	单击	双击
	复位	开机/关机	TF卡/白噪音/蓝牙功能切换	断开蓝牙 (仅限蓝牙模式)
	/	上一曲	音量减小	/
	/	下一曲	音量加大	/
	/	取消倒计时	倒计时 30/60/90分钟	/
	/	对联/断开对联 (仅限蓝牙模式)	播放/暂停	进入睡眠 (音量) 模式
		单曲循环 (仅限TF卡模式)	接电话/挂电话 (仅限蓝牙模式)	

-  麦克风
-  TF 卡
-  Type-C 充电口，DC 5V
-  指示灯状态详细说明：

LED 指示灯	功能模式	快闪	常亮	灭灯	呼吸灯
红灯		/	充电中	充满电	/
蓝灯	TF 卡	/	暂停	/	播放中
	白噪音模式	/	暂停	/	播放中
	蓝牙模式	等待连接中	暂停	/	播放中

功能详细说明

开机/关机

长按“①”按钮：打开或关闭电源。

功能（模式）切换

单击“①”按钮：在TF卡模式、白噪音模式、蓝牙模式之间切换。

TF卡（Micro SD）播放模式

插入TF卡，扬声器发声，此时你可以播放音乐。
在TF卡模式下，长按“⑤”按钮可启用/禁用单曲循环。

白噪音模式

单击“①”按钮切换至白噪音模式，内置音频文件将自动播放。长按“-”和“+”按钮可切换音频。单击“-”和“+”按钮可调节音量。

蓝牙无线模式

单击“①”按钮切换到蓝牙模式，打开手机的蓝牙功能，选择产品的配对码，配对成功且扬声器发声后即完成连接。

通话/免提

当扬声器处于蓝牙连接状态时，如果手机有来电，扬声器会响铃。单击“⑤”按钮接听电话，再次按下该按钮挂断电话。

TWS无线配对模式

使用两个音箱。在蓝牙模式下，长按任意一个“⑤”按钮进入配对/取消配对状态。
配对完成后，用手机搜索并连接，即可播放。
(处于TWS配对模式时，两个音箱自动切换为左右立体声。)

倒计时功能

单击“④”按钮激活倒计时关机功能。
倒计时有30分钟、60分钟和90分钟三种选项。
长按“④”按钮取消倒计时。

复位功能

如果扬声器出现卡顿或死机情况，长按“①”按钮10秒进行复位。

关于充电

将USB - C线缆插入音箱，连接DC 5V充电器为音箱充电。