4C 骑马钉

FCC Warning
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement:
This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Product Model: SVH-07

SMART HOUSE FAUCET TIMER

Model: SVH -07

Instruction Manual

The illustrations used in the instruction manual may differ from the actual products you have purchased.

Please read these instructions before use,and keep for future reference

MADE IN CHINA

WELCOME

Congratulations on purchasing your Smart Hose Faucet Timer!

Faucet watering has never been better, easier, or more convenient with the ability to control it from your phone. To access this timer, you can schedule, manually operate and monitor flow without climbing through your shrubs. It also allows you to water your lawn and garden, which is excellent for gardening, hydroponics, hiking and many, many more activities.

IMPORTANT INSTRUCTIONS

When using this smart water timer, basic precautions should always be followed, including the following:

Read all instructions before using this smart device.

SAVE THESE INSTRUCTIONS

PART 1
1. Make sure to follow the correct polarity indicated in the battery compartment to install the (1*) AA alkaline AA batteries.
2. Do not mix old batteries with new batteries. Replace all batteries at the same time. Do not use water timer for anything other than the intended purpose.
3. This appliance should not be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been supervised or given instruction concerning use of the appliance by a person responsible for their safety. This appliance is not a toy.

PART 2
1. Do not allow or submerge the timer in water or allow liquid to drain in.
2. Do not expose to the high concentrations of salt or allow it to dry out.
3. Do not assemble the equipment when it is switched ON.
4. Do not use the timer if the electrical outlet may rain. Do not use water timer for anything other than the intended purpose.
5. This appliance should not be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been supervised or given instruction concerning use of the appliance by a person responsible for their safety. This appliance is not a toy.

PART 3
1. Always remove timer from the faucet and take out all the batteries before performing any cleaning or maintenance.
2. To prevent any part of water in the timer from freezing, disconnect the electrical parts and remove the batteries in cold weather. Store the timer in a dry environment. Clean only with a thoroughly dry, dirt cotton and electrical parts immediately.
3. Do not use the timer if the timer is damaged.
4. Replace all batteries at the same time. Discharge the batteries!
5. The product itself does not generate pressure, but the pressure of tap water is used. Please make sure the pressure of tap water is between 0.03MPa and 0.8MPa before using.
6. When assembling, threaded connections should be removed.
From the hose faucet and shower indoors to avoid unintended leakage.

PART 4
1. Please activate the valve before use.If you are using it for the first time or after a long period of time, please open the faucet to check if the valve is activated. If it is malfunctioning or has sustained any damage. For questions regarding a damaged product, contact us.

TABLE OF CONTENTS

INTRODUCTION.....1-3
INCLUDED IN PACKAGE.....3
PRODUCTS OVERVIEW.....4
FEATURES OVERVIEW.....5

INSTALLATION.....6-9
STEP 1: INSTALL APP SETUP.....6
STEP 2: SET LOCAL WEATHER.....7
STEP 3: ADD THE WATER TIMER.....8-9

APP PROGRAMMING.....10-25
App Home Screen.....10
APP Programming Screen.....10-12
Manual Watering.....13
Watering Plan.....14
Normal Schedule Watering Plan Setting.....15-17
Cycle/Soak Watering Plan Setting.....18-20

Other Settings
Manual Rain Delay.....20-21

SMART AUTOMATION.....21-23
Automation & Tap-to-Run.....22-23

HOME MANAGEMENT.....23-24

RESET THE DEVICE.....24

DEVICE INDICATOR LIGHT.....24
DEVICE LED LIGHT.....24
TROUBLESHOOTING.....25
BATTERY STATUS.....26

INTRODUCTION

INCLUDED IN PACKAGE



INTRODUCTION

PRODUCTS OVERVIEW

SWV+-07 Smart Hose Faucet Timer

SPECIFICATIONS

Timer
Model: SVH-07
Range: 30ft in without interference
Pressure operating range: 0.3 bar to 8 bar/0.03-0.08MPa
Water temperature: 41°F-140°F/5-60°C
Powered by: 2* AA alkaline batteries (not included)
Bluetooth: 5.0
Bluetooth Type: BLE 4.2

INTRODUCTION

FEATURES OVERVIEW



Hydrawise Pro Overview

1. Remote Control - Manage your watering schedule via the APP at any within 300m without interference hub.
2. Hub Required - Works only with a USB port could be used on adapter or via power supply with USB port.
3. Manual Watering Time-with turn on/off watering and set watering time via bottom button.
4. Watering on schedule-The timer can be set up to several automatic watering programs daily. Each watering program has a different start time, duration, and watering frequency. For example, program 1 may run for 10 minutes every day, while program 2 may run for one hour every weekend after finishing information. The timer will execute the irrigation plan according to the weather trigger conditions you set automatically.
5. Rain Delay-Pause watering for 24 hours or 48 hours.
6. Two Watering Modes-normal and Cycle&Soak mode.
7. Low Power Alarm-The app will notify you when the batteries are at a low power level.

INSTALLATION

STEP 1: INITIAL APP SETUP

1) Download the Tuya Smart App
Search for Smart Life or the Tuya Smart App on your smart device.
Search "Smart Life/Tuya" and download the free version or iOS app.

2) Open the Tuya Smart App
Create an account with your email or mobile number and set a password to begin.

3) Add Device
Ensure your phone/region details are correct on the "Add Device" page and click "Next".

Register

INSTALLATION

STEP 2: SET LOCAL WEATHER

Program and get weather information based on the following steps:
1.Tap the Home Management at the bottom right of the interface.
2.Tap the "Home Management".
3.Tap the "Location" after you create and name "Home Name" and a home name for yourself.

Weather information will be displayed at the top of the "Home" screen and timer programs screen (the weather information will be updated for you to set the delay time according to the actual weather conditions).

INSTALLATION

STEP 3: ADD THE WATER TIMER

1. Insert Two AA Batteries
Remove one of the batteries and the **Left** cover the **Alkaline AA batteries** to power your timer. Remove the battery cover and install the batteries according to the drawings illustrated in the Step. Finally reinstall the battery cover back.

Step 1: Take out the cover on the back of the timer in the rectangle direction and remove the cover.
Step 2: Put the 2 pcs of AA metal rods to access the battery compartment.
Step 3: Insert 2 pcs alkaline batteries into the timer in the correct orientation and reinstall the battery cover and timer rear cover back.

PLEASE NOTE:
*Please use only alkaline batteries.
*Do not mix old and new batteries.
*Do not mix alkaline, standard or rechargeable batteries.
*Exhausted batteries are to be removed from the product.
*Do not short-circuit the battery terminals.

PLEASE NOTE:
Ensure that the battery cover is closed tightly to prevent water and dust from entering.

INSTALLATION

Step 2: If you have a pairing mode and blinking a green light(nearly 0.5 second) for 1 minute.
Return to the APP home screen, and tap **"Add Device"** or **"Add Device"**, and the screen will change to the **"Device"** page and enter into the timer programs screen.

INSTALLATION

Tips 1: If you click from the device, please tap the icon **"Turn on Bluetooth"** and follow the tips to turn on Bluetooth and wait the device to pair.

Tips 2: If at this time you need to re-pair, press and hold **the ON/OFF** button for more than 5 seconds to enter the pairing mode (the green light flashes quickly), and click the Bluetooth icon some play, indicating that the connection is ready for **"Add BT And Device"** and add timer again.

INSTALLATION

Tips 3: If you remove or change the bottom/cold condition Bluetooth symbol 1, there is no need to reconnect to Bluetooth. Tap the icon **"+"** to turn on/off the device after re-install batteries.

APP PROGRAMMING

APP HOME SCREEN

1. Home Management
Tap the Home Management to customize the home name and add family members.
Members & Sub-accounts:Tap to manage invitation and delete family member relationship.
2. Add Device
Tap the Add Device, smart devices on the APP to create a smart home irrigation system.
3. Local Weather Forecast
Set your local weather forecast from sensors to realize intelligent watering.

APP PROGRAMMING

A. All Devices
Tap the **"All Devices"** and the devices you have connected. Tap to whether operation page of devices you have added to program the operation schedule of the device.
B. Room/Device Management
Tap the **"Room Management"** and **"Device"** module devices and edits these devices to different rooms for management and use.
Device Management is for removing the current smart device from the list.
C. Timer
There are **"Tap to-Run"** and **"Automation"** functions on the **"Device"** screen. You can automate multiple immersive products by setting conditions and tasks.
D. Me
Tap the **"Me"** to enter the **"Me"** screen.
On the **"Me"** screen, there are **"Message Center"** and **"FAQ & Feedback"** functions. You can check the device alarm message in the **"Message Center"** and you can get **"FAQ and Feedback"**.

APP PROGRAMMING SCREEN

Tap the water timer on the **All Devices** list on the APP home screen, **it will display all the programming screen of the timer** as the picture shown.

NOTES:
The Water timer will **ON** and perform the preset watering schedule after the application is programmed successfully, even if the phone or device.leaves.screen(icon).

APP PROGRAMMING

APP PROGRAMMING

Manual Watering

Manual Watering
The timer has the ability to allow you to manually water without interfering the programmed schedule. Manual is used to test equipment, run an extra watering cycle in an area, or to use the hose faucet without resetting the timer.
Tap the **"Manual"** button on the **"Device"** screen, the timer will also turn you dials at once. LED indicator in ON/OFF button **will** be on in green. Tap the **"Manual"** button to turn on in green color.

You can set how long you want your manual watering mode to run using the app. Go to **"Home"** screen > tap the **"Manual"** > tap the **"Watering Time"** > select the desired time > tap **"Confirm"**.

Stop Watering
You can stop the flow of water at any time, whether it is during manual watering, or during a programmed one.
Press the ON/OFF button or the **"Manual"** icon once to stop watering.

Rain Delay
The maximum runtime is 24 hours.

APP PROGRAMMING

For example:
The first picture below shows that the Bluetooth water timer **will** water for 10 minutes in Normal Schedule mode first, then **will** run/activate at 8:00 am.

APP PROGRAMMING

1. Normal Schedule Plan Setting
Normal Schedule: Water for a particular period in a day.
Tap the **"Watering Plan"** on the **"Device"** screen to enter the setting page.
Each watering plan can be set with different start time, duration and watering day.
Choose the "Sun, Tue and Sat" for the **"Mon"** to **"Sun"** in the **"Set Watering Day"** screen > tap the **"Confirm"** on the top right corner > tap the **"Add Timer"** > tap **"Confirm"** > tap **"Save"** to save the settings.

+ How to set up the watering plan?
1.Tap the **"+"** icon on the below screen of the APP. Then tap **"+"** icon choose the schedule type.
2.After the setting plan has been successfully created, Normal Schedule and Cycle&Soak.

NOTE:
These two modes do not refer to the difference in the water output of the timer, but the different settings of the watering frequency and duration.

Normal Schedule Mode: Watering at longer intervals
Cycle/Soak: Watering at shorter intervals

APP PROGRAMMING

2. Normal Schedule Plan Setting
Tap the common cycle duration period cannot exceed the total period.
For example:
1).The picture below right shows that Bluetooth water timer **will** water for 30 minutes every Monday, Tuesday, and Saturday at 8:00 am until ends at 8:30. The total period is Monday, Saturday at 8:00 am and ends at 8:30. The total period is 30 minutes.
2).The picture below right shows the starting date after tapping **"Next"**, because the 30 minutes total period ends at 8:30 am.

APP PROGRAMMING

3. Normal Schedule Plan Setting
Interval Schedule: Water for a particular period in a day.
Tap the **"Watering Plan"** on the **"Device"** screen to enter the setting page.
Each watering plan can be set with different start time, duration and watering day.
Choose the "Sun, Tue and Sat" for the **"Mon"** to **"Sun"** in the **"Set Watering Day"** screen > tap the **"Confirm"** on the top right corner > tap the **"Add Timer"** > tap **"Confirm"** > tap **"Save"** to save the settings.

APP PROGRAMMING

For example:
The first picture below shows that the Bluetooth water timer **will** be watering for 10 minutes every 2 hours in Cycle&Soak mode. The start time is every Monday, Tuesday, and Saturday at 8:00 am this time, the Cycle&Soak mode has not started and ends at 10:00 am. The total period is Monday, Saturday at 8:00 am and ends at 10:00.

APP PROGRAMMING

For example:
The first picture below shows that the Bluetooth water timer **will** be watering for 5 minutes every 2 hours in Cycle&Soak mode. The start time is every Monday, Tuesday, and Saturday at 8:00 am this time, the Normal Schedule mode has not started and ends at 10:00. The total period is Monday, Saturday at 8:00 am and ends at 10:00.

APP PROGRAMMING

Tips
1.There will be a time conflict notice when the schedules overlap, causing plans to fail to run properly.
2.The timer supports:
6x Normal Schedule mode time, then add Cycle&Soak mode.
3.The timer supports:
1). The picture below left shows that the Bluetooth water timer **will** be watering for 10 minutes every Monday, Tuesday, and Saturday at 8:00 am this time, the Normal Schedule mode has not started and ends at 10:00. The total period is Monday, Saturday at 8:00 am and ends at 10:00.
2). The picture below right shows that the Bluetooth water timer **will** be watering for 5 minutes every 2 hours in Cycle&Soak mode. The start time is every Monday, Tuesday, and Saturday at 8:00 am this time, the Normal Schedule mode has not started and ends at 10:00. The total period is Monday, Saturday at 8:00 am and ends at 10:00.

APP PROGRAMMING

The second situation
Set Cycle&Soak mode time, then add Normal Schedule mode.
For example:
The first picture below left shows that the Bluetooth water timer **will** be watering for 5 minutes every 2 hours in Cycle&Soak mode. The start time is every Monday, Tuesday, and Saturday at 8:00 am this time, the Cycle&Soak mode has not started. The Normal Schedule mode has not started and ends at 10:00. The total period is 8:00 am and ends at 10:00.
1. The picture below right shows that the Bluetooth water timer **will** be watering for 10 minutes every Monday, Tuesday, and Saturday at 10:30 in Normal Schedule mode. The start time is every Monday, Tuesday, and Saturday at 10:30 this time, the Normal Schedule mode is watering is successful. At this time, the Cycle&Soak mode has ended.

APP PROGRAMMING

1. Manual Rain Delay
Manual rain delay is to pause watering or when weather has caused high soil moisture. During the rain delay, the timer stops watering. After the rain delay ends, the timer will execute the next watering schedule. Rain delay can be set up to 24 hours or 48 hours.
Tap the **"Manual Rain Delay"** on the **"Device"** screen > tap the **"Set Delay"** > tap **"Confirm"** > tap **"Save"** to save the settings. Tap the **"Cancel Rain Delay"** to turn off the rain delay.

2. Rain Delay
Rain delay is to pause watering or when weather has caused high soil moisture. During the rain delay, the timer stops watering. After the rain delay ends, the timer will execute the next watering schedule. Rain delay can be set up to 24 hours or 48 hours.
Tap the **"Rain Delay"** on the **"Device"** screen > tap the **"Set Delay"** > tap **"Confirm"** > tap **"Save"** to save the settings. Tap the **"Cancel Rain Delay"** to turn off the rain delay.

3. Child Lock
Child lock is to prevent children from accidentally turning on the water timer.
Tap the **"Child Lock"** on the **"Device"** screen > tap the **"Confirm"** > tap **"Save"** to save the settings.

4. Sound
Tap the **"Sound"** on the **"Device"** screen > tap the **"Confirm"** > tap **"Save"** to save the settings.

5. Time Sync
Tap the **"Time Sync"** on the **"Device"** screen > tap the **"Confirm"** > tap **"Save"** to save the settings.

6. Restore Factory Settings
Tap the **"Restore Factory Settings"** on the **"Device"** screen > tap the **"Confirm"** > tap **"Save"** to save the settings.

7. Watering Events
Tap the **"Watering Events"** on the **"Device"** screen.

APP PROGRAMMING

2.2 Irrigation History
The Bluetooth water timer **will** record every irrigation plan **it**'s completed for you to track the implementation of each schedule.
Tap the **"Watering Events"** on the **"Device"** screen > tap on the **"All Device"** list > Go to **"Home"** screen > tap the **"Watering Events"** > tap **"Confirm"** > tap **"Save"** to save the settings.

APP PROGRAMMING

3.Setting
Click the **"..."** icon at the bottom of the home page to enter and set the Rain rate unit (L/MIN), temperature unit (**°C/°F**) and time system (24 hours/12 hours) as required.

APP PROGRAMMING

SMART AUTOMATION

Automation & Tap-to-Run

Tap **"+"** in Home screen > Automation or Tap-to-Run.

1. Automation: Devices can execute automatically according to the set conditions. It can be set with the days and time period.
For example, if you set the condition as the weather forecast information of your home location has rain as the conditions for automatic stopping or delaying the watering, the timer will be delayed for watering when it rains, or it will not start to turn on your faucet timer.

2. Tap-to-Run:Home you can control multiple devices and place with one tap.

APP PROGRAMMING

How to set Automation or Tap-to-Run?
Tap **"+"** > Tap **"Automation"** or **"Tap-to-Run"** > Tap **"Launch Tap-to-Run"** > Tap **"Add Task"** > Tap **"+"** > Save
Please remember to save all the settings. The device will automatically execute according to the settings.



The example of the last picture shows that when it rains it shortens the valve of the WiFi water timer will be automatically turns off.

APP PROGRAMMING

How to automatic TURN OFF timer on rainy?
Tap **"+"** > Tap **"Automation"** > Tap **"+"**
Tap **"Condition"** > Tap the home screen > **"Create Scene"** or **"If"** > When weather changes > Weather > Rainy > Next > Add Task > Run the device > Tap water timer icon > Next > Off > Save > Next > Select conditions > Save(Tap Ok)

APP PROGRAMMING

HOME MANAGEMENT

APP support adding family members and sharing your home device with them to co-management and system logistics together.

Tap **"Me"** > Home Management > My home > Add Members.

You could share your irrigation code with your families or friends via email/apps or Facebook.
And they could help you on taking care of your garden when unattended.

RESET THE DEVICE

How to reset the water timer?
1. Remove all batteries from the timer battery compartment.
2. After 10 seconds,Insert 2 fresh AA alkaline batteries.
3. Press and hold the ON/OFF button of the Bluetooth water timer for more than 5 seconds, LED light will blink, the water timer is now in pairing mode, and reconnect to the app. Please refer to the "Add Device" section for more detailed instructions.
4. Press and hold the ON/OFF button of the Bluetooth water timer for more than 10 seconds, LED light will blink, the water timer is now in factory reset mode, and reconnect. The device will be restored to the factory setting, and all data will be erased out. How to re-add the water timer device via APP again.

CLEAR CACHE

Regularly clearing the cache helps the App run better.
Tap **Me** > tap **⚙** > tap **Clear Cache**

DEVICE LED LIGHT

Hose Faucet Timer LED Light			
Light Color	Light State	Duration	Description
Green	Blink	Every 0.5 sec, for 1 min	Pairing mode, ready to connect to your smart device
Green	Blink	Every 0.5 sec, for 1 min	Press and hold on to the ON/OFF button for 10 seconds to reset
Green	Blink	Every 3 sec, for until watering done	Important to your smart device. Watering
Red	Blink	Every 3 sec	Low battery, turn water indication at 2.6V and valve shut off at 2.4V
Red	Blink	Every 3 sec	Power outage warning

TROUBLESHOOTING

Possible Problem	Check If	Solution
Water timer didn't start watering as preset time	Programming is correct	Set up a correct watering schedule
	Hose pressure is too low	Avoid and adjust for water county's line
	Any branches or water inlet screen are blocked	Regularly clean the filter part of water inlet screen and valve
	Manual/Rain delay parameters are set	Check that the manual/rain delay parameters is set or not
	Rain irrigation time is set	Check if the rain irrigation time parameter is set or not
	Manual watering is on	Turn off manual watering mode
	Low battery	Replace fresh batteries
	Pin faucet is off	Turn on the faucet
Faulty valve	Valve is damaged	Contact seller for assistance
Bluetooth keeps disconnecting or can't connect	Bluetooth in sleep mode	Wake over 5-10 seconds. The device will enter sleep mode after 5 minutes of no network. Re-APP home page > Me > Bluetooth > Bluetooth is on, and power and turn it on again
	Water Timer connected to another mobile phone	Please disconnect first, then reconnect
	Low battery	Replace fresh batteries
	Large distance from the water timer	Move to the irrigation timers when connected

BATTERY STATUS

Voltage	Battery Status	Operation
3V/2V	100%	Fully power
2.95V/1.48V-2.75V	90%	Timer working normal
2.90V/1.45V-2.72V	80%	Timer working normal
2.85V/1.43V-2.70V	70%	Timer working normal
2.75V/1.40V-2.67V	60%	Timer working normal
2.65V/1.38V-2.64V	50%	Timer working normal
2.57V/1.35V-2.62V	40%	Timer working normal
2.47V/1.33V-2.61V	30%	Timer working normal
2.35V/1.30V-2.42V	20%	Timer working normal
2.30V/1.28V-2.25V	10%	Low power,replace all batteries
Voltage < 2.3V	0%	The valve will close automatically to avoid damage.Replace all batteries

1. The low battery protection function prevents battery leakage.
2. The timer checks the battery voltage every 10 seconds.
3. When the battery voltage is < 2.3V, all operations return to normal.