


WOLFBOX

Dare to Go Everywhere®



TL2000 Telescopic Camping Light

User Manual

outdoor.wolfbox.com

The information in this manual is subject to change without notice.

V1.0

Safety Instructions & Warnings	2
Package Contents	3
Product Overview	4
Stand Setup Instructions	5
Button Instructions	6
Remote Control Buttons	8
Product Specifications	9
Customer Service Center	10


Safety Instructions & Warnings

Thank you for purchasing this product. Please read this manual carefully before use to understand the product functions and operating instructions.

For any product-related questions during use, please contact us.

- Make sure the battery is fully charged before use to avoid power loss during operation.
- Please recharge the product as soon as possible when the battery is low. Leaving the product unused for a long time at low battery may cause over-discharge and prevent normal charging.
- Do not rinse this product directly with water. To clean the product, wipe it with a clean dry cloth and store it in a cool, dry place.
- Do not disassemble or modify the product structure, as this may cause electric shock or fire.
- Do not charge the product when the charging port is wet or visibly damp. Keep the charging port dry to avoid electric shock.

Package Contents




• Camping Light Head




• Floor Stand



• Tabletop Stand



• USB-C to USB-C Charging Cable




• Remote Control




• Ground Stake*3



• Hook



• Stand Storage Bag




• Light Head Storage Bag



• User Manual

Product Overview

• Product Structure




• Battery Indicator


- 4 Solid lights: 76%–100% battery.
- 3 Solid lights: 51%–75% battery.
- 2 Solid lights: 26%–50% battery.
- 1 Solid light: 6%–25% battery.
- The first light flashes: below 6% battery.

Stand Setup Instructions



- Pull the stand legs away from the center pole, then rotate them downward.
- The stand can be extended up to 2.18m/7.15ft.



- Close the lock to secure the stand height.
- Open the lock to adjust the stand height.



- Rotate clockwise to tighten and secure.
- Rotate counterclockwise to loosen and adjust.



Caution:

When folding the stand for storage, keep your fingers clear of the hinges and moving parts to avoid pinching.

Button Instructions



Main Light Button

- Press and hold to turn the main light on or off.
- Short press to switch between colors/modes: Warm White → White → Warm Yellow → Red → Red SOS. The modes cycle in sequence.
- The light remembers the last mode used before it was turned off.
- Double press to switch between single-side lighting and full lighting.



Ambient Light Button

- Press and hold to turn the ambient light on or off.
- Short press to switch between colors:
Red → Green → Blue → Red + Green → Red + Blue
→ Blue + Green.
The colors cycle in sequence.
- The light remembers the last mode used before it was turned off.
- Double press to switch between steady light mode and breathing gradient mode.
- During breathing mode, short press to pause and keep the light at the current brightness level.



Increase Brightness

- Press and hold for continuous brightness increase.
- Short press to increase brightness by one level.
There are 5 brightness levels.




Decrease Brightness

- Press and hold for continuous brightness decrease.
- Short press to decrease brightness by one level.
There are 5 brightness levels.

Remote Control Buttons

The remote control can be attached to the clip on the stand base for convenient storage and easy access when the light is raised.



- | | |
|----------------------------------|---|
| 1 Main Light On/Off | 5 Increase Main Light Brightness |
| 2 Color Temperature Adjustment | 6 Ambient Light Color Switch |
| 3 Ambient Light On/Off | 7 Ambient Light Breathing Mode |
| 4 Decrease Main Light Brightness | 8 Single-Side/Dual-Side Main Light Switch |

Product Specifications

Product Name	Telescopic Camping Light
Model	TL2000
Input	5V / 3A
Brightness	Up to 2,000 lumens
Stand Weight	1.5 kg / 3.31 lb
Light Head Weight	541 g / 1.19 lb
Material	PC + Aluminum Heat Sink
Battery Capacity	49.58 Wh (13400mAh @ 3.7V)
Folded Stand Length	55 cm / 21.65 in
Total Height with Light Head	2.32 m / 7.61 ft
Extended Stand Height	2.18 m / 7.15 ft

Note:

When the product is used at maximum brightness, the brightness may automatically decrease if the battery level is low. This is designed to reduce power consumption and protect the product.

Customer Service Center

If you have any problems with the function or installation, please contact us with any questions.



Help Center



For more information:

✉ outdoor@wolfbox.com

🌐 outdoor.wolfbox.com

☎ +1 866 965 3070

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment, This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The device can be used in portable exposure conditions without restriction.

WOLFBOX

Dare to Go Everywhere®

Check us out here!
Product and service are the foundation of WOLFBOX.

Email: outdoor@wolfbox.com
Phone: +1 866 965 3070



outdoor.wolfbox.com