

WIRELESS OPEN-EAR HEADPHONES USER MANUAL

TONEMAC Q1

Welcome!

TONEMAC offers 12 months of global manufacturer's warranty and 90 days refund policy to make sure that every customer can buy without worry.

If you have any questions about our products or services, please feel free to contact us via the following email: Supports@TONEMAC.com.cn (Please send in your buying details which included the shop name, order ID, and address, etc.)

@2023 TONEMAC Tech. Co., Ltd. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission.

Printed in China

WARNING FOR HEADPHONES

For safe and correct use of earphones, read this manual before use. Keep the manual and safety information in a convenient place for future reference.

IMPORTANT SAFETY PRECAUTIONS

Before using this product, please read and save the enclosed warnings and safety instructions.

The possible results of incorrect use are marked by one of the two symbols— "WARNING" and "CAUTION"—depending on the imminence of the danger and the severity of the damage.

1. **WARNING** -Ignoring these warnings may cause severe injury or death as a result of an incorrect operation
2. **CAUTION** -Ignoring these cautions may cause moderate injury or property damage as a result of incorrect operation.

WARNING

Listening to audio at excessive volumes can cause permanent hearing damage, Overexposure to excessive sound levels can damage your ears resulting in permanent noise-induced hearing loss (NIHL). Please use the following guidelines established by the Occupational Safety Health Administration (OSHA) on maximum time exposure to sound pressure levels before hearing damage occurs.

90 dB SPL: at 8 hours	95 dB SPL: at 4 hours	100 dB SPL: at 2 hours
105 dB SPL: at 1 hour	110 dB SPL: at 30 min	115 dB SPL: at 15 min
120 dB SPL: Avoid or damage may occur		

- Focus on your safety and that of others if you use the headphones while engaging in any activity requiring your attention, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad, etc. Remove the headphones or adjust your volume to ensure you can hear surrounding sounds, including alarms and warning signals.

- Use caution and follow applicable laws regarding mobile phone and headphone use if using headphones for phone calls while driving. Some jurisdictions impose specific limitations on using such products while driving. DON'T use the headphones for any other purpose while driving.

- Keep this product and its accessories out of reach of children under age 3. Handling or using by children may pose a risk of death or serious injury. Contains small parts and cords that may pose the risk of choking or strangulation.

- Do not place any naked flame sources on or near the headphones, such as lighted candles.

CAUTION

- Do not attempt to modify this product. Doing so could result in personal injury and/or product failure.

- Do not drop, sit on or allow the headphones to be immersed in water, otherwise, the headphone's failures may result.

- Do not be subject to extreme force and do not pull on the cable or failures may result.

- Keep dry and avoid exposure to extreme temperatures and humidity.

- Stop using the earphones immediately if they are causing great discomfort, irritation, rash, discharge, or any other uncomfortable reaction.

- If you are currently receiving ear treatment, consult your physician before using this device.

INTRODUCING TONEMAC M3

Charging Case x1

Open-Ear Wireless Earbuds x2

USB-C Charging Cable x1

MFB Button

Left Earbud

Right Earbud

Indicator Light

USB-C Charging Port

POWER ON & PAIRING

Open the charging case, the earbuds will automatically power on and enter Bluetooth pairing mode. Choose "TONEMAC Q1" from your device's Bluetooth list when connecting for the first time.

CHARGING

- Fully dry off the earbuds and the USB port before charging.
- Use a certified USB-C charging cable and charger to prevent any damage.
- Fully charge the earbuds and the charging case before the first use.

1. Place the earbuds in the charging case and close it.
2. Connect the charging case to the power by using a USB-C charging cable.

- The LED indicators on the charging case indicate the charging status.

Blinking: Charging Keep Lighting: Full Charge

WEARING

Choose the ear tips that fit your ears best.

Insert the earbuds into the inner canal of your ears and turn gently until you find the most comfortable and secure position.

- Your earbuds come with multiple pairs of Ear Tips, among which Medium-sized are pre-installed.

CONTROLS

Playback Actions	
Play / Pause:	Click the MFB button once
Per. Track:	Triple-click the MFB button
Next Track:	Double-click the MFB button
Phone Call Actions	
Answer / End a Call:	Click the MFB button once
Decline a Call:	Press and hold the MFB button for 2 seconds
Device Actions	
Power on	Press and hold MFB button for 1 second
Power off:	Press and hold MFB button for 5 seconds

SPECIFICATIONS

Model	TONEMAC Q1
Bluetooth Version	5.2
Bluetooth Profile	HSP / HFP / A2DP / AVRCP / SPP / GATT
Audio Codec Format	SBC / AAC
Bluetooth Range	10 m (33 ft)
Battery Capacity	70 mAh x2 (earbuds) 400 mAh (charging case)
Playing Time	Up to 10 hours (Total 30 hours with the charging case)
Charging Time	1 hour
Driver Size	16.2 mm
Latency	38 ms on Game Mode

Limited Warranty

TONEMAC Technology Co., Ltd (“TONEMAC”) warrants this product against defects in material or workmanship for the periods and as set forth below when purchased directly from TONEMAC or TONEMAC Retailer. Under this Limited Warranty, TONEMAC will, at its option, (i) repair the product using new or refurbished parts or (ii) replace the product with a new or refurbished product. For purposes of this Limited Warranty, “refurbished” means a product or part that has been returned to its original specifications. In the event of a defect, these are your exclusive remedies.

For 1 year from the original date of purchase of the product (“Labor Warranty”), TONEMAC will, at its option, repair or replace with a new or refurbished product, the product determined to be

defective.

This warranty is not transferable. This warranty does not apply in cases of abuse or misuse of the product, use contrary to TONEMAC's instruction, ordinary wear, and tear, an act of God, negligent use, purchase from a party other than TONEMAC or a TONEMAC-authorized reseller, unauthorized repair, or modification of the product.

ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED TO THE EXTENT PERMITTED UNDER APPLICABLE LAWS AND, TO THE EXTENT NOT PERMITTED, ARE HEREBY LIMITED TO THE DURATION AND TERMS OF THIS WARRANTY. TONEMAC ALSO HEREBY DISCLAIMS ALL LIABILITY FOR INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

This warranty does not restrict the rights of the consumer mandated under applicable laws.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

CE

TONEMAC hereby declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU and all other applicable EU directive requirements.