SKU	
型号+产品名称+文件名称	C40 蓝牙UV长条灯 说明书 Atfoyer
尺寸(长x宽x高)mm	展开尺寸：770 X 130mm 折后尺寸110 X 130mm
材质	80G书写纸 四色印刷 正反面印刷 风琴折
料号	A330C402Z01
版本号	Z01

包装	电子	结构	确认人	审核人
林利诚				
日期：2022.9.19	日期：	日期：	日期：	日期：

Atfoyer®

LED LIGHT

Product Manual

MODEL: ATC40CTBL

SAFETY INFORMATIONS

Disconnect the power supply before attempting any work on the unit!
•Installing these units involves work on the mains voltage supply; installation must therefore be carried out professionally in accordance with the appliance national wiring regulations and electrical operating conditions.
•The product must be installed by a licensed professional electrician.
•Check all components for damage, do not use the product if it is damaged.
•To ensure the product can work normally, please use it in the voltage within the range on the lamp label.
•The floodlight enclosure heats up when the light is on.Please adjust the angle of the light after the power off for 10-15 minutes. Do not look into the LED light at a short range or any prolonged period (>5 min).
•Do not install the unit on (normally) flammable surfaces.
•Do not alter or change parts of the light at will, in case of the accidents such as breakage, fall, electric shock, fire, etc.
•To reduce the risk of strangulation the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach
•The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
•Never plug the light in with wet hands in case of electric shock.
•This light is a non-dimmable product. To avoid failure, please don't connect it with the dimming controller
•Do not connect this light fixture to an ungrounded electrical system.
WARNING: Installing this light in an ungrounded electrical system may cause the metal parts of the light to carry current.If any wires or wire connections are damaged or loose. In this case, anyone who touches the light will receive an electric shock, resulting in injury or death.
•Be careful not to damage or cut the wire insulation (covering) during installation. Do not let the wires touch any sharp edges.
•For type Z attachments:
This external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.

COMPONENTS AND STRUCTURE

ATC40CTBL



1. Tempered Glass Lid
2. LED Light Source
3. Lamp Bracket

2x18AWG (US) 1.5mm(4.92ft)

PARTS LIST

A Screw QTY: 2

B Machine Screw QTY: 2

C Expansion Rubber Plug QTY: 2

D Lamp Brackets QTY: 2

E Hex Screw Key QTY: 1

SPECIFICATIONS

LED FLOODLIGHT	
Model	ATC40CTBL
Input Voltage	100-125V ~ 60Hz
Input Current	0.32A
Rated Power	40W
Wavelength	385-400nm
Power Factor	≥0.9
Chromaticity coordinate	x=0.1763 y=0.0317
CRI	-1.9
Beam Angle	120°
t_a	-20-40°C/-4°F-104°F
Luminaire Location	DRY LOCATIONS ONLY
DIMENSIONS	
Model	ATC40CTBL
Dimensions（LxHxW）	394 x 40 x 56 mm / 15.51 x 1.57 x 2.2 in
Weight	0.56 kg / 1.23 lb
Max Projected Area	0.0255 m² / 0.2744 sq.ft

Note:
The intended purpose of this special purpose product:This light is used to create atmosphere. It is not suitable for household room illumination, the light source is not intended for use in other applications.



APP INSTALLATIONS

STEP 1

1. Please scan the QR code.
2. Search for " Trick Light" in the Apple Store or Google Play.
3. Download and install the App, as shown in the picture.



STEP 2

Note:

- **Before using the app, please make sure that the Bluetooth of your mobile phone is enabled.**
- Unable to connect to Bluetooth:
  After you open the app and select the color, the color doesn't change on the flood light. it means that the Bluetooth fails to connect. The light might has been connected to the other phone.
  1. You need to disconnect the Bluetooth of the other phone, and then your phone will be automatically connected to the light. At this time, when you turn on the Bluetooth, it will show that the device Trick-JOOOI is conne ted, which means that the Bluetooth is connected now.
  2. Open the APP and place the phone near the light, it will be connected to the nearest Bluetooth without blocking, after the light is turned off and turned on again.

APP OPERATING INSTRUCTIONS



Brightness Selection Interface:
You could adjust the brightness.

Music Mode Interface:
You could control the brightness and dynamic changes of the light by playing local music in the phone.

APP OPERATING INSTRUCTIONS



Dynamic Mode Interface:
The light has 5 dynamic modes (Gradient, Breathing, Strobe, Jump, Auto), and speed can be adjusted.

Mobile Speaker:
The dynamic modes can change with the sound inside the phone or other external sounds.

APP OPERATING INSTRUCTIONS

Timing Interface:
You can turn on or turn off the light regularly.

HOW TO CONTROL LIGHTS IN GROUPS

If you use the app to connect 2 or more lights, the app will default , these lights as a group, and you can control these lights at the same time.



If you want to control one of the lights separately, select the light first and then control it.

PREPARATION

Check all components for damage, do not use the product if it is damaged.
Estimated Assembly Time:10-30 minutes

TOOLS REQUIRED（not included）

Flathead screwdriver | Screwdriver | Electric drill | Eye Protection | Pliers | Step Ladder

WARNING:

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
RISK OF SHOCK- BEFORE BEGINNING INSTALLATION,TURN OFF ELECTRICITY AT THE CIRCUIT BREAKER BOX OR THE MAIN FUSE BOX.

CAUTION:

PLEASE MAKE SURE YOUR WALL SWITCH AND POWER AT MAIN CIRCUIT BREAKER BOTH ARE OFF.

IF IN DOUBT ABOUT ELECTRICAL INSTALLATION, CONSULT A LICENSED ELECTRICIAN.

WARNING: INSTALLING THIS LIGHT IN AN UNGROUNDED ELECTRICAL SYSTEM MAY CAUSE THE METAL PARTS OF THE LIGHT TO CARRY CURRENT IF ANY WIRES OR WIRE CONNECTIONS ARE DAMAGED OR LOOSE. IN THIS CASE, ANYONE WHO TOUCHES THE LIGHT WILL RECEIVE AN ELECTRIC SHOCK, RESULTING IN INJURY OR DEATH.

BE CAREFUL NOT TO DAMAGE OR CUT THE WIRE INSULATION (COVERING) DURING INSTALLATION. DO NOT LET THE WIRES TOUCH ANY SHARP EDGES.

INSTALLATION STEPS

Product appearance may vary from image shown.



STEP 1:
Fix the bracket on the lamp with the combination screw. (as shown in the image)
STEP 2:
According to the spacing (see the "F" part of the picture) of two holes on the lamp brackets, drill two mounting holes. (as shown in the image)
STEP 3:
Put the brackets onto the prepared mounting holes and then screw them on.
STEP 4:
Adjust the beam direction as you like, and then plug into the main socket.

FCC ID: 2A6YR-ATC40CTBL

FCC Statement:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Manufacturer/Hersteller: Brightech-Lighting Inc.
50 COMMERCIAL ST PLAINVIEW NY 11803
www.brightechlite.com

Made in China