

C03 自拍杆

使用说明

各部分说明

可分离手机夹

调节锁

不锈钢杆

遥控器

三脚架

取出遥控器

使用遥控器

开关键:  
↑上推开机 ↓下推关机

拍照键:  
单击拍照/录视频

连接遥控器

初次连接:  
开启遥控器,  
指示灯闪烁进入配对状态,  
手机搜索“Selfie”匹配,  
配对成功后,指示灯熄灭。

在未连接状态下:  
5分钟无操作自动关机  
(重复拨动开关键开机)

自动连接:  
开机可自动连接已配对手机。

可拆手机夹

安装手机

利用手机推动  
夹子后固定

拆卸手机夹

将手机旋转至  
竖屏后向上取出

手机支架

打开手机夹

手机支架

使用三脚架

1

2

3

4

调节自拍杆

360°

225°

↑

↓

规格

|       |             |
|-------|-------------|
| 自拍器型号 | C03         |
| 材料    | ABS+不锈钢     |
| 折叠长度  | 196mm       |
| 总长度   | 1075mm      |
| 尺寸    | 196x52x37mm |
| 产品重量  | 162g        |
| 电池    | CR2032(可更换) |

(电池不得暴露于诸如日照、火烤或类似过热环境中)

提醒

·遥控器兼容  
Android 4.4以上 iOS 5.1以上

·Android设备设置  
如果你在相机选项下改变了你的  
“音量键功能”，请把它改为“默认”或者  
“拍照”，让遥控器正常工作。

感谢您的支持!

CE

FC

RoHS

C03 Selfie Stick

User Manual

Part Description

Detachable  
Phone Clip

Adjustable Lock

Stainless Steel Rod

Remote Control

Tripod

Remote Control

Take out the remote control

Use the remote control

Power Key:  
↑ Push up to turn on  
↓ Push down to turn off

Button:  
Click to shoot  
photo/video

Connect Your Phone

First time connection:  
Turn on the remote control and  
the light flashes to enter the  
pairing state. Search "Selfie"  
with your phone to match, after  
successful pairing, the indicator  
light will turn off.

In the unconnected state:  
No operation of the remote control for 5 mins,  
it will automatically shut down.  
(Repeatedly toggle the power key to turn on)

Automatic connection:  
Turning on the remote control automatically  
connects the paired phone.

Detachable Phone Clip

Clip the phone

Use the phone to  
push the clip to  
clamp the phone

Remove the phone clip

Turn the phone selection  
to vertical screen  
and remove it upwards

Phone Holder

Open the phone clip

Phone holder

Use the Tripod

1

2

3

4

Adjust the Selfie Stick

360°

225°

↑

↓

Specification

|                 |                     |
|-----------------|---------------------|
| Remote Model    | C03                 |
| Main Material   | ABS+Stainless Steel |
| Folded Length   | 196mm               |
| Extended Length | 1075mm              |
| Product Size    | 196x52x37mm         |
| Product Weight  | 162g                |
| Battery         | CR2032(Replaceable) |

(the Battery must not be exposed to sunlight, fire or  
similar overheating environments.)

Remind

·Remote control compatibility:  
Android 4.4 or above, iOS 5.1 or above

·Android devices settings:  
If you change your "volume key function" on  
the camera, be sure to change it to the "default  
value" or "Shooting". Getting the remote  
control to work.

Thank you for your support!

CE

FC

RoHS

FCC Statement

RF Exposure Information

The device has been evaluated to meet general RF  
exposure requirement.The device can be used in  
portable exposure condition without restriction.