

Operation method

Ready to boot
1. Insert TF card of burned program
2. Use 5 V2A of power to charge the machine, about 5 hours 2.. If it's a 5 V2A power charge, it'll be longer


Switchgear operation
1. boot - press power button for 2 seconds
2. Shutdown - Press Power Key to Shutdown or Press SELECT to Select Shutdown and Restart
Press "Power" for 7 seconds - Force shutdown

Game operation
When entering the desktop, the direction key is left and right - select the simulator, press the A key to enter the game directory, the direction key up and down select the game program, press the L/R2 to change the simulator, press the A key to start the game
Press the SELECT START to exit the game, SELECT up and down = volume adjustment

Functional operations
Luminance Adjustment - Press "START" Select "System Settings" -> "BRIGHTNESS" to adjust
Audio Adjustment - Press "START" Select - Sound Settings - System Volume

If technical and system updates may lead to operational changes, without prior notice!

RGB 10 MAX II 说明书



機能の説明
SELECT=START=ゲームを終了します / SELECT=UP/DOWN=音量調節
SELECT=L1=L2=ゲームスタート/ゲームの設定画面
SELECT=L1=LEFT/RIGHT=ゲーム機モード切替
SELECT=L3=L3-R2=システムに入る / SELECT=B=ゲームリセット
WiFi-定期的に機能停止状態にあります。使用が必要なら、手動で開く必要があります。
WiFiを同時に開くとマシンの稼働時間が短くなります。

操作方法

電源投入前の準備
1.焼き上がったプログラムを挿入したTFカード
2.5V2Aの電源を使用して自機を充電して、約2.5時間。5V1Aの電源の場合充電時間が長くなります

オン/オフ操作
1.電源を入れ、電源キーを2秒間長押しするとシステムに入る
2.シャットダウン-電源キーを押してシャットダウンするか、SELECTを押してシャットダウンと再起動を選択
電源キーを7秒間長押しします（強制的にシャットダウンします）。

ゲーム操作
進入机面後、方向鍵左右-選択シミュレータ。押A鍵进入游戏目录、方向键上下-選択游戏番組、押L1/R2 变换模拟器、押A键开始游戏
同時に SELECT START を押すとゲームを終了し、SELECT 方向上下=ボリュームサイズ調整

きのうそうき
明るさの調整-START キーを押してシステム設定を選択し-BRIGHTNESS キーを押して調整
サウンド調整-START キーを押して選択-サウンド設定-システムボリューム

技術やシステムのアップデートがあった場合、予告なしに動作が変更されることがあります！

Operation method

Ready to boot
1. Insert TF card of burned program
2. Use 5 V2A of power to charge the machine, about 5 hours 2.. If it's a 5 V2A power charge, it'll be longer


Switchgear operation
1. boot - press power button for 2 seconds
2. Shutdown - Press Power Key to Shutdown or Press SELECT to Select Shutdown and Restart
Press "Power" for 7 seconds - Force shutdown

Game operation
When entering the desktop, the direction key is left and right - select the simulator, press the A key to enter the game directory, the direction key up and down select the game program, press the L/R2 to change the simulator, press the A key to start the game
Press the SELECT START to exit the game, SELECT up and down = volume adjustment

Functional operations
Luminance Adjustment - Press "START" Select "System Settings" -> "BRIGHTNESS" to adjust
Audio Adjustment - Press "START" Select - Sound Settings - System Volume

If technical and system updates may lead to operational changes, without prior notice!

RGB 10 MAX II 说明书



機能の説明
SELECT=START=ゲームを終了します / SELECT=UP/DOWN=音量調節
SELECT=L1=L2=ゲームスタート/ゲームの設定画面
SELECT=L1=LEFT/RIGHT=ゲーム機モード切替
SELECT=L3=L3-R2=システムに入る / SELECT=B=ゲームリセット
WiFi-定期的に機能停止状態にあります。使用が必要なら、手動で開く必要があります。
WiFiを同時に開くとマシンの稼働時間が短くなります。

操作方法

電源投入前の準備
1.焼き上がったプログラムを挿入したTFカード
2.5V2Aの電源を使用して自機を充電して、約2.5時間。5V1Aの電源の場合充電時間が長くなります

オン/オフ操作
1.電源を入れ、電源キーを2秒間長押しするとシステムに入る
2.シャットダウン-電源キーを押してシャットダウンするか、SELECTを押してシャットダウンと再起動を選択
電源キーを7秒間長押しします（強制的にシャットダウンします）。

ゲーム操作
進入机面後、方向鍵左右-選択シミュレータ。押A鍵进入游戏目录、方向键上下-選択游戏番組、押L1/R2 变换模拟器、押A键开始游戏
同時に SELECT START を押すとゲームを終了し、SELECT 方向上下=ボリュームサイズ調整

きのうそうき
明るさの調整-START キーを押してシステム設定を選択し-BRIGHTNESS キーを押して調整
サウンド調整-START キーを押して選択-サウンド設定-システムボリューム

技術やシステムのアップデートがあった場合、予告なしに動作が変更されることがあります！

RGB 10 MAX II 说明书



如有技术和系统更新可能导至操作有变,恕不另行通知

操作方法

开机前准备
1.插入烧好的程序的TF卡
2.使用 5V2A 的电源对本机进行充电，大约 2.5 小时。如果是 5V1A 的电源充电时间会延长
开关机操作
1.开机-长按“电源键”2 秒可进系统
2.关机-按“电源键”可关机 也可以按“SELECT” 选择关机和重启
长按“电源键”7 秒-强制关机
游戏操作
进入桌面后,方向键左右-选择模拟器,按 A 键进入游戏目录,方向键上下-选择游戏节目,按 L1/R2 变换模拟器,按 A 键开始游戏
同时按 SELECT+START 可退出游戏,SELECT+方向上下=音量大小调节
功能操作
亮度调节-按“START” 选择“系统设置”-“BRIGHTNESS” 进行调节
声音调节-按“START”选择- 声音设置-系统音量

如有技术和系统更新可能导至操作有变,恕不另行通知

RGB10 MAX II Instruction



如有技术和系统更新可能导至操作有变,恕不另行通知

RGB 10 MAX II 说明书



如有技术和系统更新可能导至操作有变,恕不另行通知

操作方法

开机前准备
1.插入烧好的程序的TF卡
2.使用 5V2A 的电源对本机进行充电，大约 2.5 小时。如果是 5V1A 的电源充电时间会延长
开关机操作
1.开机-长按“电源键”2 秒可进系统
2.关机-按“电源键”可关机 也可以按“SELECT” 选择关机和重启
长按“电源键”7 秒-强制关机
游戏操作
进入桌面后,方向键左右-选择模拟器,按 A 键进入游戏目录,方向键上下-选择游戏节目,按 L1/R2 变换模拟器,按 A 键开始游戏
同时按 SELECT+START 可退出游戏,SELECT+方向上下=音量大小调节
功能操作
亮度调节-按“START” 选择“系统设置”-“BRIGHTNESS” 进行调节
声音调节-按“START”选择- 声音设置-系统音量

如有技术和系统更新可能导至操作有变,恕不另行通知

RGB10 MAX II Instruction



如有技术和系统更新可能导至操作有变,恕不另行通知

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction