

CUSHION 98

Tri-Mode 98 Keyboard with Nest-Mount Design



User Manual

English	1
Ducky Cushion Specs	1
Ducky Cushion Main Layer	2
Ducky Cushion Fn Layer	3
Ducky Cushion Fn Function	4
Ducky Cushion Connection Function	5
Ducky Software	6
Warning	7

Ducky Cushion

English


Model: Cushion 98 Wireless keyboard

- Type : Mechanical Keyboard
- Switch : Mechanical switches
- Keycap Material : PBT
- Printing Method: Double-Shot or Dye-Sublimation
- Origin Of Production: China

98 Layout


- Size : 385 x 147.8 x 41.6 mm
- Weight : 1216g

For more information on the specs and details of our keyboards, please contact the distributor for your region.



Main Layer


Keyboard configuration diagram, US layout used as example



Note : Detailed functions may be modified through Ducky Hub.

Fn Layer

Keyboard configuration diagram, US layout used as example



Note : Detailed functions may be modified through Ducky Hub.

Fn Function

Fn +	F7	=	Previous playlist
	F8		Next playlist
	F9		Play/Pause
	F10		Mute
	F11		Volume down
	F12		Volume up
	Ins		Decrease Screen Brightness
	Del		Increase Screen Brightness
	1!		Profile 1
	2@		Profile 2
	3#		Profile 3
	Backspace		Function Toggle
	P		PrtSc
	[{		ScrLk
	]}		Fn Lock
	Q		BT1 device
	W		BT2 device
	E		BT3 device
	R		BT4 device
	Enter		Minimize all windows and mute audio
	B		Hold to see battery status
	Left Win		Enable / Disable Left Windows Key Function
	Right Shift		Switch between profiles 1 and 2

- Hold to see battery status (1 lights up = 10%, 1+2 lights up = 20%, etc.)
- Hold both Win keys for five seconds for factory reset.
- Fn + 1!/2@/3# allows you to toggle between Profile 1 to Profile 3.

Wireless 2.4G pairing method

After pressing and holding Fn+T for 5 seconds, the T light will flash faster. Re-plug and unplug the 2.4G receiver for pairing. After successful pairing, T will remain on.

Connection Function

Wired mode

- Switch the connection mode selector to the  mode
- Connect the keyboard to a PC using the included Type-C® cable


2.4 GHz mode

- Switch the connection mode selector to the  mode
- Connect the included 2.4 GHz wireless dongle to a PC

BT mode

- Switch the connection mode selector to the **BT** mode
- Press Fn + Q/W/E/R to select the desired pairing host
- Press and hold FN + Q/W/E/R for three seconds to start pairing
- Turn on the BT connection on the device
- Follow the pairing instruction on the device
- Enter the pairing passkey on the keyboard when prompted

Ducky Software



Note : For customization, please access the customization software at <http://duckyhub.io>

Warning

FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:


- (1) this device may not cause harmful interference and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by Ducky void the user's authority to operate the equipment and could void the warranty.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



the power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 5 Watts in order to achieve the maximum charging speed



Ducky global

CUSHION 98

Tri-Mode 98 Keyboard with Nest-Mount Design



<https://ducky.global>