

Ducky OK-M 98 / 75 / 65

1.Specification:

Ducky OK-M-98 Wireless

- Size: 394 x 143 x 41.5 mm
- Weight: 1120g
- PBT Double - shot keycap
- Made in China
- case: Plastic ABS

Ducky OK-M-75 Wireless

- Size: 337 x 142 x 43.2 mm
- Weight: 880g
- PBT Double - shot keycap
- Made in China
- case: Plastic ABS

Ducky OK-M-65 Wireless

- Size: 336 x 119 x 40.8 mm
- Weight: 705g
- PBT Double - shot keycap
- Made in China
- case: Plastic ABS

Input: 5Vdc 1000mA.

Battery: 3.7Vdc, 4000mAh for OK-M-75 and OK-M-98;

3.7Vdc, 2000mAh for OK-M-65

2.Package Contents:

keyboard/dongle/USB cable/key puller/Ducky brush

3.Safety and Electrical Safety Instructions for Keyboards

- 1.Read the Manual: Carefully read and follow the instructions in this manual before using the keyboard to ensure proper use and safety.
- 2.Proper Use: Use the keyboard only as intended by the manufacturer. Improper use can lead to injury, damage, or malfunction.
- 3.Do Not Open or Modify: Do not attempt to open or modify the keyboard. Internal components may carry an electric charge even when the device is turned off. Repairs should only be conducted by qualified personnel.
- 4.Keep Away from Children: Ensure that the keyboard is kept out of the reach of children. Small parts may pose a choking hazard.
- 5.Avoid Moisture: Keep the keyboard away from water and other liquids to prevent electrical short circuits or damage. Do not use the keyboard in damp or wet environments.
- 6.Avoid Heat Exposure: Do not place the keyboard near heat sources or in direct sunlight to avoid overheating.
- 7.Proper Power Supply: For wired keyboards, ensure the keyboard is connected to the correct power source as specified by the manufacturer.

4 .Instruction:

Connect the keyboard with the included cable, and the device will be automatically installed and can be used afterwards.

Wired mode:

Switch the connection mode selection switch to  mode,

Connect the keyboard to the PC using the included Type-C® cable.

2.4GHz mode:

Switch the connection mode selection switch to the 2.4G mode,

Connect the attached 2.4 GHz wireless dongle to the PC.


Bluetooth mode:

Switch the connection mode selection switch to mode,

Select the desired paired host by pressing Fn + 1/2/3.

- Press and hold Fn + 1/2/3 for three seconds to start pairing.
- Turn on the BT connection on the device.
- Please follow the pairing instructions on the device.

- When prompted, enter the pairing key on the keyboard.




FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



<https://ducky.global>



Ducky global



FR

**Cet appareil
se recycle**

REPRISE
À LA LIVRAISON



À DÉPOSER
EN MAGASIN



À DÉPOSER
EN DÉCHÈTERIE



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !