















T12 PRO 说明书

尺寸：70*80 mm

材质：100g铜板纸

印刷工艺：正反面印刷

折叠方式：装订册子

T12 Pro  English User Manual T12 Pro Wireless Earbuds 1	User Manual Thank you for purchasing our bluetooth earbuds T12 Pro. Please review this manual thoroughly before operating your device. Package Content 1. T12 Pro Wireless earbuds -----1 Set 2. Charging case -----1 Set 3. USB cable -----1 pcs 4. User manual -----1 pcs  Earbuds Charging Case  USB Cable User Manual 2	Product Diagram  Multifunction Button LED Light Microphone Charging Pin  Charging Pin Charging Port Reset Button How to wear Please place the earbuds into the cochlea gently, and adjust them to a suitable angle.  3	Power on Method 1: Both earbuds powered on and will be connected to each other automatically as soon as the charging case is opened. Take out both earbuds, the master earbud will be flashing red and blue LED light alternatively. (By default factory setting, the left earbud is the master earbud.) Method 2: If your charging case is running out of battery, or earbuds are not in the case. Long press the multifunctional button on both earbuds for about 2 seconds to power them on. The master earbud will be flashing red and blue LED light alternatively. (By default factory setting, the left earbud is the master earbud.) 4	Pairing Use Method 1 or 2 to pair up the device if you are using it for the first time. Turn on the earbuds and the Bluetooth function on your electronic device, search and choose for "T12 Pro". When it shows "connected", it means it is connected successfully. After connecting it for the first time, the earbuds will automatically connect with the device the next time you turn them on. The earbuds will recognize the latest device it is connected to. If the latest device is not nearby, the earbuds will turn into a searching mode (red and blue light flashing alternatively). Notice 1. Pairing mode will only last for 5mins at most, the earbuds will power off after that if they are not paired. You need to redo the previous steps again to connect the earbuds with your electronic devices. 2. The connection will be lost if the earbuds are out of the range of the electronic device. It will be reconnected if both devices are within the detectable range in 5 minutes. 5	Power off Method 1: Simply just put the earbuds back into the charging case and close it, then the earbuds will be powered off automatically. (The earbuds will not power off automatically if the charging case is out of battery) Method 2: Long press the multifunctional button for 5 seconds, the red light flashes three times, and the earbuds are powered off. (Note: If the earbud is left unpaired for 5 minutes, the earbud will automatically turn off.) Answer a call Press the multifunctional button once to answer a call. Ending a call Press the multifunctional button once to end a call. Rejecting a call Double-click either side of the left and right ears and refuse to answer when calling. 6	Call switching mode During the call, double-click either side of the left and right earbuds to switch between the two calls. One-Key Siri Under standby or music playing mode, double-tap the multifunctional button to activate siri. (This feature is only available for IOS system devices). Music playing 1. Play/Pause: Press the multifunctional button to start or pause the music. 2. Previous song: Press the left earbud for 2 seconds to go back to the previous song. 3. Next song: Press the right earbud for 2 seconds for the next song. (In mono mode press any one of the earbud for 2 seconds for the next song.)  7
4. Mono mode: only can skip to the next song. 5. Auto Play: Once you finished your phone call, the music will be back on automatically. Wireless Charging Supported We recommend you use a wireless charging pad (not included).  8	Charging the earbuds When the earbuds are on low battery, there is a voice prompt to remind you to put the earbuds back into the case for charging. The red light is on when the earbuds are charging. The red light will turn off when the earbuds are fully charged.  9	Mono Mode 1. For mono mode, make sure only one earbud is turned on before connecting to an electronic device. 2. When connecting to a known device, turn on the earbud by pressing the multifunctional button for 2 seconds and it will reconnect to the device automatically. 3. When playing music in mono mode, the multifunctional button only allows you to switch to the next song. 4. When connecting to a new device, press the multifunctional button for about 5 seconds to enter pairing mode, then select "connect" in the Bluetooth setting.  10	Reset Setting When the earbuds is in the charging case, press and hold the charging case for 5 seconds, digital screen lights up for 2 seconds, then the earbuds are reset.  Active-Standby Mode 1. The earbud can work independently; you do not need to connect both earbuds with your mobile phone to get them to work. If you are using one earbud and would like to connect another earbud, simply just take the remaining earbud out of the case. 2. When the master earbud (default left) is out of battery or is not placed in the charging case, the right earbud will change to the master earbud.  11	Technical Solution If you have issues pairing the earbuds with your electronic devices, please try the following steps: First: Make sure the earbuds are fully charged, are powered on, and are not paired with other devices; the mobile phone Bluetooth function is enabled and is on, within the range of distance between the earbuds and your mobile phone. If the above steps do not solve the problem, please try to reset it. When the earbuds is not paired with the device, first hold down the earbuds for 5 seconds to power off, then hold down the left and right earbuds for 10 seconds at the same time to reset the earbuds and clear the pairing with the phone, and finally hold down the earbuds for 5 seconds to start up, and the earbuds can be paired with the new device.  12	Product Specification Model: T12 Pro Earbuds size: 45.6*17.6*18.5mm Charging case size: 60*26*49mm Transmission distance: 10 meters Input voltage: DC 5V Earbuds battery capacity: 3.7V/45mAh Charging case battery capacity: 3.7V/400mAh Working time: 8 hours Charging case charging time: About 1.5 hours IOS battery status: Support 13	Safety Criterion 1. Please follow the instruction of the user manual and do not disassemble or modify the device otherwise it may cause the earbuds to fail to work, or burnt. 2. Do not drop or wash the product in any liquid. 3. Do not use adapters with current/voltage exceeding the limit 1A/5V to charge the case or the battery will be damaged. 4. Do not put the equipment under too high or too low temperature (Below 0 °C or above 45°C) 5. Do not block the charging pin, LED indicator and the microphone. 6. Do not use the earbuds over time and over-volume, or it will make you feel dizzy or damage your hearing. 7. Do not use the devices under thunderstorm environment. A thunderstorm may cause abnormal operation of the devices, signal interruption, etc. 14
日本語 製品紹介 T12 Proワイヤレスイヤホンをお買い上げいただきありがとうございます。ご使用前に取扱説明書をよく読みください。 パッケージ内容 1. T12 Proワイヤレスイヤホン -----1個 2. 充電ケース -----1個 3. USBケーブル -----1本 4. 取扱説明書 -----1冊  イヤホン 充電ケース  USB充電ケーブル 取り扱い説明書 15	製品紹介 T12 Proワイヤレスイヤホンをお買い上げいただきありがとうございます。ご使用前に取扱説明書をよく読みください。 パッケージ内容 1. T12 Proワイヤレスイヤホン -----1個 2. 充電ケース -----1個 3. USBケーブル -----1本 4. 取扱説明書 -----1冊  イヤホン 充電ケース  USB充電ケーブル 取り扱い説明書 16	マルチ機能ボタン LED指示ライト マイク 充電接点 充電インターフェース ケース充電ポート 充電リセットボタン 装着方法 イヤホンを目に装着し、適切な角度に調整します。  17	電源オン 方法1：充電ケースを開けると、両方のイヤホンが自動的にオンになり、互いに接続されます。イヤホンを取り出します。マスターに設定されたイヤホンのLEDが赤色と青色の交互に点滅します。（工場出荷時の設定では、左側のイヤホンがマスターに設定されています。） 方法2：充電ケースのバッテリーが不足しており、イヤホンがケースに収まっていない場合の方法です。両方のイヤホンでマルチ機能ボタンを2秒間押し続けると、電源がオンになります。マスター側のイヤホンでLEDが赤色と青色の交互に点滅します。（工場出荷時の設定では、左側のイヤホンがマスターです。） ペアリング 初回使用時は、方法1または2を使用してデバイスをペアリングしてください。イヤホンの電源をオンにした後、デバイスでBluetooth機能をオンにして、T12 Proを検索します。接続されると、接続済みであることが表示されます。初回接続の後は、イヤホンをオンにすればデバイスと自動的に接続されます。イヤホンは最後に接続されたデバイスを認識します。最後に接続されたデバイスが近く存在しない場合は、イヤホンは検索モードに入ります（LEDが赤色と青色の交互に点滅します）。 18	注意 1. ペアリングモードが維持されるのは5分間までです。その間にペアリングされない場合、イヤホンの電源はオフになります。イヤホンがデバイスへ接続する場合は、上記の手順を繰り返してください。 2. イヤホンがデバイスの接続距離を超えて離れると、接続が途切れます。5分以内に、両デバイスを検出可能な距離まで近づけてください。 電源オフ 方法1：イヤホンを充電ケースに入れて蓋を閉じれば、イヤホンは自動的に電源オフになります。（充電ケースのバッテリーが不足している場合は、イヤホンは自動的に電源オフになります。） 方法2：マルチ機能ボタンを5秒間押し続けると、LEDが3回赤色に点滅し、イヤホンの電源が切れます。（注意：イヤホンがペアリングされずに5分間経つと、イヤホンは自動的に電源オフになります。） 着信の応答 マルチ機能ボタンを一回押すと着信に応答できます。 通話の終了 マルチ機能ボタンを一回押すと通話を終了します。 19	通話の拒否 左右いずれかをダブルクリックすれば、着信の応答を拒否できます。 通話切替 通話中に、左右いずれかをダブルクリックすれば、2つの通話を切り替えます。 Siriの起動 スタンバイまたは音楽再生モードで、マルチ機能ボタンをダブルクリックすればSiriが起動されます。（この機能はIOSデバイスでのみ使用できます。）  20	音楽再生 1. 再生一時停止：マルチ機能ボタンを押すと音楽が再生または一時停止されます。 2. 前の曲：左のイヤホンを2秒間押し続けると、前の曲に戻ります。 3. 次の曲：右のイヤホンを2秒間押し続けると、次の曲に進みます。（モノラルモードでは、いずれかのイヤホンを2秒間押し続けると次の曲に進みます。） 4. モノラルモード：次の曲へ進む操作のみ可能です。 5. 自動再生：通話を終了すると、音楽は自動的に再開されます。 21
ワイヤレス充電対応 ワイヤレス充電パッド（別売り）の使用をお勧めします。  22	イヤホンの充電 イヤホンのバッテリーが不足すると、イヤホンをケースへ戻して充電するよう促す音声メッセージが流れます。イヤホンの充電中はLEDが赤色に点滅します。イヤホンの充電が完了するとLEDは消灯します。  23	モノラルモード 1. モノラルモードでは、デバイスへ接続する前にイヤホンの片方のみをオンにしてください。 2. ペアリング済みのデバイスへ接続する場合は、マルチ機能ボタンを2秒間押し続けてイヤホンをオンにすれば、デバイスへ自動的に接続されます。 3. モノラルモードで再生すると、マルチ機能ボタンは次の曲へ進む操作のみ可能です。 4. 新しいデバイスとペアリングする場合は、マルチ機能ボタンを5秒間押し続けるとペアリングモードに入ります。続いてBluetooth設定で「T12 Pro」を選択してください。  24	工場出荷時の設定リセット イヤホンが充電ケースに収まっている状態で、充電ケースを5秒間押し続けます。デジタル画面が2秒間点灯した後、工場出荷時の設定リセットされます。  アクティブスタンバイモード 1. 左右のイヤホンは独立して動作できます。両方のイヤホンをスマートフォンへいつも接続する必要はありません。イヤホンの片方を使用している状態で、もう片方のイヤホンも接続する場合は、ケースからイヤホンを取り出すだけで済みます。 2. マスター側のイヤホン（デフォルトでは左）のバッテリーが切れたり、充電ケースに収められていない場合は、右側のイヤホンがマスターイヤホンに変わります。 25	技術的問題の解決法 イヤホンとデバイスのペアリングがうまくいかない場合は、以下の手順に従ってください。 まず、イヤホンをフル充電させた状態で電源をオンにして、他のデバイスとのペアリングを解除してください。スマートフォンのBluetooth機能を有効にし、イヤホンとスマートフォンの距離を十分近くとらえて、再度お試しください。 上記の手順を読んでも問題が解決しない場合は、リセットを試みてください。 イヤホンがデバイスとペアリングされていない状態で、イヤホンを5秒間押し続けて電源をオンにします。続いて左右のイヤホン両方を同時に10秒間押し続けると、イヤホンがリセットされてスマートフォンのペアリング情報が消去されます。最後に、イヤホンを5秒間押し続けると起動し、新しいデバイスとペアリングできるようになります。  26	製品仕様 モデル： T12 Pro イヤホンの寸法： 45.6*17.6*18.5mm 充電ケースの寸法： 60*26*49mm 通信距離： 10メートル 入力電圧： DC 5V イヤホンのバッテリー容量： 3.7V/45mAh 充電ケースのバッテリー容量： 3.7V/400mAh 動作時間： 8時間 充電ケースの充電時間： 約1.5時間 IOSのバッテリーステータス情報： 対応 27	製品仕様 1. 取扱説明書の指示に従ってください。イヤホンを分解または改造しないでください。故障や火災の原因となります。 2. 本製品は落下させたり、洗浄したり、液体に接触させてはなりません。 3. ケースの充電時は1A/5Vの制限を超える電流/電圧の定格を持つアダプターを使用しないでください。バッテリーが破壊する可能性があります。 4. イヤホンは室温で保管してください。（0°C未満または45°Cを超える環境に放置してはなりません。） 5. 充電インターフェース、LEDインジケータ、マイクを塞いではいけません。 6. イヤホンは長時間、大音量で使用しないでください。頭痛や聴覚障害の原因となります。 7. 落雷のある環境では本製品を使用しないでください。落雷は機器の異常動作や信号の中断などの原因となります。 28
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. 29	-Consult the dealer or an experienced radio/TV technician for help Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. FCC ID: 2A7CM-T12 30	31	32			