公司品牌：Blackview	备注： 第一版，
产品型号：AuraBass 1	
设计项目：说明书	
文件名称：M5_Blackview_AuraBass 1_英文说明书_认证用	
说明书尺寸：80mm X 100mm 工艺说明：105g铜板纸，单色印刷，装订成册	
制作版本：01	

160.0 mm

80.0 mm

100.0 mm

Blackview
AuraBass 1


USER GUIDE

English

■ SPECIFICATION

Model: AuraBass 1	Playing time: 11hours
Bluetooth: V5.3	Input: 5V ⎓ 0.8A
Waterproof level: IPX7	Output: 8W
Battery: 3.7V/1800mAh	Product Size: 109 x 94 x 51.5 mm
Charging time: 3 hours	Product Weight: 256g

■ BUTTONS AND FUNCTIONS



❶ **Short press:** Switch EQ.
❷ **Long press:** Turn on/off.
Speaker crashes, press and hold for 8 seconds to shut down and reset.
❸ **Long press:**
1. In connected state: Long press for 2 seconds to disconnect.
2. When Bluetooth connection is disconnected: Long press for 2 seconds to reconnect to the last disconnected phone.
❹ **Short press:** Volume down
Long press: Previous song
❺ **Short press:** Volum up,
Long press: Long press the next song.

❻ **Short press:**
1. Play and pause
2. During an incoming call: short press to answer the call
3. During an active call: short press to hang up the call

Long press:
1. Press and hold for 2 seconds to reject the call.
2. Press and hold for 2 seconds to enter TWS connection, and press and hold to disconnect TWS connection during TWS connection.
3. Press and hold for 8 seconds to clear pairing information and restore the default volume with a prompt sound, which will automatically shut down.

Double click: Double click while the phone's Bluetooth is connected to call back the last call made from the phone.

❼ TYPE-C charging port.

■ LED LIGHT DEFINITION

BLUETOOTH INDICATOR
Bluetooth not connected: Indicator flashes rapidly
Bluetooth connected: Solid indicator
Music playing: The indicator light flashes once and then stays on
Playback paused: The indicator light flashes once and then stays on

CHARGING INDICATOR
Power on: Solid light
Charging: slow flashing
Fully charged: steady light


BOOST EQ light
Normal mode: Light off
Bass boost mode: Light on

■ VOLUME LEVELS


16 levels in total, with default media volume set to Level 7.

■ BLUETOOTH

❶ **Bluetooth connection:**
Turning on the speaker will automatically enter the Bluetooth mode.
❷ **Disconnect Speaker:**
When connected via Bluetooth, press and hold the Bluetooth button for 2 seconds to disconnect.
❸ **Reconnect Speaker:**
Some Bluetooth devices support automatic reconnection.
When Bluetooth is disconnected, press and hold the Bluetooth button for 2 seconds to reconnect to the last paired device.




❹ **Hands Free Function:**



Short press to hang up during answering state
Short press to answer during incoming call state
Long press to reject during incoming call state
Double press to call back

❺ **Music Control:**
Short press to play/pause the music.




■ TWS CONNECT

❶ Press and hold the Play/Pause-button on one of the speakers for about 2 seconds until you hear a"beep"sound and let go.



Primary speaker　　Secondary speaker

❷ Find the Bluetooth name and connect. There will be only one bluetooth name on device after 2 speakers are paired.



■ TWS DISCONNECT

Press and hold the Play/Pause-button on one of the speakers for about 2 seconds until you hear a prompt sound.

■ AUTOMATIC TURN-OFF

Bluetooth not connected: Auto-shutdown after 10 minutes.
Bluetooth connected but not playing: Auto-shutdown after 30 minutes.

■ LOW VOLTAGE STATUS

1. When the voltage is ≤ 3.4V, an alarm will sound once every minute, and the device will shut down immediately after three alarms.
2. When the voltage is ≤ 3.2V, an alarm will sound once only before the device shuts down.
3. When the voltage is ≤ 3.4V, the device cannot be powered on.

■ TROUBLESHOOTING

- **The speaker does not turn on?**
Recharge the speaker.
- **The speaker does not turn off or does not respond?**
Reset your speaker, press and hold Power Button for 8 seconds to shut down and reset.
- **There is no sound?**
Adjust the volume: make sure that your Bluetooth device is within range. ensure there is no obstacles in the way that can block/disturb the signal. check via the device's Bluetooth connection if the speaker is connected with the device.
- **There is poor sound quality?**
Move the device closer to the speaker or try removing obstacles between them.
- **Cannot connect the device with the speaker?**
Disconnect other connected devices and ignore the pairing from your devices and re-pair the speaker.
Or you can long press and hold Power Button for 8 seconds to reset the speaker to re-pair it.
Please make sure the speaker is within the Bluetooth covering range by 10 meters and powered on.

■ IMPORTANT NOTE

1. To ensure the waterproof performance of the Bluetooth speaker, remove all cable connections and close the USB plug.
2. Exposing a Bluetooth speaker to liquid without taking these steps can cause permanent damage to the speaker. Do not expose your Bluetooth speaker to water while it is charging, as doing so may cause permanent damage to the speaker or power supply.
3. The IPX7 waterproof rating is defined as the speaker can be submerged for up to 30 minutes at a depth of 1 meter If the speaker is not used for a long time, please charge it at least every three months.
4. Battery life varies depending on usage patterns and environmental conditions.

■ SAFETY PRECAUTIONS

1. Do not place the speaker in a place where it is easy to fall.
2. Do not disassemble, repair or modify this product by yourself.
3. Keep the speaker away from extreme temperatures.
4. Do not use the speaker in an outdoor thunderstorm environment.
5. Do not use any corrosive cleaners to clean the speaker.

WARNING



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction

Follow Blackview community, a place where you can share and discuss with Blackview user keep posted with most up-to-day news

2.5 - 5.0 W

The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 5 Watts in order to achieve the maximum charging speed.