

Front Buttons Introduction

Button 1: Recording button

1. Press it will enter recording mode and repeat your words automatically
2. Long press this button to start recording (at least 10 seconds) you can record the whole passage, release this button to end the recording, press it again it will play the whole passage just said.

Button 2: Sing button

1. Press this button once to start playing a song, press it twice to cut to the next song.
2. Long press for 2 seconds can open the Bluetooth mode, the name is BT003-AUDIO, after the connection is complete, you can play any music in your phone.

Cautions:

1. Open the bottom open key, it will automatically enter the recording mode.
2. In Bluetooth mode, press the music button can make the cactus toy stop glowing and twisting body, press again to resume glowing and twisting.
3. If you press the record button when the Bluetooth mode is on, Bluetooth will automatically disconnect, and then enter the recording mode, you need to reconnect to restore Bluetooth mode.

前面的按钮介绍

按钮 1：录音按钮

1. 按下它将进入录音模式，并自动重复你的话。
2. 长按此键开始录音（至少 10 秒），你可以录下整个段落，松开此键结束录音，再按就会播放刚才的整个段落。

按钮 2：唱歌按钮

1. 按这个按钮一次可以开始播放一首歌曲，按两次可以切到下一首歌曲。
2. 长按 2 秒可以打开蓝牙模式，名称为 BT003-AUDIO，连接完成后，可以播放手机中的任何音乐。

注意事项：

1. 打开底部的开关键，会自动进入录音模式。
2. 在蓝牙模式下，按下音乐键可使仙人掌玩具停止发光和扭动身体，再次按下可恢复发光和扭动。
3. 如果在蓝牙模式时按下录音键，蓝牙会自动断开，然后进入录音模式，需要重新连接才能恢复蓝牙模式。

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.