


Digital Photo Frame|WiFi

Installation and Instruction Manual




Digital Photo Frame Installation Method



Method 1: Portrait Installation



Method 2: Horizontal Installation



CONTENTS OF BOX:



1. **CONTENTS OF BOX**
10.1 "IPS Touch Screen.

2. **POWER**



After connecting power adapter, please press and hold power button for approximately 5 seconds (until screen turns on). When it is on, press and hold power button for approximately 3 seconds to access reboot or power off menu. Short press on power button will turn off/on screen (but leave the photo frame in position).

3. **RESET**
Use a needle or paper clip to reset unit.

4. **USB-C**
Connect frame to a PC, MAC, Ipad to transfer photos and videos.

5. **MICRO SD CARD**
Load external max 128GB micro SD memory card here.

6. **CHARGING PORT**
Plug the DC adapter power cord port into the charging port.



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**


4. **Select "WiFi" tab.**

5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**



Create new account

1. **Open Biu Frame APP.**
How to install BiuFrame APP?
(Please refer to the instructions in 1. 1, download and install in advance).

2. **Please click "Sign in" to register.**

3. **Please click "Add your avatar."**
You can choose one as your avatar by taking a photo or choose a picture in your album.

4. **Please fill in the E-mail, login password, name, etc.**
the security of your account and facilitate future forgetting of your password, you need to reset your password and retrieve your account.

5. **If you read and agree, please tick the agreement option**
Tips: It is recommended that you read the content of the agreement carefully. We have elaborated many statements in the agreement, which can answer many doubts about your future use.

6. **Please click "Sign Up" to complete your account creation.**

7. **Congratulations, you have a new account with your own frame.**
Please remember your E-mail and password, they are very important, you need to log in to the App.
If you need to log in to a new account, please click the back button in the upper left corner to enter the login interface.

8. **The network will be automatically linked.**

APP SETTING

1. **Download Biu Frame APP.**

Plan-A Scan the QR code to download APPS
Plan-B Please search and download in Apple APP Store or Google Play.

Log in

1. **Please enter Email and password in turn, and click "Log in".**
Tips: For more security, if your account is already logged in on other machines, This login will automatically log out of your other devices.

2. **Successful Login.**
If the login is successful, it will automatically enter the main interface.
Tips: If you fail to log in multiple times, please try to click "Forgot password" to reset the new password, and then log in again.

Forget the password

1. **Please click "Forgot Password" button.**



2. **Please enter the E-mail you used when creating a new account and click "send".**

3. **The cloud service will send an email with a link to your email.**
This link will guide you to reset your password. Our cloud service will send an email with a link to your E-mail.

4. **Check if your EMAIL has received an email with the subject "ResetPassword".**
Note: That the subject of the email we send is "ResetPassword" and the sender is Service@cloudphotoframe.com. Please confirm and click on the link to prevent from being infringed by forged email.

5. **Open the email and click on the link.**

6. **Enter your new password in the web page that opens.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**

5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

CONTENTS OF BOX

1. **Activation**

Plan-A Scan the QR code to download APPS
Plan-B Please search and download in Apple APP Store or Google Play.

Log in

1. **Please enter Email and password in turn, and click "Log in".**
Tips: For more security, if your account is already logged in on other machines, This login will automatically log out of your other devices.

2. **Successful Login.**
If the login is successful, it will automatically enter the main interface.
Tips: If you fail to log in multiple times, please try to click "Forgot password" to reset the new password, and then log in again.

Forget the password

1. **Please click "Forgot Password" button.**

2. **Please enter the E-mail you used when creating a new account and click "send".**

3. **The cloud service will send an email with a link to your email.**
This link will guide you to reset your password. Our cloud service will send an email with a link to your E-mail.


4. **Check if your EMAIL has received an email with the subject "ResetPassword".**
Note: That the subject of the email we send is "ResetPassword" and the sender is Service@cloudphotoframe.com. Please confirm and click on the link to prevent from being infringed by forged email.

5. **Open the email and click on the link.**

6. **Enter your new password in the web page that opens.**

7. **Congratulations, you have a new account with your own frame.**
Please remember your E-mail and password, they are very important, you need to log in to the App.
If you need to log in to a new account, please click the back button in the upper left corner to enter the login interface.

8. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**



4. **Select "WiFi" tab.**

5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**



5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

9. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**



5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

9. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**



5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

9. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**



5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

9. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**



5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

9. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**



5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

9. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**



5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

9. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**



5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

9. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**



5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

9. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**



5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

9. **The network will be automatically linked.**



Link wireless settings

1. **Set up a wireless network connection.**

2. **When playing a photo, click any area of the picture to display the operation panel.**

3. **Click settings button, enter settings page.**

4. **Select "WiFi" tab.**

5. **Click "Use WiFi" switch to turn on the wireless network.**

6. **Select your wireless network from the list and click.**

7. **Enter the wireless network password and click OK.**

8. **The network will be automatically linked.**

9. **The network will be automatically linked.**

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.