








C16A说明书

单页尺寸:80mm * 120mm

折叠方式:风琴折

ANJANK C16A User Manual V1  If you have any questions please feel free to Email us at customer01@kerhanstar.com	Top View ① Pairing - Long press to enter pairing mode. (a tone will sound and the Wi-Fi icon will flash continuously) ② Volume + ③ Volume - ④ Light Brightness ⑤ Night Light ⑥ Favorite Sound and Light - Short press: turn on / switch - Long press: turn off / switch - During Routine: — Short press: turn off - During Alarm: — Short press: 9-minute snooze - Long press: turn off 1	Front View ⑦ Clock Display ⑧ Wi-Fi Icon 2	Back View ⑨ USB-C DC Port 3	Get Started 1.Preparation - Connect the power cable to the device, then plug it into your power outlet. - Make sure your smartphone is connected to a 2,4GHz Wi-Fi network and has Bluetooth turned on. - Scan the QR code or search for "ANJANK" in the App Store, Google Play, or Android to download the app, complete the registration, and log in to your account.  4	2.Wi-Fi Pairing Step 1: Long press the "Pairing" button on the device until you hear the prompt tone to enter pairing mode.  Step 2: Tap "Add Device,"  5	Step 3: Tap: "Start Searching."  Step 4: Select the device named "ANJANK GlowRise."  6	Step 5: Choose the same 2,4GHz Wi-Fi network that your phone is connected to, enter the correct password, and tap "Next" to complete the pairing.  7
MY K-LIFE App Interface  8	1.Clock Display Setting - Switch 12-hour or 24-hour format. - Adjust the clock display brightness range from 0% to 100%. - Night Mode setting. 2.Alarm Setting You can customize up to 15 alarms. 3.Routine Setting You can customize up to 15 daily routines. 4.Night Light Choose from 10 nightlight options and turn on, including one custom. 5.Favorite Sound and Light You can customize up to 15 sound and light combinations. 6.Timer Setting Set a timer to turn off current music and light. 9	7.Light Brightness Adjust the light brightness from 0% to 100%. 8.Volume Adjust the volume from 0% to 100% (maximum 90 dB). Restore Factory Settings Press and hold "O" and "C" simultaneously to restore factory settings.  10	Family Mode (Primary Device & Sharing) 1.Primary Device The phone that successfully completes its initial pairing in factory settings will be designated as the primary device. Once the primary device is established, other phones will be unable to pair with the device through the standard pairing process unless the primary device is removed. 2.Connection QR Code Sharing Step 1: Tap "Settings" on the "Controller" page  11	Step 2: Tap "Shared Connection QR Code" on the "Settings" page  3.Scan to Add Device Control  12	Feedback & Support We offer a one-year warranty for this product. If you encounter any issues while using the product or the app, you can contact us at customer01@kerhanstar.com, or submit your feedback directly through the "Feedback" section under "Profile" in the app.  13	FCC Warning This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does 14	cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. FCC RF exposure statement: The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body. 15