





S12 说明书/成品尺寸：TBD mm 材质：120g 铜版纸 印刷：黑白印刷

S12 User Manual Manual before operating your device. In order to avoid unnecessary injuries, please do not Disassemble this product by yourself, and please use a standard charger.	Product Contains Wireless Earbuds x2 Charging Case x1 USB Charging Cable x1 Pairs of Ear Caps x4 (XS/S/M/L) M size on earbuds	Product Specification Driver: 6mm Support Profile: HFP / AVRCP / A2DP Earbuds Charging Time: Up to 1 Hour Charging case Charging Time: Up to 1.5 Hours Charging case Charging Time: Up to 3 Hours (Wireless) Working Voltage: 5V Transmission Range: Up to 10m Working Temperature: -30° - 70° Wight: 86.8g	Power On / off 1)Earbuds will auto power on and connect when you open the charging case. 2)Earbuds will auto power off and disconnect when you close the charging case. 3)If charging case open but earbuds don’ t power on, please long press touch button for 2 seconds to power on. (and please charge charging case) 4)If charging case close but earbuds don’ t power off, please long press touch button for 5 seconds to power on. (and please charge charging case) Open Close	Bluetooth Pairing When you use earbuds first time, please connect your cellphone / laptop. Open the charging case and check the white and red LED light flash on earbuds. Turn on the Bluetooth page on your cellphone or laptop and open the cellphone Bluetooth. Select “S12” to connect the device, the white and red light off when you connect the cellphone. The device will automatically turn off if not connected cellphone within 5 minutes. Reset Earbuds When your earbuds got the problem, please try to reset earbuds. Short press left & right touch button for 5 times at some time to reset. 
--	--	---	---	--


Product Wear Step1: Take out the earbuds. (right earbud on lest side / lest earbud on right side) Step2: Insert the ear cap into your ear. Step3:Put the ear hook over back your ear. Step4:Adjust by twisting for comfort and secure. 	Product Control  Play/Pause Short press the touch button twice  Previous Song Long press Left touch button for 2 seconds  Next Song Long press Right touch button for 2 seconds  Volume Up Short press Right touch button once  Volume Down Short press Left touch button once  Answer a Call Short press the touch button twice  End a Call Short press the touch button twice  Reject Call Long press the touch button for 2 seconds  Switch a call Short press the touch button twice  Voice Assistant Short press the touch button thrice
--	--

Product Charging

1)Put the earbuds back charging case to charging earbuds.

2)Plug the USB type-C to charging the charging case.

3)The power display will tell you the charging case power and Earbuds

Type-C charging Port

Charging Pins of Earphone

Charging Display of Earbuds

Power Display of Case

Wireless Charging

We recommend you also can use wireless charging pad to charge charging case.(up to 3 hours from 0% - 100%)