

120g 铜版纸/ 折页/ 双面印刷

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE FCC 
FCC ID: 2A7J2-TWS03B

FCC ID: 2A7J2-TWS03E

Charging Port of Charging Case

LED of Charging Case

Touch Button - MFB

Charging Pin of Earbud

Microphone

TP103B Wireless Earphones
Type-C USB Charging Cable
Silicon Gel Tips (S/M/L)
Quick Guide

Bluetooth: V5.4
Frequency Range: 2402-2480 MHz
Sensitivity: 110 $\pm$ 3dB
Impedance: 32 ohm $\pm$ 15%
Input: DC 5V / 500mA
Earphones Battery Capacity: 30 mAh x 2
Charging Pod Battery Capacity: 250 mAh
Charge Time: 1.5 hours

When the charging case is connected with charger (or computer USB port) by charging cable, the indicator will flash in red. When the charging case is fully charged, the indicator will be lit-in red.

When the charging case is out of battery, the earbuds will not turn on/off automatically when removed from or placed back into the charging case. In this case, turn the earbuds on/off manually.

Take the earbuds out of the charging case, the earbuds will automatically power on and enter into pairing mode.

Touch the MFB for 2 secs on both earbuds to turn on the earbuds. (You will hear the prompt tone). The earbuds will automatically enter pairing mode.

Diagram illustrating the Bluetooth settings on a smartphone. The Bluetooth toggle is turned on. A red box highlights the device name 'TP103B', and a green box highlights the status 'Connected'.

Turn on the device's Bluetooth setting .
Search for and choose **TP103B** to pair,
your device will show "connected" .

Auto Power-Off

Put L&R earbuds back into charging case, the earbuds will automatically power off .

1. Touch the MFB for 5 secs on both earbuds to power off the earbuds.
2. The earbuds will automatically turn off when without pairing for 10 mins.

Insert the earphones directed towards your ear canal. Twist gently until the earbuds fit comfortably and get better sound experience.


The diagram illustrates the touch gestures for the Earbud R. It is divided into three main sections: Calls, Music, and Voice Assistant. Each section lists specific gestures and their corresponding actions, accompanied by icons.

Category	Gesture	Icon	Action
Calls	Tap Once	Phone handset	Answer Call
	Tap Twice	Phone handset with slash	End Call
	Touch for 2s	Phone handset with X	Reject Call
Music	Tap Twice	Play / Pause button	Play / Pause
	Touch for 2s	Next / Previous track buttons	Earbud R- Next Track Earbud L- Previous Track
	Tap Once	Volume up/down buttons	Earbud R- Volume Up Earbud L- Volume Down
	Voice Assistant	Microphone icon	SIRI / Voice assistant

If you have problem to connect the earphones with your device, don't worry about it. please follow the step as below:

1. Make sure all devices have turned off Bluetooth Function and pairing record have been cleaned.
2. Take the earphones out of the case, tap each earbuds by 5 times quickly , prompt sound will be activated , then follow the pairing step as instruction.

Model: TP103B



Quick Guide