


User Manual

Sports Wireless Earbuds


Model:V17



-Born for Better Sound-
-Born for Better Wearing-

Instructions

Step1: Open the charge case



Step 2: Skills of connection

Power on:


1.Once open the charge case, taking out both of them, then the left and right earphones will power on and automatically pair. (Need to ensure the case with enough power)

2.When initial pairing, please go to the Phone (Device) settings and turn on the Bluetooth Switch.


3.Searching for V17 to connect.
Note: After pairing the device for the first time according to the manual.Taking out the any side earphone from the charge case, the earphone will connect the (Last) Bluetooth Device automatically.

Step 3: Wearing way is super important

As the picture show, the Left and Right are different.



Correct



Wrong



Step 4: Function key guide

1.Fast Double clicks on the Right, earphone to play the next song.

2.Fast Double clicks on the Left, earphone to play the previous song.

3.Voice Assistant (Siri): Long press, the left and right earphones for 3 Seconds, click once to cancel.

4.Answer a call: Click once on the left earphone or right earphone.(when a call coming in)

5.Hang up the call: Click once the left or right earphone. (when calling)

6.Reject the call: Long press the left or right earphone for 3 seconds. (when calling)



Step 5: Special use attention

1.When charge case without the power and need the urgent use, please take out both of the earbuds and long touch 3 seconds to power the earbuds on, then use it normal.

2.When charge case not around you, if earbuds stop the Bluetooth connect, it will turn o ff in 5 minutes.

3.Taking the earbuds back into smart charge case, earbuds will auto power o ff and charging, when they are full of power, they will stop auto.

Step 6: Operation exception handling

1:If the replacement of a single product or misoperation, resulting two headphones can not be connected to the phone at the same time. Please kindly try as following step to fixed (A-C):

A:Delete all "V17" in mobile phone.

B:If the left and right earphones crash due to unknown reasons, you can press the power on button for 15 seconds to reset, and then the left and right earphones will be powered on for automatic pairing.


C:1.After pairing, press the wireless pairing operation.
2.If the cause is unknown, turn off the headset and restart it.

Dear, If there is still with any questions or suggestions, please feel free to contact us byAmazon Message, we are kindly.


Thank You So Much for your trust and support



Correct



Wrong



Sharing Seller Tips:
Tips 1: If taken out the earbud not power on, in this situation, please press that earbud for 3 seconds to power on or reset into the case and take out again auto to power on.
Tips 2: Please wear in correct way like the picture showing.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a ClassB digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particularinstallation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.