

英语反面

FULMINARE WIRELESS SPEAKER FULMINARE-HS02  USER MANUAL Please read the instructions carefully before using the product.	PRODUCT SPECIFICATIONS: ◆Model: FULMINARE-HS02 ◆Bluetooth Version: V5.1 ◆Connection Distance:10M approx ◆SNR: 85dB ◆Battery: 2400mAh 8.8Wh ◆Playingtime: 4H ◆Charging Time: 4H ◆Speaker Size: Φ52 mm ◆Power: 4Ω/5W*2 RMS ◆Frequency: 140HZ-16KHZ ◆Input: 5V=1A ◆Dimension: 399.5*56.65*75.3mm ◆Weight: 670g±20g PACKING LIST: Wireless speaker ×1 Type-C charging cable ×1 AUX cable ×1 User manual ×1	POWER ON/POWER OFF: Power On: When the speaker is power off, rotate the power switch clockwise to turn on the speaker and with blue lights flashing. Power Off: When the speaker is power on, rotate the power switch counter clockwise to turn off the speaker and with blue light off. BLUETOOTH CONNECTION: 1. Turn on the Bluetooth speaker, and the blue light flashes for pairing. Search the bluetooth device " FULMINARE-HS02 " on your phone, it will connect with your phone. 2. As the Bluetooth speaker is turned on, it will automatically connect with the previous mobile phone that has connected before, no more searching Bluetooth device on your phone any more. 3. No pairing connected for 10 minutes, the speaker will automatically shut down. For usage again, restore the twist switch to the shutdown position before starting the speaker.	MUSIC PLAYING & PICK UP CALLS: 1. When playing music, click the "⏸" to pause the music and then click button again to restart to play. 2. When a call comes, click the "📞" to pick up a call, and then click the button again to hang up a call. In order to reject a call, long press the button "⏸" for 2 seconds. 3. When the music is playing, rotate the clockwise to turn on the volume. 4. When the music is playing, counter clockwise to turn down the volume. 5. Press "⏮" to play the previous song. 6. Press "⏭" to play the next song. MODE SWITCH: The speaker will enter wireless BT mode when power on. Insert the TF card then it will automatically enter the TF card playback. Click the "📀" button to switch TF card / AUX / wireless BT mode. LIGHTING ADJUSTMENT: The "M" key can control the light on and off, you can long press the "M" key to turn on or off the light function.	CHARGING: 1. This product has built in non-removable rechargeable battery, which can be charged by type-C cable. 2. Charging voltage and current is 5V≈1A. 3. When the speaker is charged, the red light will be on. As it is fully charged, the lights will be off. 4. Charging the speaker while playing music will speed up the decline of battery life. We suggest use the speaker after fully charged. Repeated charging and discharging will lead to the decline of battery life, which is a normal phenomenon of rechargeable batteries. WARRANTY STATEMENT: All products are warranted to be free from defective materials and workmanship. The warranty period for all equipment provided by our company is 12 months after purchase. If you have any questions, please contact a customer service representative for assistance. FCC WARNING: Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	Note: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
---	---	--	--	--	---