

128g双铜，尺寸：70*90MM，单面单色印刷，对折。

teckwe

Wireless Speaker

User Manual




Please read the instructions carefully before using the product.

PRODUCT SPECIFICATIONS:

Model: HS12
Bluetooth Version: Bluetooth 6.0
Connection Distance: 10m approx
Dimension: $\Phi 72 \times 155 \text{mm}$
Power: $4\Omega/5\text{W} \times 2$
Speaker Size: $\Phi 45 \text{mm} \times 2$
Battery: Built-in 18650/ 2000MAH/3.7V/7.4Wh
Playing time: 3H-6H(50% volume)
Charging time: 2H-3H
Product material: ABS+Iron net
Function: Bluetooth call/TF/AUX FM/USB/TWS/IP53/lighting
/Built-in DSP sound effect/Hifi-level sound quality
Weight: $550\text{g} \pm 20\text{g}$
Colour: Black
Charging interface: type-c Interface

PACKING LIST:

Wireless speaker x 1
Type-C charging cable x 1
AUX cable x 1
User manual x 1



WARRANTY STATEMENT:

All products are warranted to be free from defective materials and workmanship; The warranty period for all equipment provided by our company is 12 months after purchase; If you have any questions, please contact a customer service representative for assistance.

Operation Instructions

1. Power on/off: Press and hold the power button for 2-3 seconds.
2. Play mode switching: When playing music(from USB flash drive /TF card/Bluetooth), short - press the power button to switch among USB flash drive, TF card, and Bluetooth modes, If connected to an audio device via an AUX cable, it will switch to"Audio input".
3. Bluetooth pairing: The device automatically enters Bluetooth mode when powered on, On your phone, select"HS12" to complete the connection.
4. Disconnect Bluetooth: Press and hold the play/pause button.
5. Lighting mode switching: Short - press the lighting button to cycle through different lighting effects, Press and hold the lighting button to turn the lights off or on.
6. Volume adjustment: Press the"+" button once to increase the volume; press the"-" button once to decrease the volume.
7. Song switching: Press and hold the"+"button to skip to the next song; press and hold the"-"button to go back to the previous song.
8. Energy - saving mode: When the lights are off and the Bluetooth is not connected, the device will automatically power off after 5 minutes.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.