

Conference Speaker

SKYWIN



IMPORTANT

Thank you for purchasing the Skywin Speaker unit. Please read the entire instruction manual prior to using your unit. If you have any questions regarding the

Skywin Conference Speaker, please send us email at: **support@skywin.info**


• This product is NOT a toy; keep it away from children.

• Don't use or store the device in places where exist water or splashes.

• Do not repair, may cause malfunction and warranty will be avoid.

"The operation of this equipment is subject to the following two conditions: (1) it is possible that this equipment or device may not cause harmful interference and (2) this equipment or device must accept any interference, including interference that may cause its undesired operation".

QUICK DESCRIPTION



HOW TO USE


Charge the battery

Before to use the station by the first time, connect it by 4 hours to charge the battery at 100%(Estimated time with a 5V AC adapter).



Power adapter is not included

You can use the station while it is connected to a PC or an AC adapter permanently.



CONNECT YOUR BLUETOOTH DEVICE

1. Press for a few seconds to turn on the station and start the search mode.

The button flashes quickly

2. Activate the Bluetooth in your device (smartphone, tablet or IP telephone).

3. Search and select "Skywin Conference Speaker".

If the connection is successful, the button flashes slowly



This is an example of with a smartphone. Refers to the user manual of your device to know how to pair via Bluetooth



If you want to pair another device, press the button until you hear a tone. *The station will be ready to enter search mode.*

MAKE YOUR CONFERENCES AND CALLS

Place the station in a central area and use the control panel to make calls wirelessly.



The 3 way calling or others services for conferences (previously hired with your telephone company) must be set and controlled from the paired device.

MUSIC PLAYBACK



Backward




Forward



Play



Pause



Volume Down



Volume Up



Activate/disactivate the microphone



Answer
Press once



Hang up
Press once



Redial
Press twice continuously



Reject call
Press and hold

SPECIFICATIONS

Input: 5 V --- 500 mA (by USB port)
Battery life in conversation: Up to 5 h
Battery capacity: 1 500 mAh (Li-ion)
Maximum recommended distance: 8 m
Speakers quantity: 2 x 3W
Maximum power output rms: 5 W
Microphone frequency response: 50 Hz to 15 kHz
Speaker frequency response: 20 to 20 kHz

Specifications may change without notice

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FCC ID:2A7OI-SWTALK