



- Note:**
- Don't open the shell to prevent electric shock. Please turn to qualified professional maintenance personnel for the maintenance as there are no parts in the machine that users can repair themselves.
 - Don't expose the machine to rain or moisture so as to prevent misfire or electric shock.



Short press the power button or the **⏻** key on the remote control, once shutdown prompt box appears, short press the power button or the power key on the remote control again.



Product Name	T6 Projector	Display Principle	LCD
Light Source	OSR Red-Green-Blue LED Light Source	Room	Inverted Stereo 60
Operation Mode	Remote Control	Working Environment	0-35 °C
Output Port	Headphone Audio Output	Input Port	HDMI/USB/V
Net Weight	1.045kg	Machine Size	137*101*126mm
Accessory	User Manual / Remote Control / Power Cord / Adapter		



1. Ensure the Phone and Projector are under the same WiFi (For Android Only).
2. Open 'Eshare' of the projector.
3. Choose the device with the same name with Eshare to complete mirror.



CAUTION: IR emitted from this product. Do not stare at operating lamp. May be harmful to the eyes.

- How to be with the same screen for iPhone under status of No Wi-Fi
1. If there is no Wi-Fi, firstly open 4G network of iPhone, then open **AirPlay** hot spot in the "Settings" interface of the phone.
 2. Collect iPhone's hot spot Wi-Fi for the projector.
 3. Open "Eithere".
 4. Open "Airplay" / "Screen Mirror".
 5. Find the projector and click.

- * Note: Advantage of push is it does not affect remote use of the mobile phone.
1. Ensure the Phone and Projector are under the same Wi-Fi.
 2. Open video software of the mobile phone and find the TV push icon in the four corners (It's usually on the top right or on the bottom right) (Each APPs have different push icon design).
- * Note: Not all video software have function of push.
3. Click this icon to push video to the projector. At the same time, we can have other operations on the phone, it will have no conflict.



Shenzhen Wanbo Technology Co., Ltd.
www.szwanbo.cn

Enter Setting interface in the main screen and  select input source. Enter into AV1/HDMI signal channel. Press "OK" to switch input source.

Notes:

- If you want to return to the previous layer, please press the return key.
- If you want to return to the main interface, please press the main screen key.

File Type	File format supported
Picture	JPG/PNG/GMP/GIF
Video	VP8/1,2/4/AVS2/P2/1,2/4/MPEG-4/AVI/AVS-P10 MPEG-2/3/PEG-1/realVideo 6/3/1
Audio	MP3/AAC/WMA1/8/FLAC/Ogg

Note: Specific operation contents are subject to actual situation due to irregular updates of the product system.

Projection size (under status of no keyframe correction / inch)	Screen length * width (m)	Less - screen (m)
42	0.83*0.53	1.37
58	1.23*0.75	1.96
66	1.35*0.87	2.29
88	1.86*1.05	2.73
100	2.21*1.25	3.25
120	2.66*1.48	3.91
150	3.32*1.87	4.89
170	3.76*2.12	5.53
200	4.43*2.49	6.51
250	5.54*3.11	8.16

Note: Projection size and distance are calculated according to projection ratio, which may have a deviation and subject to actual status.

Do not use pesticides or other volatile chemicals on the projector or lens. Do not let rubber or vinyl products contact the projector for a long time, which will damage the coating and make it peeled off.

- 1. **Check the Project**
 - 1.1. **Wipe with a dry, soft cloth.** If it is dried annually, we can wipe with wet cloth. Do not touch with metal objects, dry with a clean cloth and dry with a cloth.
 - 1.2. **Do not touch with wet or chemical liquids.**
 - 1.3. **Do not use force, blow air or other objects to clean quality and reduce the risk of peeling off.**
- 2. **Check the Temperature**
 - 2.1. **Do not touch the front of the screen directly or touch the screen by the back of the hand.** Please do not touch the screen with no connection, or damage the screen.
- 3. **Please do not scrape the monitor with nails or other hard objects as to avoid scratches.**
- 4. **Check the Power**
 - 4.1. **Close the power with the same method as when the power is pushed on the display or display for display, unless the fan and the screen.**
- 5. **Check the Color of the Display**
 - 5.1. **Adjust the brightness will prevent vibration and increase the lifetime temperature, which will cause defect.**
 - 5.2. **Disconnected power after the end of the project;**
 - 5.3. **Close the battery with the battery cover closed, please not touch the back of the battery cover, please turn the battery cover into the battery cover, please not touch the connector or leads;**

Part name	Heterogeneous assistance					
	Local (Lo)	Memory (M)	Context (C)	Global (G)	Hybrid nearest (H)	Hybrid extended (H+)
Shell	○	○	○	○	○	○
Optical Machine	○	○	○	○	○	○
Circuit board	○	○	○	○	○	○
Fan	○	○	○	○	○	○
Other Wires	×	○	○	○	○	○
Power supply	○	○	○	○	○	○
Power supply	○	○	○	○	○	○

○: Content of the knowledge contained in the homogeneous materials of the component is under the limits of 70/1500/1000.

×

Content of the heterogeneous assistance exceeds the limit requirements of 70/1500/1000.


is specified by the heterogeneous assistance is based on homogeneous materials of the component. The components marked "x" are not associated due to global technology development limits. Circuit board assembly: including printed circuit board and its components, electronic components, etc.

 The number in the logo denotes the normal environmental service life of the product. (Bosch Gd&D)

2. We **will** provide warranty service for any default caused by product technical reasons during warranty period.

Customer Name: _____ Purchase of Shop: _____
 Customer ID: _____ Customer Tel: _____
 Full Description (Please describe in detail for quick maintenance):


 Certificado
 QC 10



FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, Pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.