

CAR MULTIMEDIA

La Paz 880



Enjoy it.

Operating instructions



1 Return to home screen

2 Increase volume

3 Decrease volume

4 Voice Command Button

5 Next

6 Previous

Contents

Safety Information	4	iPod	13
Safety Tips.....	4	Settings	14
Safety Statement	4	General Settings	14
Warning	4	Advance settings.....	14
FCC Warning.....	5	Steering Wheel Control	15
Usage Notes	6	Audio Settings.....	15
Statements	6	Display Settings	15
Home menu	7	Bluetooth Settings and Device	15
Radio	7	Change device name	16
FM/AM Switching.....	7	Radio Settings.....	16
Automatic Search And Storage Station	7	Problemas comunes y soluciones	17
Play Station In The List	7		
Play Preset Station	7		
Manual Search Station.....	7		
Media Player	8		
Play Music.....	8		
Play Video	9		
View Picture	9		
Play Folder Contents	9		
First Letter Search.....	9		
Playing Modes	10		
Bluetooth	10		
Search Bluetooth Device	10		
Bluetooth Pairing	10		
Automatic Connection	10		
Download Phone Book.....	10		
Dial Phone Number	11		
Hands-free Mode and Private Mode	11		
Disconnection	11		
Switch Tracks.....	12		
Play/Pause.....	12		
Apple CarPlay	12		
Wired connection	12		
Using CarPlay.....	12		
Android Auto	13		
Wired connection	13		
Using Android Auto	13		

Safety Tips

- Please drive according to driving regulations and obey traffic laws;
- Please pay attention to the warning in the manual and avoid the operations that mentioned during the installation and use. The ignoring of any warning would lead to danger;
- Please do not use any function that would disperse your attention in driving. These functions should be used in the parking state. If you need the function, please park the vehicle in the security zone and use handbrake to avoid the occurrence of safety accidents;
- During driving, please keep the volume of music in the state that does not affect any security alert and make sure that the driver could be able to hear the noise out of the window. Driver may not hear the emergency alert or road warning signal because of high volume in vehicle and it may lead to traffic accident;
- For security considerations, driver in the vehicle should not watch the video, please enable the “handbrake test” function in system settings;
- Please do not insert your finger, a foreign matter or conductive material into the gap or slot;
- Please do not wear headset in driving;
- Please do not use the product for any other function except for navigation and multimedia;
- Any accessories should be matched with the parameters of the product during the replacing; Unsuitable accessories might damage the product and cause serious safety accidents, which will lead to personal injury.

Safety Statement

- This product is the auxiliary equipment for increasing driving experience, please keep the safety in the first place and never be careless or lack of judgment. Please avoid using any function that may affect your safety during driving, otherwise the safety accidents caused by improper

operation has nothing to do with our company; Please take the actual situation as the basis for the processing; Such as map navigation, it works only as a reference, please consider the actual road conditions;

- The navigation map provider is responsible for navigation map data;
- Please follow the manual steps. Any serious injury, death or goods damage that caused by the operation that does not be mentioned in the manual has nothing to do with our company.

Warning

- No desmonte, instale ni repare el producto usted mismo. Póngase en contacto con el personal de servicio especificado por el fabricante primero si es necesario. La operación que realiza la persona que no tiene equipo electrónico, modificación del vehículo u otra capacitación relacionada puede causar accidentes, incendios, descargas eléctricas u otros peligros.
- Por favor no cambie arbitrariamente el sistema.
- No acerque el producto del fuego, ni deje en contacto con líquidos y evite daños al producto que puedan provocar descargas eléctricas, incendios y otros accidentes.
- No instale ni use este producto en un entorno que no cumpla con las condiciones de instalación. De lo contrario, puede causar daños a la unidad o lesiones al usuario.
- No cambie arbitrariamente la frecuencia de emisión, aumente la potencia de transmisión (incluida la adición de un amplificador de potencia de RF) agregue una antena externa o use otras antenas de transmisión.
- No interfiera con los servicios legítimos de comunicación por radio durante el uso del producto. Una vez que ocurre la interferencia, el usuario debe dejar de usar el producto inmediatamente y el producto no debe usarse a menos que la interferencia desaparezca.

FCC Warning

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Warning Statements:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment

shall be installed and operated with minimum distance 20cm between the radiator & body.

Installation Instructions



- The vehicle must meet the voltage, current and power that required, please check the conditions before installation;
- The installation should be done while the battery of the vehicle is disconnected;
- To ensure that the product has been fitted with a fuse;
- The installation of the product should not affect the safety of the operation and function of the vehicle.
- The installation position should not block the driver's sight and should not be on the place that the brake, steering wheel, seat belts, airbags and other vehicle safety equipment should be;
- Please confirm the matching condition of the vehicle interface before install this product, use the appropriate patch plug if the interface is not matched.
- Please be familiar with the connection of the vehicle before installation, confirm the position of the piping, electrical wiring, fuel tank and other vehicle system components. Do not touch or damage these components and avoid the exposure of wires that may cause corrosion, leakage, etc.;
- Please do not conduct the installation in place of condensation, drench water sites, high humidity, containing dust and oil smoke. If water, moisture, dust and oil smoke enter the product, it may cause smoke, fire or failure.
- Please do not move or disassembled the existing screws, nuts, bolts, clips, connecting fixed appliances, accessories and so on, do not change or remove vehicle incidental contact system and wire clip, otherwise it may impair the function of automobile safety;
- In order to avoid the occurrence of fire damage to the product or vehicle, please do not allow the existing power supply circuit overload when power the product; Please be sure that the power wires have insulation treatment and install with fuses, circuit breakers and relays.
- Please use non conductive tape in insulation treatment, wrap the ends of the wire and unused wire; correct insulating treatment can avoid the occurrence of electric arc, electric shock or fire. In order not to impede the brake pedal, gearbox and steering wheel, plastic belt could be used to fix the wires. Please do not make the wires contact high temperature surface, the heat can easily cause damage to the wires and lead to short circuit, arc or fire;
- Please fix the wire on the electric chair or other parts of vehicle where will not lead to the scratch or damage of wire. In addition, the wire should be fixed in the hidden place as far as possible, it will make the environment inside the vehicle beautiful.
- Please do not block the airflow vents, otherwise it may cause internal overheat and fire;
- After the installation is completed, please check the wire connection of the vehicle, then run all functions, including lights, speakers, stereo, reversing operation and other electrical systems and ensure that the vehicle function is normal and can be used safely.

Usage Notes

- Please use this product in 9-16V DC voltage range. Mismatched voltage (too high or too low) will cause damage to the product and the battery of the vehicle;
- Please use the 15A fuse;
- Please operate the product at the temperature of -20° C to +70 ° C;
- Use the soft wet cloth to wipe the stain gently;
- It is recommended to not use the product in excessive wet environment. If the function is failed, please shut down the product and restart after the moisture dispersed;
- When OS is crashed and affects driving, please park the vehicle in the safety zone and restart the machine;
- When it is in cold start process, it may not be able to accurately display the current time and location, user could use GPS positioning function to correct it;
- The product may not run normally because of bumpy road. Users could reuse this product when the road conditions improve;
- When playing HD video, it is suggested to close navigation system to avoid the stuttering;
- Foreign objects or water into the machine may cause the smoke or smell. When it occurs, please immediately shut down the machine and contact the service center;
- If the product has any fault or any serious damage, stop using and contact customer service center immediately;
- It is not in the scope of warranty that the products cannot run normally, data is corrupted or lost because of operation without manual instruction or artificial damage to the product.

Statements

- This manual mainly introduces the function and operation method of the product, it is only used as user's operating guidelines, not as a basis for other criteria and maintenance services;
- When there is improvement of products, specifications and design are subject to change without notice, please consult the supplier for details;
- Without our authorization, the contents of this manual shall not be used for other commercial purposes;
- The final interpretation of this manual shall be owned by manufacturer.



Apple CarPlay:	Connect to iPhone.
Tutorial:	User manual.
BT Music	Play audio streaming through Bluetooth.
Android Auto	Connect to Android phone.
USB	Play music/video/image in USB device.
Radio	Listen to FM or AM radio program.
Phone	Make a hands free phone call.
Settings	Set the parameters of the product.
Screen off	Close screen display.
Clock	Display time clock.
EQ	Choose different EQ types.

Radio



FM/AM Switching

- Touch to switch between FM and AM.

Automatic Search And Storage Station

- Touch to automatic search and save station; When search is completed, the first radio station searched will be automatically played and the stations will be stored in the list.

Play Station In The List

- Touch or to select the station in the list to play.

Play Preset Station

- Touch to enter preset list and select the preset station to play.

Manual Search Station

- Touch or to search previous by step.
- Touch or to search next by step.

Manual Search Station

- Long press  or  to search for the previous or next available radio station. If the station is searched, the process will stop and play the station searched.

Sliding  left or right to rough adjust radio frequency.

Collect Station


- Touch  to collect current station into the favorite list.
- When  change to red color, touch it again, the collection will be canceled.
- Touch  Radio
-  Favorite, then touch  to cancel collection.

Media Player

Insert USB Flash Drive with media files.

- Music: APE, FLAC, MP3, WMA, WAV, M4A, OGG;
- Video: 3GP, AVI, MKV, MOV, MP4, MPEG, VOB, WMV, M4V;
- Picture: JPG, PNG, BMP.

Play Music



- Touch , select  to show the music list then select the music track to play.

Touch  to return to the player interface.

- Touch  or  to play the previous or next track.
- Touch  or  to pause current playing track or replay the paused track.
- Drag the  for fixed-point playback.

Play Video



- Touch , select  to show the video list then select the video track to play.
- Touch  or  to play the previous or next track.
- Touch  or  to pause current playing track or replay the paused track.
- Drag the  for fixed-point playback.
- Touch the screen to enter full screen mode. If current state is full screen mode, touch the screen again to exit full screen mode.


View Picture



- Touch , select  to show the picture list then select the picture to play.
- Touch  or  to play previous or next picture ;
- Touch  to return to the list.
- Touch  to play or pause playing pictures


- Touch  or  to rotate current playing picture
- Touch the screen to enter full screen mode. If current state is full screen mode, touch the screen again to exit full screen mode.

Play Folder Contents



- Touch  to switch to folder list, it will show the folders and music tracks, video tracks and images.

First Letter Search



- Touch  to enter the keyboard page, then input the string you want to search.
- Touch the , it will return the previous list and show the contents including the string you want to search.



Playing Modes

- 【 Sequential playing mode;
- 【 Single cycle mode;
- 【 Random play mode;

Bluetooth

The Bluetooth connection is not available when Apple CarPlay is on.


Search Bluetooth Device



Using a mobile device to search the product, the product name will be displayed on your mobile device, or touch

【 Search 】 to search the surrounding Bluetooth devices. Make sure Bluetooth on device is enable and discoverable; All devices searched will be displayed on the product screen.

Bluetooth Pairing




Touch the product name that you want to connect in the mobile phone, or choose mobile phone on pairing list to connect, and then wait for the connection.

Automatic Connection


If the connected device is out of the operating range, the Bluetooth connection will be disconnected automatically. If user does not close the Bluetooth function, the Bluetooth is automatically reconnected when the device returns to the operating range in few minutes.

Download Phone Book


Touch 【 Download 】 to download phone book from mobile device, download tips will be shown on the mobile device screen.





- Touch **Dial** to select the digital numbers on the dial keyboard, touch the **Call** to make a phone call.



- Touch **Contact** to enter contacts list then select a name from the phone book to call.




- Touch **History** to enter history record list then choose a record number for calling.



- During a call, touch **Speaker** and **Microphone** to switch between Hands-free mode and private mode; Touch


- Mute** to mute microphone so that the receiver cannot hear from your side.

Disconnection



- Touch the name of the connected device to disconnect both Bluetooth phone and Bluetooth music.
- Touch the **Phone** to disconnect the Bluetooth phone.
- Touch the **Music** to disconnect the Bluetooth music.
- Touch the **Delete** to delete the device paired.
- End the connection directly on the mobile device;

The product supports A2DP、AVRCP、PBAP and HFP protocol; Make sure Bluetooth device volume is turned to max.



Switch Tracks


Touch  or  to switch to previous or next music;

Play/Pause

Touch  to play, touch  to pause, or operate on the connected device;

Apple CarPlay

CarPlay is a safer way to use iPhone while you are driving. You can get driving directions, make phone calls, listen and send messages, and enjoy your favorite music via car’ s built-in display.



Wired connection

Connect your iPhone to USB port with a lightning cable(not included).

When using CarPlay through USB port, there is no need to pair your iPhone. If other device is connected via Bluetooth, it will be disconnected for the duration of CarPlay use;


Using CarPlay

- Tap on Phone icon for calling.
- Tap on audio app icon to enjoy your favorite music.
- Tap on map app icon to let the iPhone show you the way.
- Tap on message icon to listen or dictate a new message.
- Send commands via Siri voice control. Initiate Siri by.
- Touching and holding home button on the iPhone or CarPlay screen.
- Touching voice key on the front panel.
- Pressing steering wheel control(some cars).
- Saying “Hey, Siri” .
- Tap on  to return to CarPlay main menu.
- Tap on  to return to product main menu.

Android Auto

Android Auto is made to help you focus on the road. Connect your phone to car’ s built-in display, Android apps show up onscreen. Tap to get driving directions, make hands-free calls, talk to send a text, and enjoy your favorite music.

If you have Android 9 or below, install the Android Auto app on your phone from Google Play Store. With Android 10 or above, Android Auto is built in, so you don’ t need the app to get started



Wired connection

Connect your Android Auto compatible Phone to USB port with a USB cable (not included, original cable is recommended).

When using Android Auto through USB port, Bluetooth will connect automatically. Bluetooth connection is needed for the duration of Android Auto use.


Using Android Auto

- Tap on Phone icon for calling.
- Tap on audio app icon to enjoy your favorite music.
- Tap on map app icon to let the phone show you the way.
- Tap on message icon to listen or dictate a new message.
- Send commands via Google Assistant. Initiate Google Assistant by
 - Touching mic icon on Android Auto screen.
 - Touching voice key on the front panel.
 - Pressing steering wheel control (some cars).
 - Saying “OK, Google” .
- Tap on  to return to Android Auto main menu.
- Tap on  to return to product main menu.


iPod

Connect to iPhone/ iPod.

General Settings





- Touch to select the time zone of the region;
- Touch to set date, touch OK for setting done;
- Touch to set the time, touch OK for setting done;
- Open/Close 24H mode
- Open/Close Auto Adjust mode
- Open/Close auto launch for Android Auto(Android Auto projection mode is automatically active or not)



- Touch to select language;
- Open/Close Rear View Camera Delay mode;
- Open/Close ACC OFF Delay mode
- Enter advance settings;
- Touch to recovery to factory settings


Advance settings

Ingrese la contraseña 0000



- Steer wheel control settings;
- Select a different boot logo;
- Open/close the Enable Trajectory mode;
- Screenshot Control: after opening the screenshot function, press the standby button ;
- Touch to choose the Static Trajectory Adjust setting;
- Touch to choose left driving position or right driving position (for CarPlay), reconnect to take effect;
- Select a different Led color;
- Touch  to returnn;


Steering Wheel Control




After the **Calibrate** is touched, select the keys you wanted to set. Pressing one steering wheel key when the screen pop a window with “Press the physical key on the steering wheel”, the key will keep the function of the item after touching **Confirm** with the item displaying **Activated** (repeat all wanted items

before confirm). One key has just a function after setting for once. Touch **Calibrate** to recalibrate the key.

Audio Settings




- Open/Close beep, one touch one beep.
- Open/Close loudness effect.
- Regulate subwoofer effect.
- Adjust the volume for each audio source.




- Select the sound effect, choose it directly.
- Move original point to adjust the speaker output balance.

Display Settings



- Adjust screen brightness(when vehicle light is on, adjust night brightness).
- Recover to default values.

Bluetooth Settings and Device




- Open/Close Bluetooth.
- Open/Close automatic connection.
- Open/Close automatic receiving; if open, the incoming call will be received automatically.

phonebook; if open, the product will automatically download phonebook from mobile phone when Bluetooth connection is done(need permission of mobile phone);

Change device name

- Revised device name.

Radio Settings



- When the scan quality is adjusted to the left, the stop sensitivity will be improved(more stations); On the - contrary, the stop sensitivity will be decreased(less stations);
- Touch to recover to default stop sensitivity;
- Touch to select the region, please do not change the settings arbitrarily;
- Open/Close RDS;

Addition: Drag up on radio label to check product version

Common Problems and Solutions

When there is a problem with the machine

- Recovery to factory settings or reset;
- Try reigniting;
- Please check the phenomena that described in the table below and try to use the solutions;
- Contact Service Center;

Machine/function	Phenomena	Solutions
Machine	Cannot power on/off	Check the connection, if it is broken, try to reconnect it; Check the main fuse, if it is damaged, replace it; Press reset key;
	No sound	Adjust the volume; Confirm whether the music and video is supported or not; Confirm whether the connection of the power amplifier is lost;
Reversing	Abnormal picture	Exit reversing mode and enter again; Check whether the camera is covered by foreign matters; Check whether the type of reverse camera is matched or not; Check the reversing signal cable;
Radio	Noisy; Cannot search the station	Ensure there is no metal products around the machine; Driving the vehicle to the place where the radio signal is good and search the station; If the solutions above are invalid, please check whether the antenna is disconnected, damaged, etc.;
Bluetooth	Connecting fail	Please make sure that the Bluetooth of mobile device is turned on, the machine is not connected;
USB playing	Playing fail	Ensure the U disk is not damaged; Please make sure that the format of content is supported;

Blaupunkt Technology Americas S.A. Phone:
+595 21 329 7313

E-mail: info@bpamericas.com