


技术要求：
1、材质：80g双胶纸 2、成型尺寸：80X100MM 3、印刷色：黑色印刷 4、工艺：正反面印刷，先对折再对折

英语

Product Description



1. Left speaker

2. Right speaker

3. Power & mode switching

① Long press to turn on / off

② Short press Bluetooth / aux mode switch

4. Light & pause / play adjustment

① Short press light mode switch

② Long press pause / play

5. Previous & volume+

① Long press previous song

② Short press volume+

6. Next & volume-

① Long press next song

② Short press volume-

7. FX LED light effects

8. 3.5mm audio jack

9. USB jack: 5V speaker input power

Bluetooth mode

1. After the speaker is powered on, long press the **MODE** key to power on. The default mode of power on is aux mode. Short press to switch the Bluetooth / aux mode. Then open the Bluetooth device of the mobile phone or computer, search the corresponding Bluetooth device, name it " **R40** ", and click connect. After pairing and connecting, there will be a prompt tone, you can play music

2 after connecting with mobile phone once, Bluetooth has memory function. After turning on the Bluetooth of mobile phone, it can connect automatically or manually according to different types of mobile phones. If it needs to be disconnected, the Bluetooth settings can be disconnected through the mobile phone.

3. Insert aux in and press **MODE** key to switch to aux mode.

Note:

If the audio cable is connected to the computer or the mobile phone has current noise, please turn the audio cable head to adjust until there is no current noise.

FCC Caution

FCC ID:**A202205R40**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and; (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Mobile device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.




R40

用户手册

取扱説明書

USER MANUAL

产品说明



1.左音箱

2.右音箱

3.电源&模式切换

①长按开关机

②短按蓝牙/AUX模式切换

4.灯光&暂停/播放调节

①短按灯光模式切换

②长按暂停/播放

5.上一曲&音量+

①长按上一曲

②短按音量+

6.下一曲&音量-

①长按下一曲

②短按音量-

7. RGB灯光

8. 3.5mm音频输入

9. USB 5V/1A电源输入

蓝牙模式

1.音箱通电后，长按MODE键开机，开机默认模式为AUX模式，短按为蓝牙/AUX 模式切换，然后打开手机或电脑蓝牙设备，搜索相应的蓝牙命名为“R40”，然后单击连接。配对连接完成后会有提示音，你可以放音乐

2与手机连接一次后，蓝牙就有了记忆功能。打开手机蓝牙后，可以自动连接或根据不同类型的手机手动连接。如果它需要断开，可以通过手机断开蓝牙设置。

3.插入AUX IN连续短按MODE键切换到AUX 模式。

注：

如果音频电缆连接到电脑或手机有电流噪音，请转动音频电缆头进行调整，直到没有电流噪音为止。

规格

蓝牙版本：V5.0

蓝牙接收距离：≥ 10米

输出功率（RMS）：5W×2

扬声器尺寸：2.5英寸×2


频率响应：60Hz-20KHz

电源：USB 5V/1A

音频输入：蓝牙/3.5mm AUX

产品尺寸：W83×D103×H180mm

製品の説明



1.左スピーカー

2.右スピーカー

3.電源&モード切替

①長押しスイッチ

②短押しブルートゥース/AUXモード切替

4.ライト&一時停止/再生調整

①ライトモードを短く切り替える

②長押しして一時停止/再生

5.前の曲&ボリューム+

①前の曲を長押しする

②音量+を短く押す

6.次の曲&ボリューム-

①1曲長押しする

②音量を短く押す-

7.RGBライト

8.3.5 mmオーディオ入力

9.USB 5 V/1 A電源入力

Bluetoothモード

1.スピーカ-の電源を入れた後、MODEキーを長く押し-て電源を入れ、電源を入れるデフォルトモードはAUXモードである。Bluetooth/AUXモードに切り替え、携帯電話やパソコンのBluetoothデバイスをオンにします。対応するBluetoothの名前を「R40」と検索し、「接続」をクリックします。ペア接続完了成後にヒント音があり、音楽を流すことができます

2一度携帯電話に接続すると、Bluetoothには記憶機能があります。携帯電話のBluetoothを開くと、自動的に接続したり、異なるタイプの携帯電話に手動で接続したりすることができます。切断する必要がある場合は、携帯電話でBluetooth設定を解除できます。

3.AUX INを挿入し、MODEキーを連続的に押してAUXモードに切り替えます。

メモ：

オーディオケーブルがパソコンや携帯電話に接続されている場合、電気ノイズが発生した場合は、音を回してください周波数ケーブルヘッドは、電流ノイズが発生しないまで調整します。

きかく

Bluetoothバージョン:V 5.0

Bluetooth受信距離：≥10 m

出力パワー（RMS）：5 W×2

スピーカサイズ:2.5インチ×2

周波数応答：60 Hz-20 KHz

電源：USB 5 V/1 A

オーディオ入力：Bluetooth/3.5 mm AUX

製品サイズ：W 83×D103×H180mm

中文版

日语