



User Manual

Model: H70B8
Govee Lightwall

IMPORTANT SAFETY INSTRUCTIONS

When using products, basic precautions should always be practiced including the following:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

- All safety messages will alert you to know what the potential hazard is, tell you how to reduce the chance of injury, and let you know what can happen if the instructions are not followed.
- Correct voltage: Make sure your local outlet voltage and circuit frequency correspond to the values indicated on the appliance's rating label.
- This is the Safety Alert Symbol. This symbol alerts you to potential hazards that may result in serious injury. All safety messages will follow the Safety Alert Symbol and either the words "DANGER" Or "WARNING". -Danger means that failure to heed this safety statement may result in severe injury or death. -Warning means that failure to heed this safety statement may result in extensive product damage, serious injury, or death. -Caution means that failure to heed this safety statement may result in minor or moderate injury, or property or equipment damage.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of the appliance or any other appliance. The fumes can create a fire hazard or explosion.
- Never clean appliance parts with flammable fluids or harsh chemicals. The fumes can create a fire hazard or explosion.

- The product is not a toy. Children and the disabled should use it under adult supervision.
- Do not allow children to assemble and install this product.
- **DO NOT ATTEMPT TO OPEN, MODIFY, OR REPAIR THIS PRODUCT.** Any alteration or use of non-approved parts voids all warranties, negates compliance certifications, and may result in malfunction, electric shock, fire, or personal injury.
- Do not cover the product with flammable materials such as cloth or paper to prevent fire accidents.
- Do not place the product near windy areas or flammable items to avoid accidents such as fires.
- Please do not operate the product with wet hands or pull on the power cord, as this may damage the power cord and cause a fire or electric shock.
- When the product is not in use for a long period of time, please unplug the power cord from the outlet to prevent fire accidents.
- Regularly inspect the cable, power supply, and all other components. Do not use this product if any component is damaged.
- If the LED light source does not illuminate when the light is turned on, please disconnect the power supply, perform troubleshooting checks first, and if it still does not illuminate, please consult after-sales service.
- When cleaning the light fixture, please turn off the power supply, use a soft cloth dipped in neutral detergent, wring it out, wipe the fixture, and then wipe it dry with a dry cloth.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
Children should be supervised to ensure that they do not play with the appliance.

- The product is not suitable for installation in bathrooms.
- For ambiance lighting only. Not for illumination.
- This device uses a non-replaceable light source. When the light source reaches the end of its life cycle, this device should be replaced.
- The light source or separate control gear is not intended for use in other applications.
- Do not connect the lighting strings to the supply while it is in the packing or wound onto a reel.
- Do not use the lighting strings when covered or recessed into a surface.
- Do not open or cut the lighting strings.
- Move all cribs, beds furniture and toys away from the lights, Do not tie the bottom of the string lights and form loops as this could wrap around a child's neck and cause SUFFOCATION.
- This product is rated as IP65 Waterproof. It can be used outdoors but cannot be immersed in water.
- The internal light sources of the string lights cannot be replaced. If the light sources sustain damage, the product should be replaced.
- Do not allow children to assemble and install this product without adult supervision.
- Avoid installing this product near major heat sources.
- External dimmers cannot be used with this product.
- Use this product with the provided power adapter only.
- To reduce the risk of strangulation, the flexible wiring connected to this luminaire shall be effectively fixed to the wall if the wiring is within arm's reach.
- Keep all string lights out of the reach of children.
- Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.

- This seasonal use product is not intended for permanent installation or use.
- Do not mount or place near gas or electric heaters, fireplaces, candles or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Unplug the product when leaving the house, or when retiring for the night, or if left unattended.
- This is an electric product – not a toy! To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.
- Do not use this product for other than its intended use.
- Do not hang ornaments or other objects from cord, wire, or light string.
- Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- Do not cover the product with cloth, paper or any material not part of the product when in use.
- To reduce the risk of fire and electric shock: Do not install on trees having needles, leaves or branch coverings of metal or materials which look like metal, and
- To reduce the risk of fire and electric shock: Do not mount or support strings in a manner that can cut or damage wire insulation.
- To reduce the risk of electric shock, use only with the power-supply cord provided or with a cord set intended for outdoor use.
- Do not use a cracked, frayed, or damaged cord. Inspect the cord periodically.
- Do not abuse cord – Do not carry product by the cord or yank or pull it to disconnect from the outlet.

- Disconnect the product from the outlet when not in use.
- Do not place near standing areas of water, such as ponds and pools.
- To reduce the risk of fire or electric shock, do not attempt to replace lamps or modify string.
- Do not connect to another lighting string, decorative outfit, or seasonal product.
- To reduce the likelihood of excessive heat and possible damage, use only decorative lamp accessories packaged with this product.
- Read and follow all instructions that are on the product or provided with the product.

SAVE THESE INSTRUCTIONS

Use and Care Instructions

- Do not mount or support wires in a manner that can cut or damage wire insulation.
- When not in use, store neatly in a cool, dry location protected from sunlight.
- Before using or reusing, inspect product carefully. Discard any products that have cut, damaged, or frayed wire insulation or cords, cracks in the enclosures, loose connections, or exposed copper wire.
- When storing the product, carefully remove the product from wherever it is placed, to avoid any undue strain or stress on the product conductors, connections, and wires.


Introduction

Thank you for choosing Govee Lightwall. This light features a metal steel frame structure for easy installation and disassembly, suitable for both indoor and outdoor use. Featuring a 32 × 48 array of 1536 high-density LED lights, it delivers rich and varied lighting effects. Perfect for ambient lighting and decoration in gardens, stages, or any space, it also shines during parties and holidays like Christmas, Valentine's Day, and Halloween. With DIY and Music modes, you can design your own lighting effects to add excitement to your gatherings.

What You Get

Item	Quantity
Light Curtain	3
Control Box	1
Power Adapter	1
Vertical Support Pole	2
Horizontal Support Pole	1
Water Bag	2
Light Curtain Hanging Hook	6
Light Curtain Fixing Hook	2
Light Curtain Connection Clip	8
Screwdriver	1
Bottom Screws	4
Service Card	1
User Manual	1

At a Glance



- | | |
|------------------------------|---------------------------------|
| ① Control Box | ⑧ Water Bag |
| ② Power Adapter | ⑨ Base |
| ③ Horizontal Support Pole | ⑩ Light Curtain Fixing Hook |
| ④ Light Curtain Hanging Hook | ⑪ Light Curtain Connection Clip |
| ⑤ Vertical Support Pole | ⑫ Light Curtain Connection Cord |
| ⑥ Screwdriver | ⑬ Bottom Channel |
| ⑦ Bottom Screws | |

Control Box:

On/Off Button

- Press to turn the light on or off.
- Long press for 5 seconds to reset.



Pairing Your Light with Govee Home App

What You Need

- A Wi-Fi router supporting 2.4GHz and 802.11 b/g/n bands. 5GHz is not supported.
- A smartphone or tablet running iOS or Android.



The Apple logo® is a registered trademark of Apple Inc. App Store® is a service mark of Apple Inc.



Google Play is a trademark of Google LLC.

1. Download Govee Home App from the App Store (iOS devices) or GooglePlay (Android devices).
2. Turn on your smartphone's Bluetooth.
3. Open the app, tap the “ + ” icon in the top right corner and search for “H70B8”.
4. Tap the device icon and follow the on-screen instructions to complete pairing.

Controlling the Device with Your Voice

1. Open the app, then tap the device icon to enter the details page.
2. Tap the settings icon in the top right corner.
3. Select User Guide and follow the on-screen instructions to control the device using your voice.

Specifications

Power Input (Adapter)	100-240V ~ 50/60Hz 1.8A
Power Input (Control Box)	24VDC 3A
Light Displaying Technology	RGBIC
Waterproof	String Light (IP65) Control Box (IP65)
Control Methods	App, Control Box, Voice Control
Working Temperature	-20°C ~ 45°C / -4°F ~ 113°F

Matter Guide

Cautions:

1. You need to complete the network connection of apps that support Matter (eg. Google Home/Apple Homekit etc.) within 15 minutes after the product is powered on when using Matter for the first time.
2. An IPv6 network is required.
3. Changing the network may cause Matter to malfunction.
4. If the product cannot connect to the app, press and hold the power button on the control box for 5 seconds to restore the factory settings. After that, try connecting again later.

Step 1

Find the QR code or device number of Matter on the product or on Device Settings page in Govee Home App.

Step 2

Turn on the Bluetooth on your smartphone.

Step 3

Download and open the app that supports Matter like Google Home/Apple Homekit, etc.

Step 4

Use the device number or QR code on the product in the app to complete the network connection of Matter for the product.

Matter Simple Setup Guide

Instruction:

Matter Simple Setup (MSS) is a function supported by Amazon Frustration-Free Setup (FFS) technology. FFS securely utilizes the network of helper or provisioner devices (such as compatible Echo devices) that are already connected to the internet. These provisioners help to set up provisioned devices in fewer steps. Matter simple setup can help connect Matter-certified devices to your home networks in fewer steps.

Steps for MSS functions:

Step 1

Make sure you select the option "Link to Alexa account" when purchasing the device and save your network passwords to Amazon.

Step 2

Power on the device and connect it to the same Wi-Fi network used by the Echo device with the Alexa account logged in.

Step 3

Echo occasionally captures device information, and when it picks up a signal for an MSS-enabled device (usually within five minutes), it adds the device to the device list on the Alexa App. After the device is powered on, you can directly speak to Echo and say, "Alexa, discover my device."

Step 4

There will be a voice notification and pop-up after the device is successfully added. You can then use Alexa to turn on/off the device and set its brightness and colors.

Tip: When adding multiple devices via MSS, the devices will be named "First Light", "Second Light", and "Third Light" on the Alexa App device page, depending on the order they are added. The devices can be renamed as needed.

How can you manage settings for Matter simple setup?

You can disable Frustration-Free Setup for all your devices by visiting the "Manage Your Content and Devices page" (<https://www.amazon.com/mycd>). From the Saved Network Passwords tab under Preferences, you can prevent new Matter simple setup enabled devices from accessing or deleting your stored network passwords. If you own a router with Matter simple setup turned on and want to prevent your network passwords from syncing with Amazon, consult your router manufacturer on how to disable Matter simple setup.

More Support

You can access "Amazon Help & Customer Service" for more help and support regarding FFS&MSS (<https://www.amazon.com/gp/help/customer/display>).

Troubleshooting

1. Failed to connect to Govee Home App.
 - a. Make sure the curtain lights are connected to power.
 - b. Make sure your smartphone's Bluetooth is enabled.
 - c. Keep your smartphone close to the control box and try again.
 2. Missing parts/Receiving products from a secondary sale.
 - a. Check the pictures on the web page to confirm what parts are missing and contact customer service in the app for replacements.
 - b. If you received a product from a secondary sale or a product that cannot work properly, please contact customer service in the app for a replacement.
 3. Network failure.
 - a. Make sure your home Wi-Fi is 2.4 Ghz, and your smartphone's Bluetooth is on.
 - b. Long press the control box for more than 5s to reset the whole light. Unbind and then rebind the light.
 - c. If the light is too far away from the Wi-Fi, bring the device closer to the Wi-Fi, and then reconnect to the network.
 - d. Check if there are too many devices connected to the network. If so, change to another network.
 - e. If the above methods cannot solve your problems, please contact customer service in the app to replace the control box.
 4. App operation guide is needed.
 - a. Open Govee Home App, tap My Profile>>Govee Instructions>>AppGuide>>How to Use, to find more details.
- If your problem persists, please contact Customer Support.

FCC Statement

This device complies with Part 15 of the FCC Rules and Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC and ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Responsible party (this contact information is only for FCC matters) :

Name: GOVEE MOMENTS(US) TRADING LIMITED

Address: 2501 Chatham Rd Suite R Springfield IL 62704

Email: certification@govee.com

Contact information: <https://www.govee.com/support>

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Qianyan Technology LTD is under license.

The trademark Govee has been authorised to Shenzhen Qianyan Technology LTD.

Copyright ©2021 Shenzhen Qianyan Technology LTD.

All Rights Reserved.

Customer Service



Warranty: 12-Month Limited Warranty



Support: Lifetime Technical Support



Email: support@govee.com



Official Website: www.govee.com



@GOVEE



@goveeofficial



@govee.official



@GoveeOfficial



@GOVEE



Govee Home App

For FAQs and more information,
please visit: www.govee.com