


蓝牙自拍杆 使用手册

自拍杆功能介绍



遥控器功能键



蓝牙遥控使用步骤

第1步：在手机上点击 设置 > 蓝牙，并将手机蓝牙打开。
第2步：长按遥控器开关键2秒开机。
第3步：当手机搜索到名为"Selfie"的蓝牙设备时，点击并选择配对。
第4步：打开相机、短视频APP，按下遥控器功能键即可在手机上实现相对应的操作。
第5步：长按遥控器开关键2秒关机。
温馨提示：请根据您的手机型号，扫描下方二维码获取视频教程。

扫码获取视频教程



苹果手机




安卓手机

电池更换 / 充电步骤

可拆卸电池款：

按图示箭头方向将后盖推开，更换电池后将后盖安装回去。




充电款：

使用USB 5V的适配器进行充电。（充电时红灯常亮，充满后指示灯熄灭）



补光灯 (选配)



故障排除

1. 蓝牙遥控器无法开机。
 - 更换新电池。
 2. 蓝牙无法连接，或者无法正常工作。
 - 移除手机上的蓝牙配对，重启蓝牙遥控器后重新配对连接。
- 注意事项：**
1. 请勿将产品置于低温、潮湿环境保存。
 2. 请勿将产品置于曝晒、烘烤等高温环境。
 3. 请勿在设备被限制使用的场所中使用，避免违反公共秩序。
 4. 更换电池时，请将电池正极朝外放置，禁止将正负极反接。
 5. 本产品含有电池，请放置于婴幼儿触模不到的地方，防止小孩误吞。


合格证



CE RoHS

Selfie Stick User Manual

At A Glance



Function Keys



Quick Steps for Remote

Step 1: On your phone, tap Settings > Bluetooth, then turn on the Bluetooth.
Step 2: Hold down the switch button for 2 seconds to turn on the remote control.
Step 3: Once the Bluetooth name of "Selfie" appears in the display, select it and tap "pair".
Step 4: Open the Camera, Social Media or Novel App, and press function keys on the remote to operate your phone.
Step 5: Hold down the switch button for 2 seconds to turn off the remote control.
Reminder: Please Scan the following QR Code corresponding to the model of your mobile phone for more details.

QR Code



IOS




Android

Remote Battery

Replaceable Type:

Slide the back cover in the direction of the arrow, then replace a new battery, and finally insert the cover back.




Rechargeable Type:

Use a USB 5V adapter to charge the remote control (the red light is always on when charging, and goes out when fully charged)



Fill Light (option)



Troubleshooting:

1. If the remote cannot be turned on.
 - Replace a new battery.
 2. If the remote can't be connected.
 - Delete the Bluetooth pairing on your phone, reboot the remote and start a new device search.
- Attention:**
1. Don't store the product in icy or damp environment.
 2. Don't place the product in the heat.
 3. Don't use the product in restricted district to avoid violating public order.
 4. When replacing the battery, place the positive pole "+" of the battery outwards.
 5. This product contains a battery, please place it out of the touch of infants to prevent children from swallowing it by mistake.

Certificated



CE RoHS

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.