
athom

Smart Home




Devices User Manual

www.athom.tech

support@athom.tech

Step 1: Power on the device and use your computer or phone search the WiFi until find athom_xxxx and click to connect, wait several seconds until configuration page pop up



Step 2: Input your 2.4G WiFi router SSID and password, then click save

3:17

192.168.4.1
Athen_02F8F2

4G

< > Log In Cancel

WiFi Networks

WiFi Settings

SSID

Password

Save

OTA Update

Choose File


no file selected

Update

Step 3: then go to your Home Assistant
It will shows new devices discovered, press
config to add it succesfully



Step 4: After config successfully , now you can monitoring and control the device with Home Assitant



Notice : for more information

<http://www.athom.tech>

<https://github.com/athom-tech/athom-configs>

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.