

Wireless Microphone
x1/2*

Receiver
x1

Type-C Charging Cable
x1

Users Manual
x1

Diagram of the back of the JBL Clip 3 showing controls:

- Mic Volume +/-
- Sound Effect Switch
- Power On/Off
(Press for power on/
Holding press for power off)
- Mic Indicator Light
- Charging Port

Solid Blue	Microphone in normal working mode
Quick Flashing Blue	Microphone in pairing mode
Solid Red	Low power on microphone
Green Light Flashing	Microphone under charging

Indicator Light

Power key

- Holding press for power on/off
- Press twice to reconnect Bluetooth

Type-C Port

Solid Blue	Microphone in normal working mode
Quick Flashing Blue	Receiver and Microphone in pairing mode
Slow Flashing Blue	Receiver and Microphone unpaired
Slow Flashing Red	Low power
Slow Flashing Green	Receiver under charging
Solid Green	Receiver fully charged

Setting Steps for Speaker Use

- 1.Insert the 3.5mm Aux cable of the receiver into the Speaker's AUX connection socket;
- 2.Connect the Phone/Pad with the receiver through Bluetooth and play songs;
- 3.Turn on the microphone and start singing

1. Insert the 3.5mm Aux cable of the receiver into the Speaker's AUX connection socket;
2. Connect the Phone/Pad with the receiver through Bluetooth and play songs;
3. Turn on the microphone and start singing.

1. Insert the 3.5mm Aux cable of the receiver into the Car's AUX connection socket.
2. Connect the Phone/Pad with the receiver through bluetooth and play songs.
3. Turn on the microphone and start singing.

Note: The product has been paired before delivery. Do not pair again unless it is necessary. It is recommended that users conduct the pairing in the event that the microphone and receiver fail to connect (please refer to the description):

1. Keep one microphone power off, Hold the VOLUME+ key and POWER key at the same time for over 5s, the indicator light of microphone will frequently flicker to start the pairing mode;
2. Keep another microphone power off, Hold the VOLUME- key and POWER key at the same time for over 5s, the indicator light of microphone will frequently flicker to start the pairing mode;



Users Manual

双面印刷版面的对齐

