



QUICK START GUIDE

FOR THE ULTIMATE WAND EXPERIENCE,
DOWNLOAD THE APP*




Scan the QR code with your phone's camera to install the free Harry Potter: Magic Caster Wand™ app.

For more information, including warranty information, visit **HarryPotterMagicCasterWand.com**

CHARGING WAND AND BOX

WAND AND BOX ARRIVE PRECHARGED.

To store and charge wand, place on the built-in USB port inside the box indentation.



Then, connect USB charging cable (supplied in the box) to the port on the side of the wand box.

Connect the charging cable to power source.

WARNING: To reduce the risk of injury, wand should be charged by the box. The box should only be charged via a compliant USB-C cable and USB 5V/1A-2A charger. Do not try to remove or replace the batteries. A USB charger is not included.

FCC/IC STATEMENT

This device complies with part 15 of the FCC Rules and Industry Canada license-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de classe B est conforme à la norme canadienne NMB-003.

CAN ICES-3 (B) / NMB-3 (B)

Hereby, Warner Bros. declares that the radio equipment type Wand, Box (associated with Family No: WBMC22G1) is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

HarryPotterMagicCasterWand.com/ComplianceInformation

This radio equipment operates with the following frequency bands and maximum radio-frequency power:

Family No (device)	Frequency Bands	Maximum Conducted Power (dBm)
WBMC22G1 (Wand)	Bluetooth LE 2.4GHz	4dBm
WBMC22G1 (Box)	Bluetooth LE 2.4GHz	4dBm

FCC ID: 2A82K-WBMC22G1W
FCC ID: 2A82K-WBMC22G1B

IC: 12514A-WBMC22G1W
IC: 12514A-WBMC22G1B



© Warner Bros. Entertainment Inc.

HARRY POTTER: MAGIC CASTER WAND, WIZARDING WORLD and all related trademarks, characters, names, and related indicia are © & ™ Warner Bros. Entertainment Inc.

WB SHIELD: © & ™ WBEI. Publishing Rights © JKR. (s22)

Patent Pending

*A compatible smartphone or tablet and the companion app are required. Companion app requires registration for a free account; consent of a parent or legal guardian may be required to register for the app in certain territories. Some experiences may require future downloads. Additional data rates may apply when downloading the application.

To find all compatible devices, go to HarryPotterMagicCasterWand.com/CompatibleDevices